# LEDs:

green = on

amber = off

blue = pairing

red = replace

battery

vert = allumer

ambre = éteindre

bleu = jumelage

rouge = remplacer

la batterie


grün = ein

bernstein = aus

blau = paarung

rot = batterie

ersetzen



Press the power button to turn on / off.

To pair via Bluetooth, press & hold the power button until the light flashes blue.

Appuyez sur le bouton d'alimentation pour activer / désactiver.

Pour le jumelage, appuyez et maintenez le bouton d'alimentation jusqu'à ce que la lumière clignote bleu.

Drücken Sie den Netzschalter, um ein / aus.

Um über Bluetooth koppeln, drücken und halten Sie die Power-Taste, bis das Licht blinkt blau.

# Warni ng

### Notice:

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

### Notice:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

#### Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

## conditions:

(1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Notice:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.