## Artwork for RF board housing on BE1282

Model information label to be placed here, on the Transmitter unit.

Serial number to be placed here,

on the Transmitter unit.

