<u>Use</u>r's Manual





TB-36ML
Bluetooth Wireless Headset

Contents

What's in the box
Pair to your Bluetooth phone
Charging the battery
Battery information
Turning headset on / off
Wearing your headset
Making a call
Ending a call
Reject an incoming call
Answering a call
Transferring a call
Call-waiting (Three-Way Calling)
Volume control & Mute function
Summary of button operation
Safety and general information
FCC & IC Statement
EU
Warranty

1 What's in the box

The headset contains the following parts:


- 1.Multi-function Button
- 2.Ear Hook
- 3.Charging Socket
- 4.Microphone
- 5.Volume Up Button
- 6.Speaker
- 7.Volume Down Button
- 8.Indicator Light

Package contents:

- A. TB-36ML Bluetooth Headset
- B. Charging Charger
- C. User Manual

Optional:


D. Car Charger



Pair to your Bluetooth phone

Before you use your headset for the first time, ensure that it is paired to use it with devices such as your Bluetooth phone.

Once you pair the headset with a device, the headset will be automatically connected to the device whenever you turn the headset on.







headset by following your phone's instruction quide. Typically, go to the "Bluetooth" menu on your phone and then selecting the option to "discover" a Bluetooth device.



headset and ask if you want to pair with it. Confirm this by pressing "YES" or "OK".



Enter passkey or PIN=0000 (4 zeros). then press "YES" or "OK"


IMPORTANT!

When the headset paired with mobile phone, the indication light will flash 1 time every 3 seconds. If failed, the blue indicator light will flash 1 time every 5 seconds.

3 Charging the battery

This device has an internal, nonremovable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device.

- 1. Connect the charger to the correct outlet.
- While the charger is connected, the red indicator light is displayed during charging. If charging does not start, disconnect the charger, plug it in again, and retry. Charging the battery fully may take up to 2 hours.
- When the battery is fully charged, the red indicator light turns off.
 Disconnect the charger from the headset and the wall outlet.



Open the cover

When battery power is low, the headset will remind you by beeps every 20 seconds, and the red indicator light will also flash.

IMPORTANT NOTICE!

- For first time use, please charge the headset fully. If you cannot see the indicator light when charging, please leave the headset charging for a while (Approx 15-35 Minutes), the indicator light will then illuminate.
- 2. If after a full charge, you cannot turn the headset on, please reconnect the headset to the charger for a few seconds to activate it.

4 Battery information

Your device is powered by a chargeable battery. The full performance of a new battery is a achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. If the headset is left unused for a long time, please turn off and fully charge the headset. To prevent over-dischage, which will endanger the battery, you are recommended to charge the headset fully each month.

Never use a charger that is damaged.

5 Turning headset on /off


	How to act	Tones	Indicators
Turning on the headset			The blue indicator will flash indicating the power is on.
Turning off the headset	Press and hold the Multi-function Button for 4 seconds until you see a red indicator flashing, then release it.	Turn-Off me l ody	After red indicator flash, it will be turned off.

Please note: To conserve power, the headset will automatically turn off if it detects that it is not connected to a device for more then 10 minutes.

6 Wearing your headset

To use the headset with the ear hook:

The headset can be worn on either the Left or Right ear. If you want to wear the headset on the other ear, please change the direction of the ear hook. Follow the figures below.



7 Making a call

* Using phone's keypad

(1)Dial number on keypad.

(2)Press phone's "send"key.

* Using voice-activated dialing

Please check if your mobile phone supports voice dialing function. If your phone does support this function, please follow your mobile phone manual instructions for set up. (1) Press the Multi-function Button briefly, then you can hear a short beep.

(2) Say the name of person you wish to call.

(3) If the voice tags are paired to the related phone number stored in you mobile phone, the number will be dialed.

* Last number dialing

Please check if your mobile phone supports the redial function.

(1) Press the Volume Down Button for 2 seconds.

(2) You can hear a short beep.

8 Ending a call

Press the Multi-function Button briefly from the headset while you are on the line. You can also end call from your mobile.

9 Reject an incoming call

When you receive an incoming call, press and hold the Multi-function Button for 2 seconds and then release.

6

10 Answering a call

When you receive an incoming call, press the Multi-function Button briefly.

11 Transferring a call

- (1) Headset to phone: Press Volume Up Button for 2 seconds.
- (2) Phone to headset: Press Volume Up Button for 2 seconds.

12 Call-waiting (Three-Way Calling)

Before using 3 way calling with your headset, you must ensure that your phone supports the Hands-free Profile and that the "call hold and/or multiparty" services are available in the network.

- (1)Press the Multi-function Button briefly to accept or receive waiting (incoming) call and end active call.
- (2) Press the Multi-function Button for 2 seconds to accept waiting (incoming) call and hold active call.

13 Volume control & Mute function

You can adjust the volume by pressing volume up and volume down button.

Press and hold the Volume Down Button for 2 seconds, you will hear short beeps low to high. The headset MIC will then be muted and you will hear a remindful melody every 10 seconds. Deactivate the mute function by pressing the Volume Down button 4 seconds, you will hear short beeps, low to high first, and then hear short beeps, high to low, indicating the mute function has been cancelled.

7

14 Summary of button operation

	ACTION	HEADSET STATUS		
Button		Standby (No Ca ll s Active)	Incoming Call	1 ca ll Active
	Quick Press	Initiate voice dialing	Answer ca ll	End ca ll
Mu l ti- function	2 Seconds	-	Reject ca ll	=
Button	4 Seconds	Turn headset OFF	Turn headset OFF	Turn headset OFF
	Quick Press	Increase volume	Increase volume	Increase volume
Vo l ume Up	2 Seconds	-	-	Transfer active call to/from phone
	4 Seconds	-	-	-
	Quick Press	Decrease volume	Decrease volume	Decrease volume
Volume Down	2 Seconds	-	-	Microphone mute ON
	4 Seconds	-	-	Microphone mute OFF

	ACTION	HEADSET STATUS		
Button		1 Ca ll Active, 1 I ncoming Ca ll	1 Ca ll Active, 1 Ca ll on Hold	
	Quick Press	Answer incoming, end active	End active, retrieve held call	
Multi- function	2 Seconds	Answer incoming, hold active	Swap Calls	
Button	4 Seconds	Turn headset OFF	Turn headset OFF	
	Quick Press	Increase volume	Add held call to 3-way-calling	
Vo l ume Up	2 Seconds	-	Transfer active Call to/from Phone	
	4 Seconds	-	-	
	Quick Press	Decrease volume	Add held call to 3-way-calling	
Volume Down	2 Seconds	-	-	
	4 Seconds	-	-	

Please note: The desired function is initiated only when the button is released. It is important that the button is held for the correct period of time.

15 Safety and general information

- 1.Please read this guidebook carefully and follow the instructions.
- 2. To avoid any damage or malfunction of the device do not drop device from high places.
- 3. Keep device away form humidity, water and any other liquid. If the device is exposed to water, moisture and other liquid, do not operate it to avoid any electrical shock, explosion and damage to the device or yourself.
- 4.Do not place or keep this device near any heat sources, such as, direct sun light, radiators, stoves or other apparatus which produce heat. It may cause explosion, dearade the performance and/or reduce battery life.
- 5.Do not modify, repair or disassemble device at discretion (Especially battery: It may cause an explosion). Doing this will avoid the warranty.
- 6.Do not place the heavy objects on the device.
- 7. Use only supplied and approved charger.
 8. Replacement or service must be done by qualified service center or manufacturer.
- 9. Unplug this device when unused for long periods of time or during lightening storms.

⚠ CAUTION: ELECTRIC SHOCK HAZARD

The battery used in this device may present a risk of fire or chemical burn if mistreated.

16 FCC Statement

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

17 EU

This product is CE certified according to the provision of the R&TTE Directive (99/5/EC). Declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Please note that this product uses radio frequency bands not harmonized within EU. Within the EU this product is intended to be used in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg,

The Netherlands, Portugal, Spain, Sweden, United Kingdom and within EFTA in Iceland, Norway and Switzerland.

Bluetooth is a trademark owned by the Bluetooth SIG, Inc.

18 Warranty

The condition of this warranty and our responsibilities under this warranty are as follows: Warranty is non-transferable, and is limited to the original purchaser only.

- * You must be able to prove the date of original purchase of the unit with a dated receipt.
- *The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
- *The responsibility of supplier's products shall be limited to the repair or replacement of the product at it's sole discretion.
- * Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.
- * Supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.
- * Modification and repair of the unit this device must be done by an authorized and qualified service center or returned to the manufacturer.
- *This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.



U.S. and Worldwide Patent Pending. Built on Cambridge Silicone Radio chip. This device complies with Part 15 of the FCC Rules, and the applicable regulations within the EU. Distributed by TrueBlue™

© 2008 TrueBlue™ www.trueblueus.com

All brand and product names are trademarks or registered trademarks of their respective companies.

MADE IN CHINA