


TONE FREQUENCY = 300Hz		
REF: 0dB ⇒ 60% deviation		
AUDIO LEVEL [dB]	DEVIATION [Hz]	
-30	30	
-24	54	
-18	72	
-12	113	
-6	210	
0	366	
6	739	
12	1455	
18	2008	
24	1983	
30	2009	



TONE FREQUENCY = 1000Hz		
REF: 0dB ⇒ 60% deviation		
AUDIO LEVEL [dB]	DEVIATION [Hz]	
-30	80	
-24	126	
-18	204	
-12	422	
-6	701	
0	1552	
6	2021	
12	1983	
18	1931	
24	1996	
30	1986	



TONE FREQUENCY = 2000Hz		
REF: 0dB ⇒ 60% deviation		
AUDIO LEVEL [dB]	DEVIATION [Hz]	
-30	55	
-24	15	
-18	420	
-12	712	
-6	1568	
0	2002	
6	2113	
12	2088	
18	2165	
24	2093	
30	2096	



TONE FREQUENCY = 3000Hz		
REF: 0dB ⇒ 60% deviation		
AUDIO LEVEL [dB]	DEVIATION [Hz]	
-30	117	
-24	218	
-18	351	
-12	792	
-6	1186	
0	1317	
6	1395	
12	1440	
18	1979	
24	2005	
30	2014	

