DACOM®
CREATE A MELODIOUS WORLD

Bluetooth Speaker

Model name:Y003
FCC ID:WTDY003 **The pocket music fairy**

Coco Bluetooth Speaker User Manual **EN**

Perface / Contents

Dear Customer

Thank you for using Bluetooth speaker. Please read the user manual carefully for proper instruction to maximize the advantage of our product. Our Bluetooth speakers are well designed, fashionable, smart and portable, pure acoustic and multi functional. We have patents for the whole series of our Bluetooth speakers.Our Bluetooth speakers are applied with the top advanced electro acoustic technology, providing you the best enjoyment of music any time at home, outdoor or business work, and provide the perfect acoustic with your notebook and any digital audiovisual devices. Lead you to wonderful music,enjoy healthy & happy life.

Contents

Cautions / Tips

Cautions

- Please keep or use this product at normal temperature;
- Do not expose this product in rain or moisture;
- Do not throw this product in case any damage thus made;
- Do not disassemble, repair or reform this product;
- Do not clean this product with any chemical solvents;
- Please use USB power of DC5V for output when needed;
- Please follow the instructions of matched battery; do not throw away or put it in fire to avoid any danger.

Tips

- For your health and longer lifespan of this product, please do not play it with high volume for long time as it will harm your ear.
- In public, please switch it to play in your ear phone, thus will not disturb others.
- Due to its complication, the lithium battery is built-in designed for this product highly improving the safety with less power consumption.
- When an error occurs, please turn it off and pull out the USB socket to avoid any damage to other components.
- The warranty card is not applicable for any deliberate disassembling.

11

Product Description

Item: Bluetooth Speaker
Bluetooth standard: V 4.0
Charging means: power adapter output (DC5V 1A)
Battery: 920mAh
Bluetooth mode: headset / handfree / A2DP /AVRCP
Playing time: up to 5 hours
Standby time: up to 150 hours
Product size: 90.4 x 85 x 40 mm
Product weight: 118 g
Accessories: micro USB charging cable、user manual、audio cable

- This product can be applied to audio from any Bluetooth devices like Bluetooth mobile phones, Bluetooth notebooks.
- When being connected to Bluetooth DONGLE on PC, it can play any audio files on the computer.

12

Product schematic

LED Light
Real-time feedback work status

40mm Inside magnetic trumpet
HD sound

Audio Input
3.5mm Standard audio input jack

USB Jack
Micro USB charging port

Power switch
Power on / off

Multifunction key ○

Portable Hook
Applies to any plug device

Control keys +/-
Volume adjustment / Track selection

13   14

Features

- **Power on**-On the status of power off, push "○" to "on"
  Power off-On the status of power on, push "○" to "off".
- **Pairing**-On the status of power on, press and hold "○" for about 5 seconds, it goes to searching mode, and this may cost 2 minutes; and if it is not pairing within 2 minutes, the speaker will turn to standy mode (disconnected to mobile phone).
- **Voice dialing**-On the status of standby, double press "○"
- **Play / Pause**-Press "○" .
- **Volume control**-Short press "＋" or "－" volume will up or down,there will be a prompt voice when on the loudest sound.
- **Previous/next track**-Long press "－" for 3 seconds switch to previous track,Long press "＋" for 3 seconds Switch to next track
- **Last number redialing**-On the status of standby, press "＋" for about 2 seconds,it will dial the last number you have dialed.(Your mobile phone must support the function.)
- **Answering a call**-When there is a call, short press "○" and you can talk on the speaker.
- **Ending a call**-During the call, short press "○" and the call will be ended.
- **Rejecting a call**-When there is a call, short press "○" for one second and the call will be rejected.

15

Features

- **Microphone muting**-During a call, press "－" for about 2S, microphone is muted; press "－" again for about 2S it will work again.
- **Call switching**-Call switching between mobile phone and speaker: during a call, press "＋" for about 2 seconds, the audio will be switched from the Bluetooth speaker to mobile phone; repress "＋" for about 2 seconds, the audio will be switched from mobile phone back to the Bluetooth speaker.
- **Low power alarm**-On the status of power on, when the battery voltage is lower than 3.2V, there will be a prompt every 60 seconds.
- **Low power shutdown**-On any status of power on, when the battery voltage is lower than 3.0V, the speaker will shutdown automatically.
- **Charging status**-Red light remains solid when charging.
- **Charging completed**-Blue light remains solid when charging completed.
- **Voice Prompt**
  - When the speaker is on, there will be the automatic voice prompt: power on.
  - When the speaker is off, there will be the automatic voice prompt: power off.
  - When the speaker is in pairing mode,there will be the automatic voice prompt: pairing.
  - When being connected successfully, there will be the automatic voice prompt: speaker is connected.
  - When being disconnected, there will be the automatic voice prompt: speaker is disconnected.

16

Features

- **Call waiting**-During a call, another call comes in
  - Double press the "○" button, the current call will be kept waiting while you answer the incoming call;
  - Double press the "○" button, it can switch between two calls;
  - Press the "○" button for 1 second, the current call can be ended and switch to the waiting call.

Remark: To use the above function, your mobile phone must support Bluetooth handfree mode 1.5, and the call waiting function of your mobile phone is on.

- **Handling the call**
  - Pair to the mobile phone: when the speaker is power on, press the "○" button till the red light and blue light flash alternately, the speaker is ready for pairing;search on the mobile phone to find "Dacom Coco speaker" enter the pin code "0000" (if needed) and confirm, then your speaker is connected to the mobile phone;
  - When it is connected with mobile phone and if there is a call from the mobile phone, press "○"to answer it;
  - Note: Some phones do not need to enter a password

- **Automatic shutdown Function**-When the speaker is power on if no Bluetooth devices connected, nor line in , the speaker will be shutdown automatically in 10 minutes.

17

Features

- **Line in Function**-The speaker could be connected to other audio source with audio cable.The speaker gives the priority to Bluetooth, the line in function wont work until Bluetooth signal stopped.

- **Two-link Function**-Connect two mobile phones at the same time with a speaker:
  - Pair to the first mobile phone: on the status of power on, press "○" button till the red light and blue light flash alternately, then the speaker turns to pairing mode, and search on the mobile phone to find "Dacom Coco speaker " enter the pin code "0000" (if needed) and confirm, then your speaker is connected to the mobile phone;
  - Turn off the speaker, and turn off Bluetooth function on the first mobile phone;
  - Pair to the second mobile phone: when it is power on, press "○" button of the speaker till the red light and blue light flash alternately, then the speaker turns to paring mode, and search on the mobile phone to find "Dacom Coco speaker" enter the pin code "0000" (if needed) and confirm, then your speaker is connected to the mobile phone;
  - Connect to the first mobile phone: turn on the Bluetooth function of the mobile phone, find and select "Dacom Coco speaker" from the list, confirm to connect, then it is connected with the speaker; thus your speaker is connected with two mobile phones,so you can play music or make phone call with the two mobile phones.

Note: Some phones do not need to enter the password

18

Handling of the waste Electrical/ After service

The waste Electrical

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly topromote the sustainable reuseof material resources.

Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

After service

(A) Service system
1.Consultancies: Please read this user manual carefully before using this product. For any problem during using it, you can either contact the local retailer or call our customer service hot line: 400-881-0138
2.Exchange service: within exchange time limit, for any indelibrate error during proper use, making sure the product as well as its accessories and package are all not damaged (if the appearance is damaged, it can only be repaired) you can either have it exchanged for a new one or repaired after the error is tested and examined;
3.Warranty service: within the warranty time limit, for any indelibrate error that occurs during proper use, warranty service is free for no charge (the speaker has warranty service for free within one year; for any deliberate damage, the warranty service should be paid).

19

After Service and Explanation

4.Charged warranty service: within three years counting from one year after the date the product was purchased, any error repair will be charged; and user should pay the repair components, freight and labor cost.
5.Any of the below situation is not in the warranty service, but we provide charged service:
① The warranty date is expired;
② The warranty card is altered, or the series number differs from that of the product;
③ Accidental or deliberate damage is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.)
④ cannot provide valid warranty card or invoice (other but can prove that it is within the service limit);
⑤ Any error damage caused by force majeure such as earthquake, fire, flood, lightning strike etc.
⑥ Deliberate assembling, repair or reform without permission from our company.

(B) Explanation of After Service:
1.The date of purchased should be in accordance with that of the invoice, any failure to provide the valid proof, is subjected to the production date.
2.Quality problem does not include user's personal preference to tone and timbre.
3.The shell and user manual package are exclusive to warranty service.
4.For the model that production has been stopped, we only provide functional repair.
5.We are not responsible for any promises by retailer other than our company.

☎ **Services Hot Line: 400-881-0138**

Services time: AM 9:00 – PM6 :00
Monday to Saturday (holiday is exclusive)
http://www.china-dacom.com