In the packaging

· User Manual

Quick start in 4 steps



into the DC port of the chaming

\$300 \$1. Connect nesser adapte to power outlet



into the USB power adapter

. Each the Charmer and and receiver steems seem from under-

. Do not place or store the Charger mat and receiver shere near water or any other liquid. . After deaning, make sure the Charger mat is completely dry before you connect it to an

Warning notifications . Check if the volume indicated on the AC adaptor corresponds to the local volume before you

connect the adjactor to an electrical socket. . Never use the AC advator. Charger mat or receiver places if any of them is damaged in any yay,

. Only use the official AC adaptor (supplied together with the Charger mat). When an unofficial AC adoptor is used or an incorrect DC voltage is used for the Charger roat, the Boht will blink rapidly. He charping will occur in this case...

. Do not stick any metalic labels or any objects to the hottom of the moniver sleeve or nato.

a Home have a nanomalism or other instructed during consultance during or the manufacturer. . Do not use with an extension cord or everload electrical outlets. . Supervision is needed when used by or near children, disabled persons or those with mental.

Return Policy / Warrants Dear Customer.

disabilities.

All products are designed and manufactured to meet the highest standards and deliver high-supility performance. In case you recounter any difficulties when using your peopled, we

recommend that you first consult the user receipt or the information in the support section of

In the unlikely avent of fall are during the varianty societ. Will propose for your sendont to be

Warranty terms

considered to have started three months after the date of manufacturing indicated on the product or as derived from the serial number of the product. If any defect due to faulty materials and/or workmanship occurs within the warranty period. will make arrangements for service. Where a regain is not possible on is gleemed uneconomical may agree to replace the product.

priginal curchase. The numerity applies provided the product has been handled properly for The suggests does not cover for the losses consequent in source including but not limited to loss. of data or loss of business. The Hibrards does not apply it:

■ The sumbace documents have been about in pey way or made i leable. . The model, earlier serial number on the product has been allowed, compact or made deather . Banking or newhat resultingtons and admissions have been rested out by exactly direct

. The defect is caused by abuse or misuse of the product or by environmental conditions that

its intended use and in accordance with the operating instructions.

. The unit has been damaged - including but not limited to damage by pets. lightning. abnormal voltage, water or fire, natural disaster or transport accident, . The product is defective due to year of parts, which can be considered as consumable parts

by their nature. . The product does not function properly because it was not originally designed.

manufactured, approved and/or authorized for the country where you use the product. which might occur in instances where the product has been purchased in another country

This warranty is only solid in the country were the conduct is numbered and is not transferable and

Service needed?

product during shipment.

In order to avoid unnecessary inconvenience, we advise you to need the user manual or consult. inture the conduct without first contacting. To get this product proping or prolated nonindustry the following database annual actions: regions addresses market data and also of numbers of this let description of the problem. If the problem sources to be based on a defect in anticementals or restarble and acculds a ration from and instructions which subsection to return the product. Return shipments are at outstorner's expense, and the return must be

accompanied by the original proof of purchase, is not responsible for lost or damaged Any product returned without the priorial proof of purchase will be returned at the customer's process. All returns must include the original exclusing and included all items like product, power adapters and user manual.

After examination of the problem, the product will be repaired or produced and sent back to the address indicated on the return from

Electrical Specification Required input Ricele voltage: <150m/st-g db 1.8A SV IIPC Constant IIPC V123 RPP Satisfies Sea ency 11909 - 16909

FCC Statement

could vaid the user's authority to operate this equipment. conditions; (1) This device may not cause hamful interference, and (2) this device must accept any

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable. and con soliate radio frequency energy and, if not installed and used in accordance with the

- Connect the equipment into an outlet on a circuit different from that to which the receiver is

forth for an ancomboiled environment.

During operation the user must keep a minimum separation distance of 10 cm with RF devices.