



General Note

The information contained in this document is proprietary information of Tri-Specs, Inc. ("Tri-Specs").

Tri-Specs makes every effort to ensure the quality of the information in this document. The content of this documentation is provided on an "as is" basis and may contain deficiencies or inadequacies.

Tri-Specs disclaims any warranty and all responsibilities for the application of the device(s) that is made in relation to the accuracy, reliability or contents of this document. Tri-Specs is not liable for any injury, loss or damage of any kind incurred for the use of or reliance upon information.

Tri-Specs reserves the right to make any modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to products at any time and without notice. Such changes will, however, be incorporated into new editions of this document.

Some of the services in this manual are not supported by all networks. Contact your network operator or service provider if you are in doubt whether you can use a particular service.

© 2008 Tri-Specs, Inc.



Minimum End User Terms

YOU SHOULD CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE USING THE ENCLOSED EYEWEAR ("PRODUCT"). BY OPENING THIS PACKAGE AND USING THE EYEWEAR YOU ACKNOWLEDGE THAT YOU READ AND ACCEPT THESE TERMS AND CONDITIONS REGARDING THE SOFTWARE AND HARDWARE PROVIDED IN THE EYEWEAR AND UNDERSTAND THAT THEY WILL BE LEGALLY BINDING. IF YOU DO NOT AGREE WITH THEM, YOU SHOULD PROMPTLY RETURN THE PACKAGE FOR A FULL REFUND. Subject to the restrictions set forth below, this Agreement grants you a nonexclusive, limited license to use one of the product and to use one copy of all software owned or licensed by TriSpecs, Step Labs, Inc. (or any successor entity, "Step Labs"), all collectively referred to as "Licensors") embedded in the eyewear you purchased ("Software"), in object code format, solely as you acquired it preinstalled in the eyewear. Except for the limited use rights granted above, Licensors retain all right, title and interest in and to the Software and Product, including all intellectual property rights. The Product is protected by applicable intellectual property laws, including United States (and other jurisdictions) patent, trade secret, and copyright law, and international treaties. The Software is protected by applicable intellectual property laws, including United States copyright laws and international treaties. You may not reverse engineer, decompile, disassemble or otherwise attempt to derive the source code of the Software, except to the extent the foregoing restriction is expressly prohibited by applicable law. You may not copy the Software or create derivative works based on the Software. You may not remove or destroy any copyright notices or other proprietary markings regarding the Software. You may not export the Software. You acknowledge that the Product and Software is not fault-tolerant and is not designed, manufactured or intended for use in environments requiring fail-safe performance, in which the failure of the Product and/or Software could lead directly to death, personal injury, or severe physical or environmental damage, and agree not to use the Product and Software in such environments. You acknowledge that the Software may include certain third party software that is licensed to you subject to the separate terms of the third party licensors and you will be bound by those terms. If any such third party licenses require source code releases, attributions, disclaimers or other notices to be made to a licensee, the required disclosures are made on the TriSpecs website and on the Step Labs website. THE SOFTWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. LICENSORS DO NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE PROGRAM WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE PRODUCT OR SOFTWARE WILL BE UNINTERRUPTED OR ERROR FREE. Some states or other jurisdictions do not allow the exclusion of implied warranties, so some or all of the above exclusions may not apply to you. You may also have other rights that vary from state to state or in your jurisdiction.



LICENSOR'S LIABILITY IN CONNECTION WITH THE SOFTWARE AND PRODUCT AND YOUR USE THEREOF IS LIMITED TO THE AMOUNT RECEIVED BY EACH SEPARATE LICENSOR FOR YOUR COPY OF THE SOFTWARE AND PRODUCT, AND LICENSORS WILL IN NO EVENT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES, WHICH SHALL INCLUDE WITHOUT LIMITATION DAMAGES FOR LOSS OF DATA, SERVICE, PROFITS OR BUSINESS OPPORTUNITIES, ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE, OR PRODUCTHARWARE EVEN IF A SEPARATE LICENSOR OR ALL LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some states or other jurisdictions do not allow the exclusion or limitation of liability for certain damages, so some or all of the above limitations and exclusions may not apply to you. This license will automatically and immediately terminate in the event of material breach of any of the foregoing terms and conditions. These license terms and conditions, their interpretation, the parties' rights and obligations hereunder, and TriSpecs' intellectual property rights are governed by New York law, and all disputes you may have with Step Labs shall be resolved in the applicable state or federal courts of New York and filed in Manhattan. These license terms and conditions, their interpretation, the parties' rights and obligations hereunder, and Step Labs' intellectual property rights are governed by California law, and all disputes you may have with Step Labs shall be resolved in the applicable state or federal courts of California. In the event that the application of any provision hereof to any particular facts or circumstances shall be held to be invalid or unenforceable by a court or arbitrator of competent jurisdiction, then: (i) such provision shall be reformed without further action by the parties to the extent strictly necessary to render such provision valid and enforceable when applied to such particular facts or circumstances; and (ii) the validity and enforceability of such provision as applied to any other particular facts or circumstances, and the validity and enforceability of all of the other provisions hereof, shall in no way be affected or impaired thereby.




Contents

INTRODUCTION	1
SYMBOLS	2
GETTING STARTED	
Charging the Battery	
Turning On and Off Eyewear	
Adjusting the Volume	
USING EYEWEAR	
Pairing Eyewear with Your Phone And/Or Music Device	6
Call Functions	
Profiles	g
Controlling Music	10
STATUS INDICATORS	11
Light Indicator	11
Audio Indicator	
SAFETY INFORMATION	13
FIRMWARE UPGRADE	15



INTRODUCTION


Eyewear boasts of trilateral functionality - a technological innovation that offers a wireless link to your phone, a stereo headset that allows you to revel in superior sound quality and freedom of wireless music, and a fashion accessory that is stylish and sophisticated enough for the executive or fashion socialite.





SYMBOLS

The following symbols are used extensively in this document:



Steady Red Light




Flashing Green Light




Flashing Red Light



Flashing Yellow Light



Press in the direction shown



Pull in the direction shown



GETTING STARTED

Charging the Battery


Eyewear provides over 70 hours of standby time, up to 7 hours of talk time or 5 hours of music playback time when fully charged.

To charge Eyewear:

- 1. Plug the micro USB connector cable to your computer USB port. To charge Eyewear via the wall charger, connect the micro USB connector cable to the bundled adaptor before plugging it into an electrical outlet.
- 2. Plug the other end of the charging cable into Eyewear.
- 3. The light indicator will indicate that Eyewear is in charging mode. When charging is complete, the indicator light will turn off.

Note:


If the battery is completely discharged, it may take a few minutes before the charging indicator becomes active.






Turning On and Off Eyewear

To turn Eyewear on, pull down the right earpiece. A voice prompt "Hello" will be heard and the indicator light should flash from red > amber > green > green.




To turn Eyewear off, press and hold the Fast Backward/Previous ⁴ button and then press the right Retractable button. A voice prompt "Goodbye" will be heard and the indicator light should flash from green > amber > red > red.





Adjusting the Volume

You may use the Volume Up + and Volume Down - buttons on the left stem to adjust the volume.



- To increase speaker volume, press the front volume + button repeatedly until the desired volume is achieved.
- To decrease speaker volume, press the back volume button repeatedly until the desired volume is achieved.

Note:

When adjusting the speaker volume while Eyewear is in phone mode, a single high-pitch tone will be heard when the maximum or minimum volume level is reached. This tone does not apply when adjusting music volume.



USING EYEWEAR

Pairing Eyewear with Your Phone And/Or Music Device

Before using your Eyewear to make a call or listen to your favorite music, it must first be paired with your phone or music device. Your Bluetooth-enabled phone or music device must support the following:

- Bluetooth Advanced Audio Distribution Profile (A2DP) (for wireless audio streaming)
- Bluetooth Audio/ Video Remote Control Profile (AVRCP) (for wireless control of music)

To pair Eyewear with your phone:

- 1. Ensure that the Bluetooth feature in your phone/music device is turned on. For more information on how to turn on the Bluetooth feature, please refer to the user guide that accompanies your phone/music device.
- 2. With Eyewear turned on, press and hold the Call button until the indicator light turns red.
- 3. Search for Bluetooth devices using your phone/music device. For more information on how to search for Bluetooth devices, please refer to the user guide that accompanies your phone/music device.
- 4. Select **EYEWEAR** from the list of discovered devices from your phone/music device. Follow the onscreen prompts to confirm the selection.
- 5. When prompted, enter the passkey "0000" (four zeros). When pairing is successful, the indicator light flashes green four times and you will hear the voice prompt "Pairing Successful". Eyewear is now ready for use.

Note:

- Eyewear can store pairing information for up to 8 different devices. Once pairing is established, Eyewear will
 automatically connect to the last connected device each time it turns on and is within range. To connect to
 another device in its memory list of paired devices, the connection from that device to Eyewear must be
 initiated first.
- Two different devices (such as a phone and an MP3 player) can be wirelessly connected to the Eyewear at the same time. However, two similar devices (such as two phones) cannot.



To initiate a connection to Eyewear:

- 1. Go to the connection list in your phone/music device. For more information on viewing the connection list, please refer to the user guide that accompanies your phone/ music device.
- 2. Select EYEWEAR from your phone/music device.

Alternatively,

- 1. To connect to your phone, press the Call **\C** button. Eyewear will connect to the phone it was last connected to.
- 2. To connect to your music player, press the Play/Pause ▶/■ button. Eyewear will connect to the music device it was last connected to.



Call Functions

Function		
Turn Eyewear on	Pull down the right-hand side speaker	
Answer a Call	Press the Call button	
	Press the Volume Up + button to increase the volume	
Adjust Volume	Press the Volume Down — button to decrease the volume	
Mute the microphone	Press and hold the Volume Down — button until the voice prompt "Muted" is heard. Repeat the procedure to release from mute, voice prompt "Un-mute" is heard	
End a Call	Press the Call button	
Turn Eyewear off	Press and hold the Fast Backward/Previous [◄] button and then press the right Retractable button	
Change ring tones	Press Volume up + and Next song ▶▶ to toggle and select between 5 different tones	

Note:

When communication between Eyewear and your phone is interrupted (ie. when Eyewear is out of range), Eyewear will attempt to re-establish the connection.

After 10 minutes of unsuccessful attempts, the Eyewear will turn off.



Profiles

Eyewear supports both Handsfree and Headset profiles. However, the availability of these profiles is subject to the profiles supported by your phone.

The tables below illustrate the functionalities supported for each profile:

Handsfree Profile

Function	
Reject a Call	Press and hold the Call button
Dial by Voice	Short press the Call button and speak the name or command
Redial last dialled number	Press and hold the Call button
Put a call on hold	Press and hold the Call button
Transfer call from Phone to Eyewear	Short press the Call button while call is connected
Transfer call from Eyewear to Phone	Press the Call button twice
Answer 2 nd incoming call	Press and hold the Call button
Continue current call, reject 2 nd incoming call	Press Call button and Volume up +
End current call, answer 2 nd incoming call	Press Call button and Volume down

Headset Profile

Function	
Dial by Voice	Short press the Call button and speak the name or command
Redial last dialled number	Press and hold the Call button
Transfer call from Phone to Eyewear	Short press the Call button while call is connected
Transfer call from Eyewear to Phone	Press the Call button twice



Controlling Music

With Eyewear, you can enjoy wireless stereo audio from a Bluetooth-enabled phone or other music devices.

Function	
Turn Eyewear on	Pull down the right-hand side speaker
Play music	Press the Play/Pause ►/■ button
Stop music	Press and hold the Play/Pause ►/■ button
Pause/Resume music	Press the Play/Pause ►/■ button
Skip to next song	Press the Fast Forward/Next Song ▶▶ button
Play previous song	Press the Fast Backward/Previous Song [◄] button
Turn Eyewear off	Press and hold the Fast Backward/Previous ⁴ button and then press the right Retractable button
Adjust music volume	Press the Volume Up + button to increase the volume
	Press the Volume Down — button to decrease the volume

To make or receive a call, press the Call button. The music control buttons will be deactivated during the call. Once the call ends, the music will automatically resume.

Note:

Some music players do not support the feature that pause the music in the event of an incoming call. For these music players, Eyewear will mute the music when there is an incoming call.



STATUS INDICATORS

Light Indicator

The light indicator on Eyewear provides the following information:

Event	Light Indicator	Description
Pairing		Pairing in progress
	****	Pairing is successful
Charging		Charging in progress
	LED off	Charging is complete
Idle	* *	Eyewear is not connected to any device
Turning on/off	***	Device is powering up
	***	Device is powering down
While wirelessly connected to a device	* * *	100% to 67% battery remaining
	* * *	66% to 34% battery remaining
	* * *	33% to 0% battery remaining



Audio Indicator

The voice prompts provide the following information:

Voice Prompt	Description
Hello	Power on
Goodbye	Power off
Pairing successful	Bluetooth pairing is successful
Battery Low	Indicates 10% of battery life remaining
Connected	At power on and bonded but not connected
Transfer to Eyewear	Transfer voice from phone to eyewear
Transfer to phone	Transfer voice from eyewear to phone
Cancel	Cancel voice dial
Ring tone playing	Incoming call
Digits said	Identify caller ID
Call accepted	Incoming call answered
Answer Call Waiting	Answer call waiting and hold first call
End Call	End on-going and outgoing calls
Call Rejected	Reject incoming call or reject call waiting and sustain active call
Redial	Redial last dialled number
Muted	Prompts "muted" every 10s (Microphone)
Un-Mute	Un-mute device (Microphone)
English in English	When voice prompt language selection is English
Russian in Russian	When voice prompt language selection is Russian

Note:

- The languages supported are English and Russian.
- Press Previous Song ◄ and Volume Down = to toggle and select the language.
- The default shall be English, and the selection sequence is English and Russian.



SAFETY INFORMATION

READ THIS CAREFULLY BEFORE USING YOUR DEVICE. IT CONTAINS IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.

The Eyewear complies with part 15 of the FCC Rules. Operation is subjected to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR sec 15.19(3).

The product is also in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC and all other relevant EU Directives.

For Bluetooth troubleshooting, please refer to www.bluetooth.com for more information.

USE AT YOUR OWN RISK

AVOID HEARING DAMAGE

Listening to Eyewear at high volume may result in permanent hearing loss. If you experience any discomfort or ringing in your ear, adjust the volume down or stop using the Eyewear. With continuous usage at high volume, your ear may get accustomed to the sound level, which may cause permanent damage to your hearing. Use the Eyewear at a safe volume.

AVOID DISTRACTION

It is dangerous, and in some states or country, illegal to use headsets while driving a motor vehicle, motorcycle or bicycle. Do avoid placing or receiving calls while operating automotive, equipment to reduce the risk of accidents or injury. Use caution while using your Eyewear when engaging in ANY activities that requires your full attention. It is advisable to remove the speakers from your ears or turning off the sound to prevent any distraction while engaging in such activities to avoid accident or injury.

AVOID MOISTURE

The Eyewear is not waterproof and using it in or near water or other liquids, or wet locations, may cause electric shock and serious injury. Do not wear the Eyewear while swimming, when in the rain or during prolonged periods of perspiration. If any food or liquid spills on the Eyewear, the USB cable or power adaptor, unplug the charging cable from the eyewear and the power source and let it dry.

USE OF THE EYEWEAR

It is not recommended to use tinted lens when driving at night or at dim/dark areas, nor direct viewing of the sun or strong artificial light sources. It is also not meant for industrial protection. This Eyewear is not designed to protect the wearer from any injury in the event of impact with hard objects or if the lens or lenses are not properly secured in the frame.

ELECTROMAGNETIC INTERFERENCE

ELECTRONICS SYSTEMS

The Eyewear should not be expose to strong magnetic fields such as those that surround TV picture tubes and stereo speakers, in your home or car, without first checking with the manufacturer of those items.

RF ENERGY WARNING

Turn off your device in any facility where posted notices instruct you to do so to avoid compatibility conflicts and/or electromagnetic interference. Hospitals or health care facilities may be using equipment that is sensitive to external radio frequency (RF) energy emitted by your device.



MEDICAL DEVICES

If you use any personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

PLANE

While on board a plane, turn off your device when instructed to do so. Any use of the device must be in accordance with applicable regulations per airline crew instructions.

PROPER CARE AND MAINTAINANCE

TEMPERATURE

- Do not store or use the Eyewear in temperature lower than -10℃ / -4♥ or higher than 50℃ / 122♥.
- Do not recharge the Eyewear in temperature lower than 0℃ / 32F or higher than 40℃ / 104F.
- Do not leave the Eyewear in a parked car as environment inside the car may exceed the above temperature range.
- Do not leave the Eyewear in direct sunlight.
- Storing the Eyewear fully charged in high temperature environment may permanently reduce the battery life.
- Battery life may temporarily shorten in low-temperature environment.

SHOCK AND IMPACT

Be careful not to drop the Eyewear and do not expose the Eyewear to excessive force or impact.

DO NOT DISMANTLE OR MODIFY

Do not attempt to dismantle, modify or repair the Eyewear as it may subject you to electric shock and serious injury. In doing so will also void the limited warranty and void the user's authority to operate the device. See 47 CFR Sec. 15.21.

BATTERY

Do not attempt to remove the internal rechargeable battery. Disposal of devices that contain internal rechargeable batteries must be done in accordance with local environmental regulations.

CHARGER

Do not force the USB cable into the Eyewear micro USB connector or the adaptor USB connector. If the connector would not go into the port, try flipping the connector 180 degrees. Do not attempt to charge the eyewear with any charger other than the one that comes bundled with the Eyewear.

CLEANING AND MAINTAINANCE

Your new Eyewear comes with a pouch for cleaning and storage. Hand wash and air-dry the pouch regularly. When cleaning your lenses, use only mild soap and water and dry by gently blotting with the pouch provided. Please note the following when cleaning your Eyewear:

- The Eyewear is not waterproof. Moisture may damage the electronic circuitry. Do not rinse or immerse any part of the Eyewear. Keep the Eyewear dry at all times.
- Before cleaning, make sure the Eyewear is unplugged from the wall charger or computer.
- Do not clean the lenses with soaps, detergents, ammonia, alkaline cleaners, abrasive cleaning compounds or solvents. These substances may damage the lens coatings or leak into the Eyewear and damage the electronic circuitry.
- Should a lens become scratched, it should be replaced immediately to ensure your vision is not affected.



FIRMWARE UPGRADE

The Eyewear is firmware upgradeable via the micro USB port. Check the company website, www.trispecs.com, for any latest released firmware updates and downloads.

FCC Notice To Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:□
Radiation Exposure Statement: □
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users
must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance $\ \square$
with FCC RF exposure compliance requirements, please follow operation instruction as documented in this \square
manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.