

Difference between GEM0357E and GEM0357F

- 1) The GEM0357E contain internal antenna ANT3 and external connector J3 and switch SW4 for antenna transition and R33,R34 Q13,DS3 for external antenna indicate.
- 2) GEM0357F Only have the internal ceramic antenna ANT3. so remove external connector J3 and switch SW4 for antenna transition and R33,R34 Q13,DS3 for external antenna indicate.

Miner Kuang

Miner

Hardware Manager

Jetlun (Shenzhen) Corporation

Phone: 86-755-86148628 Fax: 86-755-86148628 E-mail: miner@jetlun.com