## Figure Explaination

By using of the TTL off-camera cable to trigger the off-camera flash when the Speedlite TTL flash works. Speedlite flash TTL + Speedlite flash trigger remote control



Speedlite flash TTL + Studio light off-camera flash trigger remote control



Speedlite flash TTL + Speedlite flash trigger remote control

Speedlite flash TTL + off-camera flash trigger remote control
The transmitter supports the Speedlite flash and will not hamper TTL
communication of camera. Furthermore, it will send the sync signal and
trigger the off-camera flashbur meanwhile.



Speed lite flash TTL + Studio light off-camera flash trigger remote control



Speedlite flash TTL + Speedlite flash trigger remote control

10

**Off-camera flash remote control** Transmitter installed on camera hot shoe, and trigger the flash light.



Studio light off-camera flash trigger remote control



Transmitter Input/output trigger off-camera flash and output flash.



Transmitter Speedlite TTL, Input/Output synchronous Trigger, off-camera light synchronous Trigger



Camera on top TTL, PC off-camera sync trigger.

Flash grouping remote control

When the transmitter is incompatible with the camera, you should use it

Use under incompatible mode



\*If the shooting interval time or 2 shooting times is longer than 30s, you need to press button again, or it may miss flash.

Slightly press the transmitter button. Non-compatible mode using method is same as compatible mode.

**€** 

#

as below:

Receiver A, B, C will operate when transmitter set at A, B, C.

Control shooting/ Remote control  Slightly half-press release button, transmitter and receiver indicate light as Green, then the camera starting focus.

2. Fully press release button, transmitter and receiver as Red, then the camera



œ. Receiver A. Bwill operate when transmitter set at A.

Some Cameras won't shoot if the camera cannot focus even get shooting signal, so please adjust the camera to "MF"

\*The shutter cable should be purchased separately.

Master camera control the slave camera

15



Camera Shutter cable is purchased separately.

Receiver B will operate when transmitter set at B.

manual information is updated at May 1, 2011. If you want to use this product combined with others, which ed after this date; please consult with the PIXEL dealer for further information. meras won't shoot if the camera cannot focus even get shooting signal, so ple ara cannot focus if the transmitter is not specific for the camera. I can start to use incredible PIXEL product. If you have any question, you can o

The service inferences and of Conservament which may be a service of the conservation of the conservatio modifications not expressly approved by the party responsible for compliance could void the user's complies whe equiment of the FCC Rules. Operation is subject to the following two conditions: (1) this

**\***00

**7**¥∟ 261121 ∨10.01

12

Receiver A will operate when transmitter set at A.

14