

#### 1.6 User Manual





### In the Box



One **ZOMM™** Wireless Leash Device



One Clear Plastic Belt Clip



English

One Micro-USB Wall Charger



One Micro-USB Update Cable



One Stainless Steel Key Ring




One Quick Start Guide

p.1



### About the ZOMM wireless leash

English






## **Turning ON the ZOMM**

### Before you begin:

- 1. Fully charge the **ZOMM** for 4 hours
- 2. Activate the ZOMM at zomm.com (see PAGE 10)
- 3. Turn your mobile phone ON
- 4. Enable Bluetooth® technology on your phone

### Pairing your mobile phone:

Verify that the **ZOMM** is turned OFF (e.g. **Z** light is OFF) then press and hold the **Z** button for at least 15 seconds.



**NOTE:** Some phones may not require a **PIN** to pair securely. If a **PIN** is required, use **0000**.

The **ZOMM** is now paired and connected to your mobile phone and the **Z** light should flash once every 5 seconds.

p.3


English



## Using the ZOMM



When the **ZOMM** and your mobile phone become separated by more than approximately 30 feet\*, **ZOMM** will alert you in three ways:



If the Bluetooth® wireless connection with your phone is suddenly lost, a similar alarm progression will occur. To cancel the alarm, simply press and release the **Z** button.

<sup>\*</sup> distance varies based on environment

## Enalish

## Managing calls

When receiving an incoming call, press the **Z** button:

- Press once to accept the call
- Press twice to cancel the call



When used as a speakerphone, press the **Z** button:

• Press once to transfer the call to your mobile phone





English


## Using the PANIC alarm

### Triggering the PANIC Alarm:

- 1. Press and hold the Z button until the alarm sounds
- 2. Immediately release the **Z** button

  The alarm will continue to sound until cancelled.







PANIC alarm

### Cancelling the PANIC Alarm:

1. Quickly press and release the **Z** button


WARNING: THE PANIC ALARM CAN CAUSE TEMPORARY OR PERMANENT HEARING LOSS IF PLACED CLOSE TO THE EAR. USE ONLY IN THE EVENT OF AN ACTUAL EMERGENCY!

## English

## Placing an Emergency Call

- 1. Press and hold the Z button until the PANIC alarm sounds
- 2. Continue holding the Z button until the PANIC alarm stops







**PANIC** alarm

- 3. Release the Z button when the PANIC alarm stops
- 4. ZOMM will call local emergency services and play a prerecorded emergency message alerting emergency services to send assistance to your mobile phone's location if you do not speak soon.
- **5. ZOMM** will serve as a speakerphone once the recorded message completes.
- You can turn on or off the **ZOMM** speaker by pressing the **Z** button
- **7.** End the call from the mobile phone (NOT the **ZOMM**).

## WARNING: ONLY USE THIS FEATURE IN THE EVENT OF AN ACTUAL EMERGENCY SITUATION!



## Turning OFF the ZOMM

# English

### To power-OFF the ZOMM:

- 1. Press and hold the Z button for until you feel a vibration
- 2. Release the **Z** button immediately
- 3. The Z light should stop flashing







eel Vibration See Flash

release Z button

### Resetting the ZOMM:

Should your **ZOMM** suddenly stop functioning or responding to user input.



- 2. Press and release the RESET button
- 3. Turn ON the **ZOMM**
- 4. **ZOMM** should automatically reconnect to your phone




## English

## Charging the ZOMM

### To charge the ZOMM:

- 1. Remove the dust cover to expose the micro-USB port
- 2. Charge the ZOMM using the charging cable provided



When charging, the **Z** light behaves differently:

Charging State	Z Light
Charging	Short Flash
Charged	ON



**NOTE:** The charging state **Z** light behavior overrides the operating state of the **ZOMM.** 




## Activating/Upgrading the ZOMM



After registering at www.zomm.com you must activate the ZOMM. You may also download updates, customize the ZOMM and configure it for your specific needs.

### Preparing for activation or an update:

1. Download and start the update software at zomm.com



### Follow the on-screen instructions on your computer.

Once the update process completes, the **ZOMM** will need to be reset, and paired with your mobile phone again. To pair your phone, follow the pairing instructions at the front of this guide (see PAGE 3).



## Safety Information and Support

#### WARNINGS:

- Keep the ZOMM device out of reach of children and pets.
- The ZOMM device's alarms are extremely loud heed all acoustic warnings when operating the ZOMM device.
- Do not use **ZOMM** while driving or operating machinery.
- Do not expose the **ZOMM** device to liquid, moisture, fire, open flames, or extreme temperatures.
- Failure to properly care for the **ZOMM** device voids all warranties and may increase the risk of serious injury or death and damage to the **ZOMM** device and other devices.
- Failure to heed all electrical safety precautions can result in serious injury, death from electric shock, or fire, or may result in permanent damage to the **ZOMM** device.
- Failure to heed all acoustic safety precautions can result in serious injury to the ear or permanent loss of hearing.

This Quick Start Guide is designed to get you started. If you are having trouble, visit **www.zomm.com** to download the full user manual.

Support for certain features may be dependent upon your mobile phone. For additional support, and for a complete mobile phone compatibility list, please go to **www.zomm.com/support.** 

p.11

English



## One Year Limited Warranty

English

**ZOMM, LLC.** extends the following limited warranty for its **ZOMM™** wireless leash. **ZOMM**'s warranty obligations are limited to the specific terms set forth below:

One Year Limited Warranty: ZOMM warrants to the original retail purchaser ("you") that the ZOMM™ wireless leash will be free from defects in materials and workmanship for a period of one (1) year from the date of your original purchase (the "Warranty Period"), subject to specific exclusions, identified at www.zomm.com/warranty.

WWW.ZOMM.COM/WARRANTY, YOU TAKE THE PRODUCT AND ANY ACCESSORIES "AS IS." ZOMM MAKES NO OTHER WARRANTY OR REPRESENTATION CONCERNING THE PRODUCT, AND EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES AND CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF WHATEVER KIND OR NATURE, INCLUDING BUT NOT LIMITED TO ANY AND ALL IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

If **ZOMM** cannot lawfully disclaim or exclude implied warranties under applicable law, then to the maximum extent possible the duration of such implied warranties shall expire on expiration of the warranty period.



#### Note on environmental protection:

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.




### Inclus dans la boîte



Une lanière sans fil **ZOMM™** 



Un clip en plastique transparent pour ceinture



Français

Un chargeur de voyage micro-USB



Un mini câble USB pour les mises à jour




Un porte-clé

Quick Start Guide

Un guide rapide d'utilisation p.13



## A propos de la lanière sans-fil ZOMM



# Français


### Allumer le ZOMM

#### Avant de commencer:

- 1. Chargez complètement le **ZOMM** pendant 4 heures
- 2. Activez le ZOMM sur www.zomm.com (voir page 10)
- 3. Allumez votre téléphone mobile
- 4. Activez la fonction Bluetooth® sur votre téléphone mobile

### Appairez le ZOMM à votre téléphone mobile:

Vérifiez que le **ZOMM** est éteint (tous les guides lumineux sont éteints), appuyez et restez appuyé sur le bouton **Z** pendant au moins 15 secondes.



**Note:** Certains téléphones mobiles n'ont pas besoin d'un code d'identification pour s'appairer en toute sécurité. Si un code d'identification personnel est demandé, entrez **0000** 

Le **ZOMM** est maintenant appairé et connecté à votre téléphone mobile et la lumière du bouton central Z clignote toutes les 5 secondes.