
circuit diagram (Transmitter)



WF-50DR-01 (TX)