




Main Board -Front




Main Board -Rear







Speaker –Rear









Camera –Rear



Power -Front




Power -Rear

























D-SUB -Rear









SD Card –Rear








Mouse -Rear







USB –Rear

