SAR   TEST   SET   UP   PHOTO

**View 1**

View 2(Normal Position)

View 3(Insert one step in External Ant)

View 4(Insert two step in External Ant)

View 5(Side External Ant)

View 6(Bottom External Ant)

View 7(Tablet mode: Side External Ant)

View 8(Tablet mode: Bottom External Ant)