# Item No. <u>PA</u> -\*\*1 - \*\*

# **Pictures**



- (1). Wireless router;
- (2). Mobile equipment (apps)
- (3). WiFi Plugtop
- (4). RF Switch adaptor
- (5). RF Dimmer adaptor;
- (6). Cloud sever

2.1 Install apps





### PS31


| Fasylink | Fasylink


(1). Install icomen free apps to your ios equipment via APP store,

(2). Install icomen free apps to your android equipment via google play store

(3). After install apps, the icon show as pic shows.

# 2.2 Account sign up, log in, find password, change password and main interface





 Fill in your e-mail address and Password then select "Sign Up" icon.
 ATTN: password is at least 6 words. Comen@gmail.com | 
password


Log In

Forget Password?

Sign Up


Fill in your e-mail address and Password, then click "log In" icon, or select "forget password" when you forgot your password


TEL:+86 574 86627888 FAX:+86 574 86627878



2.3 WiFi Plugtop ON/OFF Control setting

E-mail: sales@comen.com.cn HTTP: www.comen.com.cn






(Fig A) (Fig B)






(2) Input your wifi network and password, then select "start" before push the on/off button of wifi device 5 seconeds more, meantime the LED will be fast flashing (fig B)

Noted: 恢复出厂设置,长按按键 10 秒,执行该动作 push the button of wifi device 10 seconds more to reset default setting and clear all record



(3) waiting..... configured successfully, LED will change to blue flash;







(5) dele warning...

# 2.4 WiFi Plugtop Timer mode setting








(3) define details at "add timer" window (maximum 8 groups timer);

## 2.5 WiFi Plugtop Countdown timer mode

TEL:+86 574 86627888 FAX:+86 574 86627878




setting is control wifi devices ON or OFF


situation at fixed countdown time.






2.6 WiFi Plugtop Absence mode setting (absence mode is changing on or off situation of the device each half hour automatically by pre-setting peroid)








TEL:+86 574 86627888 FAX:+86 574 86627878




## 2.7 WiFi Plugtop lock & edit function



2.3 RF ON/OFF or Dimmer by WiFi Plugtop Control

E-mail: sales@comen.com.cn HTTP: www.comen.com.cn



(Fig C)



(1) Instantaneous Click device icon in "WI-FI device" list, the control interface will show as PIC 6 selectors, select the "RF" into RF setting.





(2) select "+" to add RF device......




(3) Type RF "Name" and select "type", then select icon or take picture as icon

E-mail: sales@comen.com.cn HTTP: www.comen.com.cn









6) Long time push device icon, drag the device you want to dele into garbage......

#### 3 Debug

Q1: App can not control WIFI device?,

A1: Check the LED situation of wifi device, check your wifi router connection.

Q2: 为什么主设备的定时反应时间比移动设备晚一些?

A2: 产品系统选用的时间为 GMT 国际格林尼治标准时间;

Q3: How to delete all record of wifi device?

A3: Push the button of wifi device 10 seconds more to reset default setting and clear all record

### 4 Product information

Items	Photo	Technical data
PA-US1-01W	Econom III	Input: 110V to125VAC/60Hz  Maximum Resistive Load:1875watt  Maximum Motor Load:1/3hp  Maximum Tungeten Load:1000watt
		Wiff: 2.4GHz / 802.11b/g/n Remote: 433.92MHz / 30meters

TEL:+86 574 86627888 FAX:+86 574 86627878

PA-USA-01W

Input: 110V to125VAC/60Hz

Maximum Resistive Load:1875watt

Maximum Motor Load:1/3hp

Maximum Tungeten Load:1000watt

Wifi: 2.4GHz / 802.11b/g/n

Remote: 433.92MHz / 30meters

Environment: 0~30°C

System: iOS 7.0 new , Android 4.0 new

• Wi-Fi Features: Supports standard IEEE 802.11b/g/n networks.

Easy opeartion one key setup, turn on/off multiple equipments.

Control via multiple terminals- smart phone/ tablet anywhere, local WiFi network or outer internet via 3G 4G, as well as LAN

network without internet.

Free icomen Apps for Android and iOS systems

### 5. Caution:

This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

ADRESSE: No.599 Jinda Road, Zhenhai Economic Development Zone, NINGBO, CHINA

TEL:+86 574 86627888 FAX:+86 574 86627878

E-mail: sales@comen.com.cn HTTP: www.comen.com.cn

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

## MPE Reminding

To satisfy FCC / IC RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation.

To ensure compliance, operations at closer than this distance is not recommended.

Les antennes installées doivent être situées de facon à ce que la population ne puisse y être exposée à une distance de moin de 20 cm. Installer les antennes de facon à ce que le personnel ne puisse approcher à 20 cm ou moins de la position centrale de l'antenne.

La FCC des éltats-unis stipule que cet appareil doit être en tout temps éloigné d'au moins 20 cm des personnes pendant son functionnement.

## **Region Selection**

Limited by local law regulations, version for North America does not have region selection option...

E-mail: sales@comen.com.cn HTTP: www.comen.com.cn