

# Desk Series User Guide



### www.ingenico.com

28-32, boulevard de Grenelle, 75015 Paris - France / (T) +33 (0)1 58 01 80 00 / (F) +33 (0)1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre

## Contents

1_Introduction4
2_Unpacking5
3_Recommendations6
3_1 Safety / Sicherheit
3_2 Telephone emergency, hanging up8
3_3 Security of your terminal (tampering attempt detection)
<b>3_4</b> Desk series : Fixed Installation
3_5 Characteristics
3_5_1 Main Characteristics
3_5_2 Haupteigenschaften 11
4_Installation
4_1 Positioning the terminal13
<b>4_2</b> Aufstellung des Terminals
4_3 Connections
<b>4_4</b> Installing the Terminal - Cable fixing
4_4_1 Kit Magic Box installation (optional)
<b>4_5</b> Installing SAM (Secure access module)

	4_6 Installing MicroSD Card (optional)	21
	4_7 Installing SIM for GPRS (optional)	22
	<b>4_8</b> Installing SAM3 (optional)	23
	<b>4_9</b> Installing 2nd SIM for GPRS	
	(optional)	24
<b>5_</b> Insta	ılling a paper roll	25
<b>6_</b> Daily	yuse	27
	6_1 Keypad functions	27
	<b>6_2</b> Adjusting the contrast (B&W display only)	28
	6_3 Card insertion	28
	6_3_1 Swipinga card	
	6_3_2 Inserting a chip card	28
	6_3_3 Reading Contacless (Optional)	28
	6_3_4 Headphone output (Optional)	30
7_Main	tenance / Wartung	30
	7_1 Paper roll	30
7_2 Cleaning of the terminal		
7_3 Transport and storage		
	7_4 Troubleshooting	32
	<b>7_5</b> Troubleshooting	_
<b>8_</b> Mark	rings	_
	8_1 FCC/IC Compliance	35

## 1\_Introduction

Thank you for choosing an Ingenico payment terminal.

We recommend you to read carefully this user guide: It gives you the necessary information about safety precautions, unpacking, installation, and maintenance of your terminal.

### **WARRANTY / SECURITY**



To benefit from the guarantee-related product, and to respect the security, we ask you to use only the power supply delivered in box with the product, entrusting maintenance operations only to an authorized person. Failure to comply with these instructions will void the manufacturer's responsibility.

### **GARANTIE / SICHERHEIT**



Um bestmöglich von dem garantierten Produkt zu profitieren und die Sicherheitsbedingungen zu gewährleisten, bitten wir Sie ausschließlich das der Verpackung beiliegende Netzteil zu benutzen und ausschließlich befugte Personen mit der Wartung zu beauftragen.

Bei Nichtbeachtung dieser Anweisung erlischt die Haftbarkeit des Herstellers.



This symbol indicates an important Warning.



Dieses Symbol weist auf eine wichtige Warnung.



This symbol indicates a piece of advice.






## 2\_Unpacking

According to the model, the following items are included in the packaging box (including optional accessories):

- The terminal equipped with its paper roll
- The power supply with its cable connection (according to the national needs).
- The cable connection for the telephone or Ethernet network





### **CAUTION**

The power supply unit provided with your equipment is specially designed forit. Do not use any other power supply.



### WARNHINWEIS

Bitte verwenden Sie ausschließlich das mitgelieferte Netzteil, kein anderes Netzteil.

SEAMLESS PAYMENT

Contactless model



## 3 Recommendations

## 3\_1 Safety / Sicherheit

**3\_1\_1** Safety

### Power on/Power down - Emergency stop

To power on or power down the terminal connect or disconnect the power supply from the electric outlet.

### Lithium battery cell

The terminal is fitted with a lithium battery cell which is not accessible to the user. Only a qualified technician is authorized to open the unit and change this component.

### Electrical power supply network

The electrical outlet must meet the following criteria:

- Must be installed near the equipment and easily accessible;
- Must meet standards and regulations in the country of use;
- For type A plug, the protection of the installation must be set to 20 A.
- Except for Norway do not connect on an IT electrical network.

### Telephone network

The phone network must comply with standards and regulations in the country of use

### **Explosion areas**

Certain regulations restrict the use of radio equipment in chemical plants, fuel depots and any site where blasting is carried out. You are urged to comply with these regulations. The terminal shall be protected by a specially fitted and certified cover enabling use in proximity to a fuel pump.

### Electronic health appliances

According to the model your terminal could be a radio transmitter which may interfere with health appliances, such as hearing aids, pacemaker, hospital equipment, etc. Your doctor or the equipment manufacturer will be able to provide you with appropriate advice.



### Bottom side compartment trapdoor

 $Located \, under \, the \, terminal, \, it \, must \, be \, in \, place \, during \, normal \, operation \, of \, the \, terminal.$ 

Le réseau téléphonique doit être conforme aux normes et réglementations en vigueur dans le pays d'utilisation.

### 3\_1\_2 Sicherheit

### Power ein/Power aus - Nothalt

Zum Ein-oder Ausschalten der Klemme stecken oder ziehen Sie das Netzkabel aus der Steckdose.

#### Lithium-Batterie

Das Terminal ist mit einer Lithiumbatterie ausgestattet, die für den Benutzer unzugänglich ist. Nur ein qualifizierter Techniker sollte die Box zu öffnen, um die Komponente zu ersetzen.

#### Anschluss an das Stromnetz

Die Steckdose muss die folgenden Kriterien erfüllen:

- In der Nähe des Geräts befinden und leicht zugänglich
- Erfüllt die Normen und Vorschriften im Einsatzland
- Typ-A Stecker müssen mit 20A abgesichert sein.
- Mit Ausnahme von Norwegen nicht an ein IT-Stromnetz anschließen.

### Telefonnetz

Einen Telefonstecker gemäß den Normen und Vorschriften des Benutzerlandes bereitstellen.

### Explosionsgefährdung

Einige Vorschriften beschränken den Einsatz von Funkgeräten in Chemieanlagen, Kraftstofflagern und anderen Standorten mit Explosionsgefahr. Sie werden gebeten, diese Vorschriften einzuhalten. Das Terminal muss durch eine Abdeckung geschützt werden, die für den Einsatz in der Nähe einer Kraftstoffpumpe speziell entwickelt und zertifiziert ist.

### Elektronik Gesundheit

Je nach Modell, könnte Ihr Gerät ein Funksender sein, der medizinische Gerste wie Hörgeräte, Herzschrittmacher, Krankenhausausrüstung, usw. stören kann. Ihr Arzt oder der Hersteller ist in der Lage, Sie entsprechend zu beraten.

#### Die untere Gehäuseabdeckung

Sie befindet sich unter dem Terminal und muss bei normalem Terminalbetrieb angebracht sein.



## 3\_2 Telephone emergency, hanging up

You have an urgent call to make, when terminal hangs on the line. Perform as follow in order to get a dial tone...

Place the handset in the hang up position and:

Press the red key (=cancel)

Or disconnect the power supply from the mains

Or disconnect the terminal telephone connector from the

telephone line socket, and place the telephone connector

into the telephone line socket.

You will get a dial tone within 6 seconds.

## **3\_3** Security of your terminal (tampering attempt detection)

Your device fulfils current applicable PCIPTS security requirements. Upon receipt of your terminal you should check for signs of tampering of the equipment. It is strongly advised that these checks are performed regularly after receipt. You should check, for example: that the keypad is firmly in place; that there is no evidence of unusual wires that have been connected to any ports on your terminal or associated equipment, the chip card reader, or any other part of your terminal. Such checks would provide warning of any unauthorized modifications to your terminal, and other suspicious behavior of individuals that have access to your terminal. Your terminal detects any "tampered state". In this state the terminal will repeatedly flash the message" Alert Irruption!" and further use of the terminal will not be possible. If you observe the "Alert Irruption!" message, you should contact the terminal helpdesk immediately.

You are strongly advised to ensure that privileged access to your terminal is only granted to staff that have been independently verified as being trustworthy.

The terminal must never be put in or left at a location where it could be stolen or replaced by another device.

Your device is also available with PCI PTS compliant pin-shield:







### CAUTION



Positioning of the terminal on check stand must be in such a way to make cardholder PIN (Personal Identification Number) spying infeasible. Installing device on an adjustable stand must be in such a way that consumers can swivel the terminal sideways and/or tillt it forwards/backwards to a position that makes visual observation of the PIN-entry process difficult. Positioning of in-store security cameras such that the PIN-entry keypad is not visible. NEVER ask the customer to divulge their PIN Code. Customers should be advised to ensure that they are not being overlooked when entering their PIN Code.

### **3 4** Desk series: Fixed Installation

If the device is to be used in a situation where it is not possible for the cardholder to pick up and shield their PIN entry themselves, the device may be used without PIN shield, but it must be installed in the following manner:

- a) The device must be angled at 45 or more, so that oversight of the PIN entry from the rear of the device is not possible.
- b) The device must either be fitted in a swivel stand so that the customer can position the device in the best angle to prevent oversight – or the device must be fixed in the best possible position to prevent oversight if such a generic position exists in the specific environment to which the device is installed.
- c) The device environment must be accompanied with conspicuous notices and educational material which informs the customer to shield their PIN during PIN entry.
- d) The device must be deployed so that oversight from other customers, either in different payment lanes, or in other areas of the shopping environment, is prevented. This may be achieved through the placement of the lanes and device, so that the customer is automatically positioned between the device keypad and other customers. Alternatively, it may be achieved by the environment in which the device is installed, so that the checkout itself shields the PIN entry process.
- e) The terminal is exclusively made for indoor use If the above conditions are not fulfilled, the device with PIN shield must be used.

## **3\_5** Characteristics / Haupteigenschaften

### 3\_5\_1 Main Characteristics

### Terminal

Weight (w/o paper roll)	about 310 g to 340 g full option
Size	187 x 82 x 68 mm (l x w x h)

### Power supply unit (wall mounted)

Weight	approx 115 g
Size	approx 77 x 25 x 89 mm (L x w x h)
Class	Class II equipment
Input voltage	AC 230V 50-60Hz
Output voltage	DC 8V 2A

### 3A Desktop power supply unit

Weight	approx 191 g (without mains cable)
Size	approx 118 x 48 x 31 mm (L x w x h)
Class	Class II equipment
Input voltage	AC 100-240V 50-60Hz
Output voltage	DC 8V 3A

The power supply unit is especially designed by the manufacturer for its terminal with contactless function, do not use another one.

### 4A Desktop power supply unit

Weight	approx 230 g (without mains cable)
Size	approx 115 x 52 x 32 mm (L x w x h)
Class	Class II equipment
Input voltage	AC 115-230V 50-60Hz
Output voltage	DC 8V 4A

The power supply unit is especially designed by the manufacturer for its terminal with radio transceivers, do not use another one.

### Accordance terminal / type of power supply

Label on terminal	Type power supply
8V 2A	Plug power supply (wall mounted) (Output 2A) Recommended for terminals without any Radio transceivers (le:Ethernet/Modem).
8V 3A	Desktop power supply (Output 3A) RecommendedforterminalswithContactless
8V 4A	Desktop power supply (Output 4A) Recommended for terminals with Radio transceivers (2G, 3G, Wifi, Bluetooth)

### Cable length

Label on terminal	Type power supply (wall mounted)
Power block cable	approx 1,8 m
Telephone cable	approx 3 m

### 3\_5\_2 Haupteigenschaften

### Terminal

Gewicht	310 g bis 340 g bei allen Optionen
Größe	187 x 82 x 68 mm (L x B x H)

### Netzteil (an der Wand angebracht)

Gewicht	ungefähr 115 g (ohne Netzkabel)
Größe	ungefähr 75 x 25 x 89 mm (L x B x H)
Klasse	Ausrüstung Klasse II
Eingangsspannung	AC 230V 50-60Hz
Ausgangsspannung	DC 8V 2A

### 3A Büronetzadapter

Gewicht	ungefähr 191 g (ohne Netzkabel)
Größe	ungefähr 118 x 48 x 31 mm (L x B x H)
Klasse	Ausrüstung Klasse II
Eingangsspannung	AC 100-240V 50-60Hz
Ausgangsspannung	DC 8V 3A

Der Netzteil wurde speziell vom Hersteller für seine Terminals entworfen und muss mit diesen benutzt werden.

### 4A Büronetzadapter

Gewicht	ungefähr 230 g (ohne Netzkabel)
Größe	ungefähr 111 x 52 x 32 mm (L x B x H)
Klasse	Ausrüstung Klasse II
Eingangsspannung	AC 115-230V 50-60Hz
Ausgangsspannung	DC 8V 4A

Der Netzteil wurde speziell vom Hersteller für seine Terminals entworfen und muss mit diesen benutzt werden.

### Dazugehöriges Terminal / Netzteiltyp

Label terminal	Netzteiltyp	
8V 2A	Plug Netzadapter (Befestigung an der Wand) (OUTPUT 8V 2A) oder Büronetzadapter (OUTPUT 8V 4A)	
8V 3A	Büronetzadapter (OUTPUT 8V 3A)	
8V 4A	Büronetzadapter (OUTPUT 8V 4A)	

### Kabellänge

Netzteilkabel	ungefähr 1,8 m
Telefonkabel	ungefähr 3 m

## 4\_Installation

## 4\_1 Positioning the terminal

Install the terminal on a flat surface, with an easy access to an electrical outlet and telephone line. Place the terminal away from any heat source and protected from dust, vibrations and electromagnetic radiations (away from video terminals, PC, anti-shoplifting barriers, ...). The terminal is exclusively made for indoor use.

### Operating conditions

Ambient temperature	from 0°C to +40°C
Max relative humidity	85% at +40°C
Max altitude	2000 m

### Storage conditions

Storage temperature	-20°C, +55°C
Max relative humidity	85% at +55°C

## **4\_2** Aufstellung des Terminals

Stellen Sie das Terminal auf eine flache Oberfläche mit einfachem Zugang zu einer Netzsteckdose und Telefonleitung. Stellen Sie das Terminal nicht in der Nähe von Wärmequellen auf und schützen Sie es vor Staub, Vibrationen und elektromagnetischen Strahlungen (weit entfernt von Videoterminals, PCs, Diebstahlschranken, etc.)

### Betriebsbedingungen


Umgebungstemperatur	0°C bis +40°C
Maximale Luftfeuchtigkeit	85% bei +40°C
Maximale Höhe	2000 m

### Lagerbedingungen

r	Logostomanostus	-20°C, +55°C
	Lagertemperatur	-20 C, +55 C
	Maximale Luftfeuchtigkeit	85% bis +55°C

### 4\_3 Connections

All connections are on the rear of the terminal protected by a down side trapdoor.



\*according to the model

Phone · TNV-3

Power Supply: Limited Power Source.

Other connections : Safety Extra-low Voltage. According to IEC60950-1 and EN60950-1

## **4\_4** Installing the Terminal - Cable fixing

### Opening down-side trapdoor


Unclip the trapdoor by pushing on the clip **1** with your finger as shown on the figure here below.

Then lift the trapdoor rearward to remove it, as shown by arrows on the figure



### Closing down-side trapdoor

To close the trapdoor, start by landing trapdoor on to bottom casing as shown on the figure 1, manage 5/6mm distance 2 for clip insertion then push 3 and clipit.



### Connecting cables



### WARNING


Connecting is to be made when the terminal is powered off.



### WARNHINWEIS

Die Anschlüsse müssen bei ausgeschaltetem Terminal erfolgen.

### Perform the following operations:



 Open down side trapdoor then unclips the cables hook

- Plug telephone line 1, equipped if necessary with 3 ser country specific converte 2 to the telephone network 4.
   Connect the other end to the terminal telephone connection. If necessary, connect the telephone (Telephone is not required for the terminal to operate)
- Optionally plug others cables (Ethernet, RS232, USB...)
- Plug PSU 6 power lead 5 into the power socket 4.



• Clips the cables-hook part to secure cables path then close down side trapdoor



(\*): TNV-3 circuit: Telecommunication Network Voltage, as per safety standard EN 60950-1.

### **4\_4\_1** Kit Magic Boxinstallation (optional)



### WARNING

Connecting is to be made when the terminal is powered off.


### **WARNHINWEIS**

Die Anschlüsse müssen bei ausgeschaltetem Terminal erfolgen.




Perform operations as described in "connecting cables" chapter and connect cables as follow:

- Cables to plug:
- Power lead
- 2 Telephone line
- 3 Ethernet cable
- 4 Serial link RS232 cable




- If you need extra cables then cut undesired over-molded section at
- Install through-holes in the lead-through guides (as indicated on the figure).





#### ADVICE

It is strongly recommended to secure the 'Magic cable' to terminal's work area in order to reduce stress on terminal and connection.



- 1 Using the supplied cable tie to attach to a table leg (or similar)
- Using the supplied cable tie and self-adhesive support
- 3 Using a counter-sunk screw (not supplied) to an appropriate surface
  - The "Magic Cable" should be readily accessible for terminal maintenance and helpdesk diagnosis purposes.



#### NOTE:

The connection Magic Box can also be attached using a VELCRO  $^{\rm TM}$  or other system.

## **4\_5** Installing SAM (Secure access module)



### **CAUTION**

Before starting, switch off the terminal by disconnecting the power supply.




### WARNHINWEIS

Bevor Sie beginnen, das Gerät auszuschalten, indem Sie das Netz.

### Perform the following operations:

- Open down side trapdoor
- Insert the SAM Card into the slot marked (1) or (2). Take care to ensure that the SAM Card is inserted in the correct manner. The cut corner must be positioned as indicated on the figure.



Close down side trapdoor




We suggest you to use a piece of adhesive previously pasted on both sides of the SAM as shown here below for easy removal

SEAMLESS PAYMENT



Cut corner





### **CAUTION**

Do not use any tools when installing or removing the SAM  $\mbox{\sc Card}.$ 



### WARNHINWEIS

Zum Einsetzen oder Entfernen der SAM Karte keinerlei Werkzeug benutzen.

## 4\_6 Installing MicroSD Card (optional)



### CAUTION

Before starting, switch off the terminal by disconnecting the power supply.



### WARNHINWEIS


Bevor Sie beginnen, das Gerät auszuschalten, indem Sie das Netz.

### Perform the following operations:

- Open down side trapdoor
- Insert completely the MicroSD Card into the slot marked (MicroSD) as indicated on the figure. MicroSD Card must be back side positioned as indicated on marking.

 $To remove the {\tt MicroSDC} ard push on it with touch panel pencil.$ 

- Close down side trapdoor
- \_





## 4\_7 Installing SIM for GPRS (optional)



### CAUTION


Before starting, switch off the terminal by disconnecting the power supply.



### WARNHINWFIS

Bevor Sie beginnen, das Gerät auszuschalten, indem Sie das Netz.

Open down side trapdoor



- Insert the SIM GPRS into the slot marked (SIM1) as indicated on
   the figure. Take care to ensure that the SIM is inserted in the
  correct manner. The cut corner must be positioned as indicated
  on the figure.
- Close down side trapdoor.



## **4\_8** Installing SAM3 (optional)



### CAUTION


Before starting, switch off the terminal by disconnecting the power supply.



### WARNHINWEIS

Bevor Sie beginnen, das Gerät auszuschalten, indem Sie das Netz.

- Open down side trapdoor
- Insert the SAM Card into the slot marked (3) as indicated on the figure. Take care to ensure that the SIM is inserted in the correct manner. The cut corner must be positioned as indicated on the figure.



Close down side trapdoor.

## **4\_9** Installing 2nd SIM for GPRS (optional)



### **CAUTION**


Before starting, switch off the terminal by disconnecting the power supply.



### WARNHINWEIS

Bevor Sie beginnen, das Gerät auszuschalten, indem Sie das Netz.

- Open down side trapdoor
- nsert the SIM GPRS into the slot marked (SIM2) as indicated on the figure. Take care to ensure that the SIM GPRS is inserted in the correct manner. The insertion position SIM corner (engraved on the terminal) must be located as shown on figure.





Do not force at the insertion. Once positioned the SIM GPRS is not fully inserted, this is normal.



Nicht mit Gewalt einzusetzen. Nach der Positionierung der GPRS-SIM-Karte wird den ganzen Weg, was normal ist nicht eingelegt.

Close down side trapdoor





## 5\_Installing a paper roll

Your terminal is supplied with one paper roll. When the paper roll is nearing the end, ared line will appear on the paper; this indicates that the paper roll must be replaced.



### CAUTION

Use only paper approved by the manufacturer (diameter 40 mm). Use of unsuitable paper is likely to damage the printer of your terminal (see paper characteristics at "Maintenance" chapter).



### WARNHINWFIS

Nur vom Hersteller zugelassenes Papier benutzen (Durchmesser 40 mm). Durch den Einsatz von ungeeignetem Papier kann der Drucker des Terminals beschädigt werden (Siehe die Papierspezifikationen in Kapitel «Wartung»).

 Openthe paper compartment by lifting the catchlocated at the rear of the terminal and drag the cover to the rear.







### **CAUTION**

Do not force the cover against the cables.



### WARNHINWEIS

Die Abdeckungen nicht gegen die Kabel drücken.

- Insert the paper roll in the compartment following the directions shown on the figure below.
- Pull the paper up to the top of the terminal and hold it in this position.
- Maintain the paper and close the lid.
- Press the top of the lid in the centre as shown by arrow, until it clips into position.








### **ADVICE**

If you are inserting a new paper roll remove the first complete turn (this first turn of sensitive surface could be damaged during shipment).

## 6\_Daily use

## **6\_1** Keypad functions



- NAVIGATION keys
- 2 Ingenico key
- 3 CANCEL key (red)
- 4 CLEAR key (yellow) / Feed paper (long press)
- 5 VALIDATION key (green)
- Oot key

## **6\_2** Adjusting the contrast (B&W display only)

### No contrast management for the Color display

If you wish to increase or to decrease the contrast of the characters displayed on screen, press simultaneously on the (dot key) and key to decrease the contrast, or the (dot key) key to increase it. Keep pressing the keys as long as necessary.

### 6 3 Card insertion

### 6\_3\_1 Swiping a card

 Insert the card manually in the driver, magstripe facing the main body of the terminal.



Swipe the card with constant speed, not too slowly not too fast, to maximize the reading efficiency and avoid annoying repetitions.

6\_3\_2 Inserting a chip card

 Chip Cards should be inserted into your terminal as illustrated with the chip facing up and into the card reader.



### 6\_3\_3 Reading Contactless (Optional)

- Bring the card firmly up to the active zone above (at about 1cm) the contactless logo located on paper trapdoor button.
- Keep the card close to the contactless logo during the transaction

Your contactless terminal provides four contactless status lights located on display/lens.



- When a contactless transaction is started the first (left hand) status light will be lit steadily; this indicates that the contactless is in use but a card is not being read.
- When a contactless card is presented to the contactless active zone (\*) during a transaction the second, third and fourth status lights will be lit in turn. The card read is successful when all four status lights are lit and a confirmation tone can be heard.



Contactless Status lights

(\*): Contactless Symbol is a trademark owned by and used with the permission of EMVCo, LLC.



### CAUTION

Do not stick any conductive label on to contactless active zone located on paper trapdoor button. It can decrease seriously contactless efficiency.



### WARNHINWEIS

Keine leitende Etikett Kleben Sie nicht an kontaktlosen aktiven Zone auf Papier Falltür-Taste befindet. Es kann ernsthaft kontakt Effizienz verringern.

### **6\_3\_4** Headphone output (Optional)

- The headphone output jack is located under the card reader outlet.
   This option is not designed to play music, but to facilitate the use by blind people.
- Die Kopfhörerbuchse ist unter der Chipkartenleser entfernt. Diese Optionist nicht für die Musikzuspielen, aber nur, um die Verwendung von blinden Menschen zu erleichtern.

## 7\_Maintenance / Wartung



### **CAUTION**

Before making any operations of maintenance in the terminal, make sure that the power supply is disconnected.



### WARNHINWFIS

Bevor irgendwelche Operationen der Wartung im Terminal, stellen Sie sicher, dass die Stromversorgung getrennt wird.

## 7\_1 Paper roll

Characteristics	Precisions
Colour	White
Width	58 mm
Diameter	40 mm max.

- The thermal paper can be deteriorated by poor storage conditions, so we recommend you to avoid:
  - storage in hot wet places (near to air-conditioner, humidity higher than 85%)
  - exposure to sunlight or ultraviolet for long periods
  - contact with organic solvents (solvent type adhesive)

- direct contact with materials containing plasticizers (PVC transparent folders or envelopes)
- direct contact with «diazo» papers
- direct contact with water
- Rubbing or pressing the paper too strongly



### **CAUTION**

In order to benefit from the complete guarantee of the product, use manufacturer approved thermal paper only.



### WARNHINWEIS

Um in den vollen Genuss der Garantie zu kommen, darf nur vom Hersteller zugelassenes warmeempfindliches Papier benutzt werden.

## 7\_2 Cleaning of the terminal

First of all, unplug all the wires from the terminal. Good rules for proper cleaning of the terminal are:

- Use a soft cloth that is very slightly soaked with soapy water to clean the outside of the terminal. Manufacturer wipes kit is strongly recommended (ref: 296118801).
- Do not clean the electrical connections.



### **CAUTION**

Do not use in any case, **solvents**, **detergents or abrasive products:** 

Those materials might damage the plastic or electrical contacts



### WARNHINWFIS

In jedem Fall, verwenden Sie keine Lösungsmittel, Reinigungsmittel oder Scheuermittel: Diese Materialien können Kunststoff-oder elektrische Kontakte beschädigen.

- Avoid exposing the terminal to the direct rays of the sun.
- Do not put anything into the slot of the smart card reader

## 7\_3 Transport and storage

- Use the original packaging for any unit or stored.
- Disconnect all cables from the terminal during the transport.

## 7\_4 Troubleshooting

The terminal does not turn on or does not connect to the telephone line

- Check the power supply and telephone line cables
- · Check for electrical power network

The terminal fails to establish a telephone connection

- Check that the tone of the phone line is free
- Check the configuration of the phone line and number to call
- · Get support from technical

### Cards are not read

- Check that the magnetic card is passed correctly (with magstripe facing the main body of the terminal)
- Swipe again the card with with constant speed, not too slow not too fast.
- Verify that the magnetic strip is not damaged, grooved or cracked
- Make sure you have inserted correctly the smart card into the smart card reader and removed the card only after the transaction

### The ticket is not printed

- Check the presence and proper positioning of the paper roll. Possibly adjust the paper roll following instructions present in this manual
- Check the type of paper used (thermal paper must be used)
- Verify thermal paper sensitive side.



## **7\_5** Environment (WEEE, Batteries and Packaging)

This product is labeled in accordance with European Directives 2002/96/EC concerning Waste Electrical and Electronic Equipment (WEEE) and 2006/66/EC concerning Batteries and Accumulators. Those provisions are requiring producers and manufacturers to become liable for take-back, treatment and recycling upon end of life of equipment and batteries.



The associated symbol means that WEEE and waste batteries must not be thrown away but collected separately and recycled.

Ingenico ensures that efficient collection and recycling schemes are set-up for WEEE and batteries according to the local regulation of your country. Please contact your retailers for more detailed information about the compliance solution in place for disposing of your old product and used batteries.

Packaging waste must also be collected separately to assure a proper disposal and recycling.

Please note that proper recycling of the electrical and electronic equipment and waste batteries will ensure safety of human health and environment

## 8\_Markings



The CE marking indicates terminal complies with harmonized standards and requirements of European Directives on:

- Radio and Telecommunications Terminal Equipment (R&TTE)
- RoHS (Restriction of Hazardous Substances)

Dieses Produkt, mit der CE-Kennzeichnung , entspricht:

- dereuropäischenRichtlinieüberFunkanlagen und Telekommunikationsendeinrichtungen (R&TTE).
- der europäischen Richtlinie über die Beschränkung der Verwendung bestimmter gefährlicher Stoffe (RoHS).



This marking indicates that the product operates with an alternating current (AC) source (mains). It is completed by afferent values (voltage, frequency and max current).



This marking indicates that your terminal is suitable for direct current (DC) only. It is completed by afferent values (voltage, and max current).



This marking indicates power supply meets the energy efficiency level VI requirements.



Marking for Class II product. Such product does not require a safety connection to electrical earth.



For Indoor use only.



Output plug is Positive (+) and the barrel (ring) of the output plug is Negative (-)



This marking indicates power supply meets limited power source safety requirements.



This marking is apposed on to connector for telephone line connection.



This marking is apposed on to connector for power supply output cable connection.

## 8\_1 FCC/IC Compliance

Model Name	FCC ID	IC NUMBER
Model : DESK/5000 Eth/Mod	FCC ID : XKB-D5000M00	IC: 2586D-D5000M00
Model : DESK/5000 CL/Eth/Mod	FCC ID: XKB-D5000M01	IC: 2586D-D5000M01
Product : DESK/5000 CL/Eth/Mod/WiFi/BT	FCC ID : XKB-D5000 CLWIBT	IC: 2586D-D5000CLWIBT
Product : DESK/3200 CL/Eth/Mod	FCC ID : XKB-D3200CL	IC : 2586D-D3200CL
Product : DESK/3500 CL/Eth/Mod	FCC ID : XKB-D3500CL	IC: 2586D-D3500CL
Product : DESK/3500 CL/Eth/Mod/WiFi	FCC ID : XKB-D3500CLWI	IC : 2586D-D3500CLWI



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and canradiateradio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.



- This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
  - (1) l'appareil ne doit pas produire de brouillage, et
  - (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
  - Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (orlesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.
  - Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.
  - This device complies with FCC RF and Industry Canada RF radiation exposure limits set forth for general population. This device must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.
  - Le présent appareil est conforme aux niveaux limites d'exigences d'exposition RF aux personnes définies par Industrie Canada. L'appareil doit être installé afin d'offrir une distance de séparation d'au moins 20cm avec l'utilisateur, et ne doit pas être installé à proximité ou être utilisé en conjonction avec une autre antenne ou un autre émetteur.
  - No changes shall be made to the equipment without the permission of Ingenico as this may void the user's authority to operate the equipment.

- Tout changement apporté à ce terminal non expressément approuvé par Ingenico est susceptible d'annuler le droit de l'utilisateur à se servir de cet équipement.
- This product meets the applicable Innovation, Science and Economic Development Canada technical specifications. The Ringer Equivalence Number (REN) indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices not exceed five. REN for this device is 0.1
- Le présent appareil est conforme aux spécifications techniques applicables d'Innovation, Sciences et Développement économique Canada. L'indice d'équivalence de la sonnerie (IES) sert à indiquer le nombre maximal de dispositifs qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme des IES de tous les dispositifs n'excède pas cinc. L'IES pour cet appareil est de 0.1.

### Part 68 of FCC Rules

Model Name	US MODEM
Model : DESK/5000 Eth/Mod	US : IEOMM01BD5000M00
Model : DESK/5000 CL/Eth/Mod	US : IEOMM01BD5000M01
Product : DESK/5000 CL/Eth/Mod/ Wifi/BT	US : IEOMM01BD5000M01
Product : DESK/3200 CL/Eth/Mod	US : IEOMM01BD3200CL
Product : DESK/3500 CL/Eth/Mod	US : IEOMM01BD3500CL
Product : DESK/3500 CL/Eth/Mod/WiFi	US : IEOMM01BD3500CL

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US: AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.

This equipment uses the following USOC jacks: (RJ11C).

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as possible.

Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of this equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, please contact INGENICO, or your local INGENICO distributor or service center in the U.S.A. for repair and/or warrant information.

If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

U.S.A service center: Ingenico North America 3025 Windward Plaza, suite 600 Alpharetta, GA 30005 USA

Tel: +1(678) 456 1200 Fax: +1 (678) 456 1201

Email: info.us@ingenico.com



This Document is Copyright © 2016 by INGENICO Group. INGENICO retains full copyright ownership, rights and protection in all material contained in this document. The recipient can receive this document on the condition that he will keep the document confidential and will not use its contents in any form or by any means, except as agreed beforehand, without the prior written permission of INGENICO. Moreover, nobody is authorized to place this document at the disposal of any third party without the prior written permission of INGENICO. If such permission is granted, it will be subject to the condition that the recipient ensures that any other recipient of this document, or information contained therein, is held responsible to INGENICO for the confidentiality of that information.

Care has been taken to ensure that the content of this document is as accurate as possible. INGENICO however declines any responsibility for inaccurate, incomplete or outdated information. The contents of this document may change from time to time without prior notice, and do not create, specify, modify or replace any new or prior contractual obligations agreed upon in writing between INGENICO and the user.

INGENICO is not responsible for any use of this device, which would be non-consistent with the present document.

All trademarks used in this document remain the property of their rightful owners."

### Your contact



### www.ingenico.com

28-32, boulevard de Grenelle, 75015 Paris - France / (T) +33 (0)1 58 01 80 00 / (F) +33 (0)1 58 01 91 35 Ingenico - SA au capital de 47 656 332 / 317 218 758 RCS Nanterre

■ ● SEAMLESS PAYMENT