## 1 Annex C – EUT internal pictures


## 1.1 List of Pictures

| Picture 1: EUT (front)                            | 2 |
|---|---|
| Picture 2: EUT (rear)                             | 2 |
| Picture 3: EUT (PCB front)                        | 3 |
| Picture 3: EUT (PCB rear)                         | 3 |
| Picture 3: FUT (with temporary antenna connector) | 4 |




EMV TESTHAUS GmbH Gustav-Hertz-Straße 35 94315 Straubing Germany Revision: 1.01 SCM Microsystems GmbH

**UHF-Desktop Reader** 



Picture 1: EUT (front)




Picture 2: EUT (rear)




EMV **TESTHAUS** GmbH Gustav-Hertz-Straße 35 94315 Straubing Germany Revision: 1.01 SCM Microsystems GmbH

UHF-Desktop Reader

110143-AU01+E02 Annex C



Picture 3: EUT (PCB front)



Picture 4: EUT (PCB rear)



EMV **TESTHAUS** GmbH Gustav-Hertz-Straße 35 94315 Straubing Germany Revision: 1.01 SCM Microsystems GmbH

**UHF-Desktop Reader** 

110143-AU01+E02 Annex C



Picture 5: EUT (with temporary antenna connector)



EMV **TESTHAUS** GmbH Gustav-Hertz-Straße 35 94315 Straubing Germany Revision: 1.01 SCM Microsystems GmbH

UHF-Desktop Reader

110143-AU01+E02 Annex C