



#### ATTENTIONS PARENTS

It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

## BATTERY INSTALLATION

## HOW TO INSTALL BATTERY IN VEHICLE (See Diagram #1)

- Turn over the vehicle and push the ON/OFF to "OFF" position.
   Use a screwdriver to remove the battery cover.
   I.nsert 6x 1.5y" Aa" size batteries into the battery compartment.
   Replace the battery cover.

## HOW TO INSTALL BATTERY IN TRANSMITTER (See Diagram #2)

- 5. Remove battery cover.
  6. Install 1x 9V batteries by matching "+" and "-" poles as indicated in the battery compartment.
- 7. Replace the battery cover
- Note: Remove battery after you have finished using your vehicle.

## HOW TO PLAY

## START TO PLAY (See Diagram #3)

- 1. Attach the antenna to the top of the transmitter ensuring that is screwed until fully
- 2. Push the ON/OFF switch to the "ON" position of the vehicle. (See Diagram #1 (1) ) FORWARD & REVERSE RUNNING (See Diagram #4)
- 3. To make the car run forward and reverse, pull or push the trigger in the transmitter

- FRONT WHEELS STEERING ADJUSTMENT (See Diagram #5)

  4. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle.

  5. If the vehicle runs towards the left, turn "Steering Alignment Lever" towards "R".

  6. If the vehicle runs towards the right, turn "Steering Alignment Lever" towards "L".

### STEERING OPERATION (See Diagram #6)

- 3 TECHNING OPERATION (See Diagiani #6)
  7. Turn the steering wheel forward or backward while pulling the trigger backward at the same time, the car will turn left or right and run forward.

  8. Turn the steering wheel forward or backward while pushing the trigger forward at
- the same time, the car will turn left or right and reverse

**STOP OPERATION** (See Diagram #7) 9. Release the trigger, the vehicle will stop.

### BATTERY CAUTIONS

- For maximum performance, use alkaline batteries.
   Do not mix old and new batteries.
- Do not mix old and new batteries.
   Do not mix alkaline, standard(carbon-zinc) or rechargeable batteries.
   Do not recharge non-rechargeable batteries.
   Ensure the batteries are inserted with the correct polarity.

- 6. Remove batteries when toy is not in use.
- N. Reinove daturies winer toy is not in the ...
   Rechargeable batteries should only be charged under adult supervision.
   R. Remove rechargeable batteries from toy before charging.
   Yhe supply terminals are not to be short-circuited.
   The antenna should not be inserted into socked outlet.

# IMPORTANT NOTICE

operation, such as nover-current (C protection function to prevent damage to circuit by abnormal operation, such as press the car or hit the car on the wall in a long time, the car will stop to work automatically, it will resume to work after the player loosen the car 4 seconds late. Also it has a low power protection, the car will stop suddenly once the battery voltage is too low, in this situation, then please charge the car immediately.



This toy is not suitable for children under the of 3 years as it contains small parts that could be swallowed. We recommend using this product under the supervision of an adult. Remove all packaging before giving to the child.

#### ABOUT FREQUENCY AND PLAYING PLACE

- 1. If there's another radio control car of the same frequence near, it may interfere with
- Control of your cal.

  2. Other radio waves may also cause interference to your control. In such a case, please play in another area or at another time.

  3. This product is suitable for running on cement or water polished ground. If running on excessively smooth surface, the car may no be able to run along a straight line and may even chief to myth LT Thurner color. skid to make U-Turn or spin.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, Inits equipment has been tested and usure to comply with the minus or a class or unjust ourselves protection pursuant to Part 15 of the PCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, fro to installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is

- -- Consult the dealer or an experienced radio/TV technician for help.



