External pictures


POWER
ALARM LED
RS 485
1 2
MAINS
19 EU
DO NOT CONNECT
OR DISCONNECT
WHILE POWER
IS APPLIED
1 = EXT.ALARM IN
2 = OUT
80-85
80-85 DL