
1006 INSTRUCTION

REMOTE FINDER FCC ID: XU31006

INTRODUCTION:

Remote key finder is for everyone who loses household items from keys to TV remote controls, needs to save precious time, and wants to avoid the stress and anxiety of not knowing where something is .1006 is a remote control device with six colour coded receivers which can be attached to things like keys, wallets, mobile phones, hand bags, TV remotes and even your young child or pet at home, garden.

Transmitter:



Receiver:













Installation:

- 1. Open the cover of the receiver with little screwdriver .
- 2. Pull out the battery insulating tab
- 3. Close the cover of receiver
- 4. Attach the receiver on the articles as you like , with key-rings, double-sided tape or rubber band .

Operation:

When keep pressing one color-coded button on transmitter for 2 seconds, the corresponding receiver will respond with beep sound meanwhile the led on receiver will flash, then you can locate the articles which you are seeking.

Lower battery warning:

When the battery power for receiver become lower ,it will send continuous sounds to warn you to change the used battery .

Specification:

Battery: 27A 12V (for transmitter)

Frequency: 433.92MHz Remote distance: 60-80 feet Sound Volume: 90-95 dB Battery life: 3-6months

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.