# Internal Photographs

EUT – Open View

Antenna Location

EUT – PCB View

EUT –Module PCB View

EUT –Motor View