BOM List

1	IC	ATJ2115C	1	U2
2	Chip choke Coil	FB601/0603	1	FB1
				C1-3 C5-6
4	Chip Capacitor	104	9	C13-14 C16
				C20
5	Chip Capacitor	225	4	C9 C15 C19 C8
6	Chip Capacitor	475	1	C12
7	Chip Capacitor	474	1	C17
8	Chip Capacitor	105	4	C21-24
9	Chip Capacitor	101	1	C33
10	Chip Capacitor	15pF	2	C10 C20
11	Chip Capacitor	105	1	C4
12	Chip Capacitor	104	3	C10 C27 C32
14	Chip Capacitor	106	7	C11 C28-30 C36-38
15	Chip Capacitor	103	2	C18 C35
16	Chip Capacitor	102	1	C34
17	Chip Capacitor	10pF	1	C31
18	Chip Capacitor	102	3	C7 C55 C63
20	Chip Capacitor	6. 5PF / NC	1	C59
21	Chip Capacitor	106	1	C25
22	Chip Audion	24MHz	1	Y1
24	backlight	BackLi	1	LED
25	Chip Capacitor	106	1	C26
26	Chip choke Coil	390nH/NC	1	FB2
27	Chip choke Coil	120nH	1	FB3
28	Remote control	CH0038	1	U4
29	FLASH	K9MBG0	1	U6
	LCD	LCD		
32	Chip Audion	9018 /NC	1	Q1
	IC	QN8027	1	U3
34	Chip Resistors	22K	4	R1-2 R16 R24
35	Chip Resistors	20R	2	R25-26
36	Chip Resistors	10R	1	R41
37	Chip Resistors	47K /NC	1	R45
38	Chip Resistors	1K	1	R3
39	Chip Resistors	4R7	1	R4
40	Chip Resistors	10K	1	R5
41	Chip Resistors	100K	1	R6
42	Chip Resistors	6K2 1%	1	R7
43	Chip Resistors	47K 5%	1	R8
44	Chip Resistors	2K2 1%	1	R9
45	Chip Resistors	100R	1	R10
46	Chip Resistors	10K 1%	1	R11
47	Chip Resistors	10K 5%	1	R12

48	Chip Resistors	15K 1%	1	R13
49	Chip Resistors	100K	4	R14 R18 R20- 21
50	Chip Resistors	51K 5%	1	R17
51	Chip Resistors	30K 1%	1	R15
52	Chip Resistors	OR/NC	2	R22-23
53	Chip Resistors	1K	1	R19
54	Button	Next	1	K1K-K5K
59	PCB	PCB	3	T1-3
60	IC	XC6206	1	U1