Manual

- —. Electrical System Parameters
- 1. Work voltage: DC6V
- 2、 Quiescent current: ≤5UA
- 3. Working current: ≤21MA
- 4. Transmitting power: ≤100MW
- 5. Working frequency: 433MHZ
- 6, Modulation mode: ASK
- 7. Encode type: learning code

Learning Instructions:

- 1) Push & hold receiver button for 3 seconds (light starts flashing faster), release button.
- 2) Press "on/off" button on transmitter (light starts on/constant) & then release (light goes back to the faster speed).
- 3) Option:learn 2nd or 3rd transmitter at this time.
- 4) Push & release receiver button to turn off learn mode (light will stay on/constant).

Note: This equipment has been tested and found to comply with the limits Class B digital device. Pursuant to part 15 of the FCC rules. This limits are designed to a provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, The user is encouraged to try to correct the interference by one or more the following measures:

- -Reorient or relocate the receiving antenna
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - -Consult the dealer on an experienced radio/TV technician for help

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSE BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.