Application notes to the wireless remote-control switch

Common methods of address code learning and removal

Learning method: hold down the learning button for about 4 seconds, release it after the learning indicator light, then press the remote control button, if learn successfully, the indicator light will go off immediately, if not, the light will be on, also the learning state will exit automatically over 5 seconds. The above operations need to be repeated for each remote -control learning.

Removal method: Press the learning button for about 7 seconds, then all the learned address codes will be deleted after the indicator light flashes three times.

Requirements of the wireless transmitting

1. The transmitting and receiving frequencies have to be consistent absolutely. Such as: 315MHz
2. Codec IC model shall match.
3. Codec IC rosc shall meet the technical requirements.
4. Codec IC addresses shall be corresponding.
5. Codec IC data shall be corresponding.
6. The working volt of the transmitting and receiving shall meet the technical requirements.