

## WIRELESS WI-FI MODULE







Compatible With:

iPhone

**iPad** 

iPod Touch

\* Plastic Case Is Included

# USER MANUAL

ШШШ.SPEEDPASSION.NET




## **CONTENTS**

1. Connecting the Wi-Fi Module	Page1
2. Setup Wi-Fi Module	Page3
3. Change SSID and Password	Page4
4. Set WEP Encryption	Page5
5. Reventon Screen	Page6
6. Reventon Flow Chart	Page9



#### Wi-Fi Module Layout





With plastic box

**Stand alone** 

#### 1. Connecting the Wi-Fi Module:



1.1 Download the "Reventon" App Reventor in the Apple App store

Compatible with iPhone, iPad, iPod touch with iOS 4.1 or above.

Search "Reventon" in App Store or visit the below link: http://itunes.apple.com/hk/app/reventon/id489795844?mt=8



1.2 Connect the Wi-Fi Module to the Receiver








1.3 Connect the Wi-Fi Module to the ESC





1.4 Turn on the ESC. The RED LED will flash continuously until the Wi-Fi module is connected with iOS Device (iPhone /iPad/ iPod touch). The RED LED will turn on once connected.

	LED light status	
Wi-Fi module not connect to any	Flash per 2 second	
device		
Wi-Fi module is connected to iOS	Turn on	
Device (iPhone /iPad/ iPod touch)		
Wi-Fi module is connected to	Flash per 0.5 second	
"Reventon" app		

- 1.5 Wi-Fi module supports WEP 64 bit encrypted wireless network (Reference to point 4).
- 1.7 As long as iOS Device (iPhone /iPad/ iPod touch) is connected to the Wi-Fi module, the user can change the SSID and password via the Speed Passion Reventon Application. (Reference to point 3)
- 1.8 If password has been lost or forgotten, keep the Wi-Fi Module power on and disconnect between iOS Device (iPhone /iPad/ iPod touch) and Wi-Fi module, and hold the "Default Setup" button at the Wi-Fi Module for 3 seconds.




The Wi-Fi configuration will return to factory settings as shown below:

SSID	Speed passion
IP	192.168.11.123
User name	admin
Password	000000

Baud rate	19200
Data bits	8
Parity bits	0
Start stop bit	1

1.9 Connection between Wi-Fi module and iOS Device (iPhone /iPad/ iPod touch).




#### 2. Setup Wi-Fi module:

2.1 Select the "Settings" icon.	Settings
2.2 Select "Wi-Fi" to go to the Wi-Fi Networks screen.	Settings  Settings  Wi-Fi  Notifications  On >
	Location Services On >
2.3 Turn Wi-Fi on.	Settings Wi-Fi Networks  Wi-Fi 2.3 ON
2.4 Enter Wi-Fi settings by pressing the blue button next to "Speed passion".	Choose a Network



12:09 PM 2.5 Select static network, enter IP address Wi Fi Networks SpeedPassion "192.168.11.223", subnet mask "255.255.255.0". OFF Auto-Join Go back to Wi-Fi Network screen. IP Address DHCP BootP Static 2.5 192.168.11.223 IP Address Subnet Mask 255.255.255.0 Choose a Network... 2.6 Finally, select "Speed passion" Wi-Fi. The Wi-Fi module is now connected. √ Speed passion ÷ (≥)

#### 3.Change SSID and Password





3.9 Change the password and press the "Save" button in the "Others" section. Password must be 6 characters.	Others  Login Password :   © Password must be 6 characters  Save
3.10 Wi-Fi module will restart.	
3.11 The SSID and password has now been	
changed.	

### **4.Set WEP Encryption**

- LUIFI MODULE SCTTING
Authentication required: admin  Don't save Temporary Permanent  Cancel OK
Basic
Wireless Settings  SSID: SpeedPassion  Encryption: WEP64
Encryption Key: 0000000000
Save



#### **5.Apple Reventon screen**


Icon








Esc setting Page



Information bar





Needle style




2. Connection page



4. Status page








3. Option page













DISPLAY STYLE  NEEDLE BAR	<ul> <li>Choose the display setting page.</li> </ul>	ay style of set esc
TEAM SETTING	<ul> <li>Go to team settir</li> </ul>	ng page
UPDATE FIRMWARE	<ul> <li>Update firmware</li> </ul>	
- WIFI MODULE SETTING	Setup Wi-Fi mod	ule
- ESC Connection -	Turn On/Off ESC	Connection
CSC Commedium.	Before close the Revent	on app, must
ON DEE	disconnect to the ESC co	nnection. Otherwise,
	the ESC could not be cor	ntrol by the Receiver
		LED light status
	If ESC Connection ON	Flash per 0.5 second
	If ESC Connection OFF	Flash 2 times per 2
		second

4. Status Page	functions		
Pink color means the data not updated to ES  Black color means the or data updated to ESI		•	Show app software version
App Software Version	V1.0		
ESC Temperature	35.0	•	Show ESC Temperature
ESC Voltage	7.6	•	Show ESC Voltage
ESC Firmware Version	MOD0V10	•	Show the ESC firmware version
ESC Model	Reventon-S	•	Show the ESC model
Threshold V/Cell Lipo Cut Off	No Protection	•	Show all setting data and motor rotation
Dynamic Multi Timing System - DMTS 3.0	26.5		Words will change to red color if the
Digital Racing Response System -DRRS 3.0	Level 7		data changed
Percentage Braking -ABS	30%		
Percent Drag Brake	20%		
Throttle Percent Reverse	50%		
Neutral Range	6%		
Over Heat Protection	Enable =95c cut off		



#### **Exemption Clause:**

Speed Passion does not have control over the installation or use of this product therefore no liability for any damages incurred in its use will be accepted. Operation of this product is at the user's risk. The use of R/C models requires a degree of skill, If you are a beginner please consult the advice of an experienced user to prevent injury to goods or other persons.

#### Caution:

1. Do not operate the Wi-Fi module at voltages lower than 5.5V or higher the 6.0V battery, damage to the ESC can result.

#### ESC product warranty period:

#### **Product Warranty:**

30 days limited warranty, this product is guaranteed to be free from defects in materials or workmanship for a period of 30 days from the original date of purchase (Verified by sale receipt dated). User accepts all resulting liability. We reserve the right to modify warranty provisions without further notice. Warranty does not cover incorrect installation, components worn by use, or any damage caused by crash, flooding or natural disaster. The company has no control over the installation of this product; no liability may be assumed nor will be accepted for any damage resulting from the use of this product.

2 month return time for any repair or services, detail update RMA services process please check with your local dealer or www.speedpassion.net

Please visit www.SpeedPassion.net for updated ESC information and new software update releases!

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must be co-located for operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The devices must be installed and used in strict accordance with the manufacturer's instructions as described in the user manual that comes with the product.

If the FCC identification number is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module.

This exterior label can use wording such as the following:

"Contains Transmitter Module FCC ID: YIU000009

When the module is installed inside another device, the user manual of this device must contain below warning statements;

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 3. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must be collocated for operating in conjunction with any other antenna or transmitter.