Attention

- 1. If batteries used improperly; it may cause heat, burst, leakage and so on problems. Please read instruction below. Be sure to insert the batteries correctly according to the positive & negative polar. Do not mix old and new batteries together. Stop to use when it get wet. When go into water or sparkle happen, should not disassembly or welding. Do not make batteries short circuit, disassembly or flow into fire.
- 2. Do not play the radio control car in the road or crowded area, to prevent accident. Please play in the safe place.
- 3. Stop playing immediately when there is a thunder.
- 4. Should not take the control car to hit everywhere.
- 5. When playing indoor, play attention to prevent causing furniture or glass broken..
- 6. Do not bend the antenna, when the antenna is broken, the sharp edge may cause injury.
- 7. When the wheel is in motion, do not put the hand ,hair or clothes etc into the turning wheel to avoiding injury.
- 8. Do not control the car move toward people.
- 9. Do not play in the place with water or sand ,to prevent circuit break down.
- 10. Keep car away from fire or place with high temperature.
- 11. This car use complicated electronic circuit board and many components . Please do not dismantle or modify the car.

Radio Control (Battery installation and changing):

- 1. Use screw-driver to take out the screw on the back panel of radio controller ,pull down and take out the battery door.
- 2. Follow the instruction in the box to install the overlaid batteries ,cover and screwing back the battery door.
- 3. When button malfunction or light indicator become dimmer, follow the step 1, 2 to change new batteries.

Battery installation and changing

- 1. To make sure the ON/OFF power button in the car bottom is in the off position ,take out the screw; side the battery door sideward to open the door.
- 2. Matching the positive and negative polar indication to install 3 AA batteries.
- 3. Install the battery properly, cover the battery door and screw back the battery cover.
- 4. When car speed decreases, follow the procedure 1, 2, 3 to change new batteries.

Operation

- 1. Turn the power switch in the car bottom to the ON position.
- 2. Press the forward button in the remote control, radio control car start to move.
- 3. Adjust the rotary button in the back of the car, to adjust the radio control car to move in straight path.
- 4. Press the turbo button to speed up the car to full speed ahead.
- 5. If want to turn left or right ,press forward button to slow down the car and on the same time press the left / right button.
- 6. When finish, turn the power position to off position.

Warning: If radio control car out of order, normally because of insufficient power supply. Please change new batteries to try.

If because of the poor contact of deformed metal plate, follow instruction drawing to pull cut the metal plate.

Attention:

- 1. When battery power is insufficient, the car speed will be obviously slow down. Please change new batteries.
- 2. When radio control car changing between move forward and backward, it will vibrate and rotate 1800. This is not out of order and could be used as good condition.

Follow the following procedure could make battery more durable.

Turn off the power after playing. If forgetting to turn off the power, it will cause the power of batteries loosing continuously, and the batteries life become shorter.

When changing the new battery, must change all batteries, if mix old and new batteries together, power will be consumed in faster way.

About frequency and playing ground

- 1. If another car using the same radio frequency operated same time nearby, the control of car would be malnutrition.
- 2. Please change the place or other period of time to play. Sometime, if affected by other radio frequency transmition the control may be also out of order.
- 3. This car suitable to play on the roughage sand road, if playing on the every smooth polished ground, because the fiction between wheel and ground is too small, may cause problem of moving in non-straight path, car rotate 1800 or continually rotating on the ground.
- 4. Better play on the larger playground ,not suitable playing indoor on a single-family house .

(1) 15.21 statement: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.







REQUIRES 3 X "AA" SIZE BATTERIES [INCLUDED]