
# **User's Instruction FCC ID:YMURF1M**



Cues can be activated one by one through pressing buttons

RFRemotech Radio Frequency Remote Technology Remote Control Products, Remote Controllable Service



# Warning!!!

A. Only the person who has Fireworks licence is allowed to purchase the product, or the person of whom there isn't fireworks purchase limitation in his/her country or district is allowed to purchase the product. RFRemotech/E-MadeinCHN is not with responsibility for any illegal usage.

# **Descriptions**

Mode: OOK Wireless Radio
Type: Learning Code
Frequency: 433MHz
Every receiver can learn one button of transmitters, Each button can activate its corresponding receiver(s) instantly.

# **A. TCF Transmitter (FCC/CE certified)**

TCF100-12LN/TCF100-12LNX

Channel: 12CH
Power: 23A 12V battery
Transmitting Range:100m
With ON/OFF switch, prevent
the buttons from misoperation



# **B.Receiver**

Model No.

AlphaFire M: RF1M(FCC/CE certified)
Cue: 1 Cue
Power: 4x AAA battery


Firing current: >750mA, Max. 5000mA Test current: <10mA

Sizes: 55x50.5x40mm, Antenna is retractile and can be folded.

1-Antenna, retractile and can be folded. 2-Power/Low Power LED. Normally the LED is always on as 3-Position Switch 4 is at FIRE or TEST. When

batteries are low, the LED blinks.
3-Test LED. When exterior circuit is coherent, the LED is on; When exterior circuit is interrupted, the LED is off.
4-3-Position Switch, TEST-Test exterior circuit, OFF-Power is off, FIRE-Receiver is armed to fire fireworks or learn code.

2



8-Learning/Firing LED. See the following description Learn Code. 9-Fast Fastening Terminals. 10-Firing LED (see the above picture in Page 2)

# **Before Use**

Put 4x AAA battery into battery enclosure.

# Learn Code

Receiver must learn code of transmitter button, so that transmitter will



work with receiver together.

**How to Learn Code:** Shift 3-position switch to FIRE, keep depressing LEARN button more than 3 seconds to have Learning/Firing LED on, and then release LEARN button, press one of transmitter buttons within 3 seconds, LED will blink once and then be off, learning code succeeds.

**How to Clear Code:** Shift 3-position switch to FIRE, press LEARN button and don't release the button for more than 6 seconds until Learning/Firing LED blinks three times and then goes off, code is cleared.

Warning: Only when no fireworks is connected, you can Learn Code or Clear Code!

### How to Use

#### A. Test

To check if external circuit is coherent.

When exterior circuit is connected, Shift 3-position switch to TEST, if TEST LED is on, it indicates the exterior circuit is coherent; If TEST LED is off, it indicates the exterior circuit is interrupted.

#### D Cir

When exterior circuit is tested coherent, shift 3-position switch to FIRE, press transmitter button, Learning/Firing LED will blink once, firing current will be sent out.

sent out.

Please note, in FIRE status, receiver can be re-activated after 5 seconds.

# Reference

Any number of receivers can be programmed to any of the buttons/channels, so a button/channel can fire multiple e-matches simultaneously.



# **Some Recommendations**



AlphaFire M12Q 1x TCF100-12LN/TCF100-12LNX 12x RF1M Range 100m. FCC, CE certified.

RFRemotech
Manufacturer: RFRemotech
E-mail: service@RFRemotech.com
Http://www.RFRemotech.com
March, 2012

# WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.