

2.8. Test Photo

Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Back View of Conducted Emission Test Setup





Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter Description : Back View of Conducted Emission Test Setup





Test Mode : Mode 5: Transmit(GFSK)_Power Cable to PC Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 5: Transmit(GFSK)_Power Cable to PC Description : Back View of Conducted Emission Test Setup





Test Mode : Mode 6: Transmit(GFSK)_USB Cable to PC
Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 6: Transmit(GFSK)_USB Cable to PC
Description : Back View of Conducted Emission Test Setup







4.7. Test Photo


Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter

Description: Loop Antenna Test Setup



Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter








Test Mode : Mode 2: Transmit (π/4DQPSK)_Power Cable to adapter

Description: Loop Antenna Test Setup



Test Mode : Mode 2: Transmit (π/4DQPSK)_Power Cable to adapter

Description: Loop Antenna Test Setup






Test Mode : Mode 3: Transmit (8DPSK)_Power Cable to adapter

Description: Loop Antenna Test Setup



Test Mode : Mode 3: Transmit (8DPSK)_Power Cable to adapter








Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter

Description: Loop Antenna Test Setup



Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter

Description: Loop Antenna Test Setup






Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Front View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Back View of Radiated Emission Test Setup (Bilog)






Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter
Description : Front View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 4: Transmit(GFSK)_USB Cable to adapter
Description : Back View of Radiated Emission Test Setup (Bilog)






Test Mode : Mode 5: Transmit(GFSK)_Power Cable to PC
Description : Front View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 5: Transmit(GFSK)_Power Cable to PC
Description : Back View of Radiated Emission Test Setup (Bilog)





Test Mode : Mode 6: Transmit(GFSK)_USB Cable to PC

Description: Front View of Radiated Emission Test Setup (Bilog)



Test Mode : Mode 6: Transmit(GFSK)_USB Cable to PC

Description: Back View of Radiated Emission Test Setup (Bilog)





Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Front View of Radiated Emission Test Setup (Horn)



Test Mode : Mode 1: Transmit (GFSK)_Power Cable to adapter Description : Back View of Radiated Emission Test Setup (Horn)

