
OPERATING INSTRUCTIONS

Model: HCT-2KRC01

Remote unit for SMART SCONCE / EZ SCONCE fixture:



The remote unit can be utilized to power unit on/dim/off. Remote unit operates with one 12V Alkaline type 23A battery (included). This remote unit will operate the fixture once the unit is manually turned on (see below SMART SCONCE / EZ SCONCE fixture point 1)

- 1. Remove the battery cover from the unit and insert the 23A 12V Alkaline battery (Provided) into the battery compartment with the polarity shown in the battery compartment. Replace the battery cover.
- 2. Press the "ON/DIM" button to power on the fixture. Press once for the light intensity switching to Bright / Normal / Dim in sequences. Press the "OFF" button to power off the fixture.
- 3. Mount remote holder on wall by double coated tape (Provided) and put the remote unit inside the holder when the remote unit not in use.

SMART SCONCE / EZ SCONCE fixture:

- 1. Push in button located on the bottom of the unit to power the unit on. Push button a second time to power the unit off.
- 2. Others of the SMART SCONCE / EZ SCONCE fixture of operation details please refer to separate user manual.

Safety:

- 1. This product is intended for indoor use only. Please keep away from moisture and direct sunlight.
- 2. Do not disassemble the back plate
- 3. Consumed batteries need to be disposed of properly. Follow the disposal instructions on the battery package. Battery selling retailers provide special containers for environmentally friendly disposal.
- 4. Remove battery from unit for long term storage to prevent damage from battery leakage.
- 5. Consumed batteries need to be disposed of properly. Follow the disposal instructions on the battery package. Battery selling retailers provide special containers for environmentally friendly disposal.

FCC ID: YP8-HCT-2KRC01

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.