# Mobile Phone

**Brand Name: GOMOBILE** 

Model Name: GO202 FCC ID: YSEGO202

Phone Specifications Dimensions (W×D×H): 109\*61\*14.8MM

Cable: Mini USB Lithium battery BL-5C 600mah

Rated capacity: 5v 0.5A

Continuous standby duration: (Relates to network status) 230-250H Continuous conversation duration: (Relates to network status) 2-2.5H

Please refer to their labels for other data related to the battery and the

### 1 Phone overview



#### 2 Getting started

#### 2.1 Installing the SIM Cards

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

- 1) Hold the End key for a while to power off the mobile phone.
- Take the back cover away.
- 3) Lift the battery away.
- 4) Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing download, till the SIM card cannot be further pushed in.
- 5) With the metallic contacts of the battery facing the metallic contacts in the battery slot, press the battery down until it locks into place, then fix its back cover.

#### 2.2 Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network.

#### 3 Input method

This mobile phone provides multiple input methods, including English input and numeric input method.

#### 3.1 To Shift Entry Methods

Press shift key to switch between input methods.

## 3.2 Numeric and English Input

Numeric input: You can input numbers with the numeric input method. Press a number key to input the corresponding number. Enalish input: Each key is used to represent multiple characters. Quickly

English input: Each key is used to represent multiple characters. Quickly and continuously press a key till the character you want appears. Input the next character after the cursor moves.

#### 3.3 Inserting a Symbol

Press the **Sym** key to enter the **Symbol** interface and select a symbol you want.

#### 4 Using the Menus

#### 4.1 Call

Through this function, you can view a list of missed calls, dialed calls and received calls etc.

#### 4.2 STK

STK service is the tool kit of SIM card. This phone supports the service function. The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

#### 4.3 Multimedia

#### File manager

The phone provides a certain space for users to manage files and supports the memory card. You can use the File manager to conveniently manage various directories and files on the phone and the memory card.

#### TV

You are able to access this menu to watch mobile TV programs. Before you watch TV programs, you'd better select the right area. Then you can search available channels and select channel to play.

#### Camera

Use this function to capture pictures.

### **Pictures**

You can view the pictures or images through this function.

#### Video recorder

This function enables you to record dynamic pictures. You can press OK key to capture video clips; left soft key to access Options; right soft key to exit capture interface.

#### Video player

Use this function to play video files. In video player interface, you can press \* or # key to tune volume.

#### Sound recorder

You can record AMR & WAV format audio files through this function.

#### FM radio

Before using this function, please insert earphone into its corresponding slot. In FM radio screen, you can press \* or # key to tune volume, left or right direction key to tune channels manually.

#### F1 race

One game named F1 Race is embedded in the phone. For specific operation. please refer to 'Game help' option of the game. 4.4 Facebook

You can log on Facebook through this application.

#### 4.5 Contacts

The mobile phone can store up to 100 telephone numbers.

#### 4.6 Messages

You are able to create, read, send and delete messages through this function.

Note: If the short message memory is full, a blinking message icon appears

on the top of the screen. To normally receive short messages, you need to delete some of the existing short messages

#### 4.7 Extras

- Bluetooth: With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.
- ◆ Torch: You can use this function to turn on/off the torch which situates at the top of the phone.
- Calendar: Once you enter this menu, there is a monthly-view calendar for you to view the date: you can go to any day you want.
- Alarm: Through this function you can set Alarm status, time, alarm tone, etc.
- ◆ Calculator: The calculator can add, subtract, multiply and divide.

#### 4.8 Music

Use this function to play audio files. In music player interface, you can press \* or # key to tune volume.

#### 4.9 Settings

Profiles

The mobile phone provides multiple user profiles, including General, Silent, Meeting and Outdoor.

#### Dual SIM settings

Dual-SIM refers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen.

## Phone Settings

- Time and date: set the date format, the time format, and detail time of the location.
- ◆ Language: Select the display language for the mobile phone.
- Pref. input method: Select preferred input method as needed.
- Shortcuts: You can add, edit, delete and change order of the shortcuts
   Dedicated key: Customize the shortcut functions of the Up, Down, Left,
  - and Right direction keys.
- ◆ Flight mode: you can select to turn on normal mode or flight mode. Display settings

## Select images and set them as wallpaper, Screen auto lock, power on display, and power off display. You can show date and time on the screen or shut down this function and you can set duration of LCD light time.

#### **Call Settings**

- Call waiting: If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.
- Call divert: this network function enables you to forward incoming calls to another number you have previously specified.
- ◆ Call barring: The call barring function enables you to bar calls as needed.
- ◆ Line switching: Switch to Line 1 or Line 2. By default, Line 1 is used.

  Advanced settings
- ◆ Auto redial: Set it to On or Off to enable or disable auto redial.
- Call time reminder: To set single or circle tone in a call to make you know the time.
- ◆ Answer mode: Set answer mode as per your need.

#### **Network Settings**

Contact the network operator to obtain the network services.

#### Security Settings

This function provides you with related settings about safety use. The preset password is 0000.

Connectivity

You can manage the data account through this function.

#### Restore settings

Use this function to restore factory settings. The preset password is 0000. Sound effects

Select on/off sound effect as per your need.

## Important Regulatory Information

FCC RF EXPOSURE INFORMATION:

WARNING!! Read this information before using your phone

In August 1986 the Federal Communications Commission (FCC) of the United States with its action in Report and Outer FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these

international standards. Use only the supplied or an approved antenna. Unauthorized antennas modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor bum may result. Please contact your local dealer for replacement antenna.

#### **BODY-WORN OPERATION:**

This device was tested for typical body-worn operations with the back of the phone kept 0.5cm from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.5cm must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party belt-clips, holsters and similar accessories containing metallic components shall not be used. Body-worn accessories

that cannot maintain 0.5cm separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

For more information about RF exposure, please visit the FCC website at www.fcc.gov

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

<ANSIC95.1> (1992) / <NCRP Report 86> (1986) / <ICIMIRP> (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120

scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1). Nevertheless, we recommend that you use a hands-free kit with your phone (such as an earpiece or headset) to avoid potential exposure to RF energy. The design of your phone complies with the FCC quidelines (and those standards).

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

#### NORMAL POSITION:

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

#### TIPS ON EFFICIENT OPERATION:

For your phone to operate most efficiently:

- · Extend your antenna fully.
- Do not touch the antenna unnecessarily when the phone is in use.
   Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

#### RF Exposure Information:

FCC RF Exposure requirements: The highest SAR value reported under this standard during product certification for use next to the body with the minimum separation distance of 0.5cm is 1.103W/kg; next to the head is 0.605W/kg. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Do not use the device with the environment which below minimum -10  $^{\circ}$ C or over maximum 50  $^{\circ}$ C, the device may not work.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.