Users manual

GSM mobile phone GO963 GOMOBILE

One. An Important safety precautions	5
Two. your phone	7
1. Technical Reference	8
2. Mobile Appearance	9
2.1 mobile phones appearance	
3.Display	10
3.1display site map	10
Three. Start using	11
1. A phone is switched on / off	11
2. installation and removal battery/SIM card/mem	
3. Battery charging	13
Four. Quick Start Guide	15
1. Calling features	15
1.1. Call 16	
1.2. Call Settings	16
1.2. An incoming call	
1.3. call options	19
1.4. Call records	20
1.5. Adjust the volume	20
2. Enter text	
Five. Function menu	22
1. Phone	22
2. Contacts	22
3. Messaging	

3.1. Write new message	26
3.2 .Reply to message	26
3.3. New MMS	27
3.4 .Forwarding information	27
3.5. Delete information	27
3.6. Remove the session	28
3.7. Information setting	28
4. Camera	28
5. Calendar	30
6. Clock	30
7. Settings	30
7.1. Sim card management	30
7.2. Wi-fi30	
7.3 Audio Profiles	34
7.4 display	34
7.5 Location & Security	35
7.6 Apps36	
7.8 Backup&reset	37
7.8 Storage	37
7.9 Language & input	37
7.10 Date & Time	38
7.11 Timer Switch Machine	38
7.12 About phone	38
8. Music	39
9. Sound Record	39
10. Video player	40
11. Gallery	40

12. Browser	40
14. Email	41
15. Downloads	41
16. File mannager	42
17. Calculator	43
18. FM Radio	43
19. Note	44
Six. Common problems and solutions	45
Seven .Reference information	48
1. Access password	48
2 Cell phone password	48
1.2 .PIN code	49
1.3. PIN2 code	49
1.4. PUK code	50
1.5. PUK2 code	51
1.6. Barring password	51
2. Health and safety information	51
2.1. Battery	51
2.2 Traffic Safety	52
2.3 Use of the environment	54
2.4 Electronic equipment	55
2.5. Other important information	56
3. Explanation of terms	57

One. An Important safety precautions

Read the following simple instructions, and comply with, Beware of dangerous or illegal. Detailed safety information, see the P49 "Health and safety information"

Traffic Safety first

Do not use the car phone, should be used after stopping

To turn off when refueling

Do not use the phone at the gas station, or near flammable liquids and chemicals agents,

On the plane to shut down

Mobile phones can cause signal interference, cell phone use on planes is not only illegal and dangerous

v This set the phone into flight mode, aircraft communication systems, interference can not shut down

In the hospital to shut down

To comply with the various rules and regulations of the hospital, shut down in the vicinity of the medical set

Interference

Mobile communications may be subject to radio interference, radio interference will affect the phone's performance Comply with the special provisions

Comply with the special provisions, and in any place that prohibit the use of cell phones or anything that may cause interference or danger, the phone is turned off (for example, in the hospital)

Rational use of

Use the phone in the normal position (near the ears). Phon e is switched on for no reason, do not touch the antenna Accessories and batteries

Applies only to mobile phone accessories and batteries

Professional services

Installation or repair must be performed by service profess ionals

Two. your phone

The phone is a GSM / WCDMA digital mobile phones. Yo u can read this manual, a comprehensive understanding of the use of mobile phones, a taste of its perfect functi on and simple operation. Music player It is a smart phone. In addition to the basic call and SM S functions, also provide you with intelligent text input, c lock / alarm, front and rear camera, music player (Micro SD card), tape recorders, calculators, browsers, e-mail, F M scenarios, timer on / off, including a variety of practic al features to facilitate your work and leisure activities. In addition, the phone using a personalized man-machine i nterface design, improved functionality to meet your need s.

1. Technical Reference

2. Mobile Appearance

2.1 mobile phones appearance

3.Display

3.1display site map

The display consists of three parts:

Range	Description
The first line	Display a variety of stand-icon
	Display the network information, stand
	by small tools (such as the clock, poi
The middle of the content	nt the king 'and so on, according to
	different type change) desktop functio
	n icon
The last line	Currently assigned to the function of the t wo soft keys and dial touch buttons

Three. Start using

1. A phone is switched on / off

Press and hold button on phone boot or shut down.

2. installation and removal battery/SIM card/memory card

When you apply for a network, you will get a SIM card, which contains proprietary information, such as the PIN, you can get the service options.

- use a SIM card please note the following informatio n:
 - all miniature SIM cards should be placed on the c hildren of the reach;
 - the SIM card and its contacts can easily scratch o r be damaged due to bending, so
 - Carry, to be extra careful when you insert or remove the SIM card:
 - Before installing the SIM card, be sure to turn off the e phone and then remove the battery

- Installation and removal of the battery and SIM as follows
 - If necessary, press and hold button until shutdown;
 - Figure 1, the upward pull from the battery cover;
 - In Figure 2, lift the battery from the battery to t he left buckle, remove the battery;
 - Figure 3, the SIM card into the SIM card hold er, until not move.
 - ♦ The gold contacts of the SIM card face down;
 - The gap of the SIM card, such as the shell at the eidentification;
 - > To install the battery, as shown in Figure 2;
 - Metal contacts on the first battery at the battery-d eck shrapnel, and then press the battery can be d own;
 - Install the battery cover, as shown in

The first battery cover both ends of the buckle at the back shell groove away, and then the battery cover a nd push down the back cover as shown, to hear the buckle sound can be.

- Installation and removal of the T-flash card
 - > The phone uses a the clamshell Micro SD deck;
 - Install the T-flash card. Open the clamshell T-Flash card connector, the metal of the T-flash card face down, according to the identity of the shell at the memory card into the slot, will deck down to hear the "label" sound can;
 - Remove the T--flash. Push up the deck to hear t he sound release the "label", you can Remove the memory card

3. Battery charging

- Connect the charger to plug in the power;
- The charger connector into the bottom of the phon e's USB interface; At this time, the upper-left corne r of the phone screen battery indicator will flash;;
 - If the charger is turned off, the screen displays c harging video and indicates that the battery charg

е

- If the phone power is low, is still excessive use, charging starts, it may take some time before the charging indicator appears on the screen;
- When the battery indicator icon is displayed on the screen is full, and no longer flashing, indicates that the charge has been completed.
- During charging, batteries, cell phones and charger s may have a fever, is a normal phenomenon;
- After charging is completed, disconnect the AC p ower outletand mobilephone charger.

Note: The phone battery charge approximately 50% of capacity, which can be used apart. Completely filled in and then run out of the first completely; fully charge d and then have to completely run out of second, which requires three consecutive cycles, the battery is easy to achieve the best use of the state.

Four, Quick Start Guide

1. Calling features

- When the network provider's logo appears on the d isplay, you can call or answer the phone
- Three interfaces: dial, caller ID and call this function;
- Display the upper-left corner of the information bar shows the network signal strength.
- The call quality by the impact of obstacles, so the move in a small area can effectively improve the si gnal strength.

Note:

v In any country using the digital GSM network, if you ar e in the network coverage area (you can check the phon e display network signal strength indicator in the upper I eft corner learned), you should be able to use the call function.

v If your network provider does not provide roaming services in the region, will be displayed on the display "can

make emergency calls (Emergency)", to tell you that only such call.

 ν If you are in network coverage, even without a SIM car d to make emergency calls.

1.1. Call

- •Click the dial-up icon, enter the dial-up interface
- •Press the number keys, enter the phone number
- Press the dial key to call
- •Press the end key to end the call.

1.2. Call Settings

- SIM card 1/2 call settings
 - Fixed Dialing Numbers: Manage Fixed Dialin g Number
 - ♦ Voicemail service: My carrier
 - ♦ Voicemail settings: Settings for My carrier
 - → Fast call setting: Edit the Fast call list
 - Reply message Hangup: when you click Incoming UI, will auto send a message to who

call you.

- Automatically send information: Whether to a utomatically send a preset message
- Edit message content: Edit message content and point special person
- Call forwarding: Call Transfer can be set to differ ent circumstances
 - Always forward
 - Forward when busy
 - Forward when unanswered
 - Forward when unreachable
- Call barring settings: Call Transfer can be set t o different circumstances
 - All outgoing: select barring all outgoing, int ernational calls or international excluding d omestic;
 - Outgoing international: barring outgoing int ernational
 - Outgoing international roaming: barring out going international roaming

- All incoming : reject all incoming calls, roa ming reject;
- Incoming calls when roaming: reject incoming calls when roaming
- Deactivate all: the abolition of all the options set. Operation of these options, you need to disable the password;
- Change password: Change Password, enter y our password

♦ Additional settings

- Call ID: Use default operator settings to dis play my number in outgoing calls
- Call waiting: During a call, notify me of incoming calls
- > Vibration: vibration when answers/hangs up Line2 is to allocate telephone network operators related
- Note:
- Some settings require network support. Call barring lo cal network and SIM card opening of this function to make the setting effective

1.2. An incoming call

When the new call, the mobile phone standby Drag the gree n answer key or the side buttons to answer the call; left dra g the red end key to reject a call.

New calls when the phone non-standby, press the green answer $% \left(1\right) =\left(1\right) \left(1\right)$

button

Or the side buttons to answer the call; reject a call pr ess the red hang up button

Description:

Insert the headset, you can use the headset key to answer.

1.3. call options

During a call, press the screen display touch screen "opt ion" button to enter the call option.

In the call option, you can proceed as follows:

- Recording
- On hold
- Add call
- Speaker
- Dialpad

- Mute: turn off the microphone, so the other can no t hear their own voice
- End

1.4. Call records

- Call records in the function menu, View specific information
- Dial-up interface view call records option

1.5. Adjust the volume

Press the side buttons adjust the volume size.

2. Enter text

When editing text, using the Android keyboard or input method of the network to download to edit Chinese, Engl ish, Burmese, numbers, symbols. Such as adding contact s, editing information.

Switch the input method:

- · Enter the text editing interface;
- · Text editing area, pop-up menu of the edit text;
- · Input method in the Input menu, select the input method.

Description: press the number sign key, switch numbers an d symbols input input mode, click on the file to toggle the case of letters.

Five. Function menu

1. Phone

- ·Click the dial-up icon, enter the dial-up interface
- ·Press the number keys, enter the phone number
- •Press the dial key to call
- •Press the end key to end the call

2. Contacts

This feature allows you to browse the address book, store, edit, delete the name and phone number in the phone and SIM card. For the convenience of the records management, the phone set group function and related items in the same group.

People:

Contacts to dispaly

Import/Export

Accounts

```
Settings
```

Send contacts by sms/mms

Delete

Groups:

Accounts

Settings

> Favorite contacts:

Accounts

Settings

Addcontacts to Favorite

> Mrre options:

Show contacts

Import/Export contacts

Speed dial

Account

V

New:

- The function to add a new phone addresses book record. Can be added to the SIM card 1, SIM card or phone, as follows:
 - add records in the SIM card memory

Select to SIM card 1 or SIM card 2

ţ

Enter your contact information

l

Enter the name and phone number

Ī

Click <Done> and save the contact information.

save the number in the phone memory

¥

Select to phone

1

Enter your contact information

ļ

Name: enter the name

Mobile: enter mobile phone

E-mail: enter e-mail

Postal adddress: enter postal adddress

More: birthday, Notes, Website, memos...

Click <Done> and save the contact information.

3. Messaging

Screen in the standby interface point to enter the main menu, and then select the information, and will enter the information center interface.

- formation Center, including the sub-menu: establishm ent of information, Inbox, Outbox, templates, text mes saging is set;
- This phone can store 5000 SMS, and can store up t o the amount of information due to the SIM is differe nt;

3.1. Write new message

The main screen standby screen, click the information icon, enter the information interface;

Click the new information, enter New message interface;

Enter the recipient number or select a contact from the phonebook as a recipient

Enter the message content

Click to send, send text messages

Note: The information session in the form of the mobile phone in order to access the inbox and outbox.

3.2 .Reply to message

7\/\ban navy information is reasived the ten

which new information is received, the top event notificat
ion indication bar display and the corresponding prompt re
ply, you can view information
☐Short message list interface, click the corresponding ses
sion records
☐Enter the reply
□Click Send to complete the reply

3.3. New MMS

- The main screen standby screen, click the information ic on, enter the information interface;
- Click the new information, enter the new editing interface;
- Enter the recipient number or select a contact from the phonebook as a recipient
- Press the Menu key, choose to add the theme to input MMS theme;
- Editorial content, insert images, audio;
- > Click to send, send MMS.

3.4 .Forwarding information

- main standby screen interface, click the information icon, enter the information interface;
- Open a session record, tap and hold a message, select the forwarding information.

3.5. Delete information

- main standby screen interface, click the information butt on, enter the information interface : The
- point hold the record of a session, choose to delete the session:
- Press OK to delete the message.

3.6. Remove the session

- main standby screen interface, click the information butt on, enter the information interface;
- open a session record, tap and hold a message, choose to delete the session;
- Click the confirmation to remove the session

3.7. Information setting

The relevant parameters of the setup information, such a s: SMS limit, send a report.

4. Camera

■ The camera options are as follows:

Camera preview interface has the flash effect icon: open, close and automatically;

Switch before and after the camera icon

HDR effect icon

Camera settings:

- Photo: Open the photo to view the photos.
- > Picture size: set the photo size
- Picture quality:set the photo quality
- White Balance: White balance settings, you can choose sunlight,fluorescent, cloudy, incandescent light
- Scene Mode: Sports, night, automatic, normal, portrait a nd landscape mode
- Color Effect: Shut down, black and white, the color, old photos, cool color and nostalgia
- Burst:Three shoot, shoot six and nine shoot
- Countdown timer:Can choose a value between 1 to 60 seconds countdown film set in the process of the count down and whether there is a voice prompt button option s
- Freeze-frame display:Open and close
- Storage Path:Can choose to take pictures of the store path
- Advanced Settings:Including jitter, exposure, metering, b rightness and contrast Settings
- > Restore defaults: Set the camera to the individual data

back to the default value

5. Calendar

Open or close of the calendar view, but also the option to vie w a note, skip a specified date

6. Clock

Set time and date, and alarm clock

7. Settings

In the idle screen, tap the screen to enter the main menu, then select Settings, and will enter the setting interface.

You can you use this menu option used to set up your phone.

7.1. Sim card management

Dual SIM settings: voice telephony, information and data connections need to set the use of

7.2 Wi-fi

■ Airplane mode

Open / close airplane mode.

■ WLAN

- In the Home interface, click Settings>Wireless and network.
- 2. Click the WLAN to turn on the WLAN capability.

Tip: When the phone battery is very low, in order to pr otect the data in the system, will be prohibited to open Wi-Fi capability.

Click on the WLAN settings, Wi-Fi network will display the search to the network name and security settings.

Tip: When you select an open network, the phone will auto matically connect to the network; if you select an encrypte d network, you must first enter the password for the (securit y), and then click the link.

4. Click on a Wi-Fi network can be connected.

Tip: After a successful connection, the status bar will displ ay the Wi-Fi icon and displays the signal strength at this ti me, your phone has access to the network.

Bluetooth

1.Click on the home interface Settings> Wireless and net

working.

2. Click the Bluetooth to turn on the Bluetooth function.

Tip:

- Opens the phone to automatically search for visi ble Bluetooth devices nearby, and display the Bl uetooth icon in the status bar.
- When the cell phone battery is low, in order to protect the data in the system will be prohibited to open the Bluetooth function.
- Click on the Bluetooth settings Bluetooth devices scan t o select the equipment you want to connect
 - Enter a pass code to pair connection.

Tip: When paired and connected after the success of t he status bar will display the Bluetooth transmission ic on, you can with the Bluetooth devices transfer data.

■ VPN settings

Add, setup and manage virtual private network.

□

- Mobile networks
- 1.Click on the Settings> Wireless and networking
- 2. Click on the mobile networks into the mobile network se

ttings.

- Data enabled: Check this box to connect to login_After successful login, Phone status bar will appear to the 3
 G network connection icon, After that you can normal use of the Internet-related applications on the phone.
- Data roaming: Check this when the phone is in roa ming state can also be the normal use of the Inter net-related applications on the phone.
- UPLMN setting
- Access Point Names: Select Access Point.
- Network operators: To enter this menu, you can cond uct a web search and automatic selection of network operation.
- Tip: the opportunity according to the user to insert personal identification card (USIM/SIM/UIM) to automatically select the network. Tip: the opportunity according to the user to insert personal identification card (USIM / SIM / UIM) to automatically select the network.

7.3 Audio Profiles

- Profile: The scene modes include: General, Silent, Vibration, outdoor
- Volume: adjust the volume
- SIM 1 Phone ringtone: Set SIM1 ringtone
- SIM 2 Phone ringtone: Set SIM2 ringtone
- Notification ringtone : Select the notification you want to use ring tones
- Audible touch tones: Play tones when using dial pad
- Audible selection: Play sound when marking screen selection
- Screen lock sounds: lock and unlock the screen to play a sound
- Haptic feedback: Vibrate when pressing soft keys and o n certain UI interactions.

7.4 display

■ Brightness: the brightness slider to the left to reduce the brightness of the screen, drag to the right you can inc

rease the brightness.

- Auto-rotate screen: the screen will automatically rotatin g horizontal screen or vertical screen
- Lock screen style: Select the lock screen style
- Wallpaper Setting: Change wallpaper
- Animation: display all the windows animation
- Screen timeout: adjustment screen to be automatic lo cking the delay before

7.5 Location & Security

- You can set up your phone menu security options, to a void illegal use of your phone or SIM card.
- Set up screen lock: use pattern, PIN or password to loc k the screen
- Set up SIM1 card lock: open that need to enter a PIN lock password every time you start, otherwise you cannot us e the SIM card; settings, enter the correct PIN code. Thre e input error when asked to enter the PUK (Personal Unbl ocking Key). PUK code is used to unlock and change a bl ocked PIN code and PUK code is not provided or missin

- g please contact the network operator.
- Set up SIM2 card lock: The same as SIM1
- Visible passwords: the password visible when the input
- Select device administrators: Add or remove device administrators
- Use secure credentials: Allows applications to access the e security credentials and other documents
- Install from SD card: Install encrypted certificates from SD card
- Set Password: Set or change the certificate store password
- Clear storage: clear all the contents of the certificate store and reset their passwords

7.6 Apps

- unknown Source :Allow install of non-electronic market ap plication
- Manage applications: management and remove the instal led applications
- Running services: view and control services that are curr

ently running

- Storage use: Check the storage space used by the application
- Battery use: Check the power consumption
- Development: set of application development options

7.8 Backup&reset

Factory date reset: Clear all the data on the phone

7.8 Storage

Show the total mobile phone SD card capacity, free space

- Install the SD card: Insert the SD card to install
- Formatting the SD card: clear all data in the phone's SD card, such as music and photos

7.9 Language & input

Select a language and keyboard settings

7.10 Date & Time

Set the city, time and date display format

7.11 Timer Switch Machine

Can be set to the time of the Switcher, off by default

7.12 About phone

Display the phone's some basic information, such as: stat us messages, electricity usage, legal information, phone mo del, version, etc.

7.13 About phone

7.14 Restore the factory Settings

Mobile phones inside state of all the data back to the fa ctory, before storing all data will be lost

7.14 The battery

Check the mobile phone battery usage

8. Music

- Play: Play the OK key or press the play button.
- Pause: pause the music player, press the OK but ton or point press the pause button.
- Stop: press the pause button to stop playing pres s the * key or point.
- Switch songs: according to the list to select a so ng, press the option key to switch songs in the p layer interface.
- volume adjustments: up and down the side button s to adjust the volume or pen point increase and decrease the volume icon

9. Sound Record

"record " button to select the cursor where the corresponding functions through the screen in accordance with the display prompts, Can be realized recording, playback, delete and other functions, you can also set the audio file storage format.

10. Video player

Play the videos in the storage device.

11. Gallery

- 1. Click the gallery on the home interface
- 2. You want to see the picture
- Sliding around in the horizontal direction, touch screen, you can switch to the previous or next image.
- 4. If you want to play slide, please click the slide show
- To share or edit images, please click on the menu to s elect the appropriate option.

12. Browser

Open a Web page

- 1. On the home page, click your browser
- 2. Click on the URL input field.
- Enter a URL, click here
 Tip: Press the menu key, but also more features.

13. Search

You can use the Google Search on the home page to s

earch for information on the network.

- 1. Click on the Google Search Gadget
- Enter in the Google Search bar, enter the text you want to s earch.

14. Email

Before using the e-mail function, please set the e-mail account

- Send and receive: automatically send e mail in the Ou tbox and receive new mail.
- Edit E-mail: edit an e-mail
- Inbox: Displays the current account to receive mail.
- Refresh: Refresh the inbox.
- Compose: Edit an e-mail
- Folders: Switch Inbox, Drafts, Inbox, Sent.
- Accounts: Add or edit an account.

Account settings:

15. Downloads

You can download some new content to your phone

(Hint: Use only the services of your credit and their sup pliers can provide the necessary security protection, to r esist the intrusion of unwanted software, please contact your service provider offers different services and charge s)

16. File mannager

In the standby interface points into the main menu, then select the file management, access to the file management interface.

This feature needs to insert the T-FLASH card can be u sed. Tone file and image files to be managed through th is module.

- Graphics files can be sent to the wallpaper, screen s aver on / off animation can also be sent as an MM S;
- Tone file can be sent to the scene mode, set caller r ing tones, SMS ring tones, alarm tones can also be sent as an MMS
- File management options include:

- > Open: open the folder or file
- > Folder: new folder in the storage card or folder
- Formatting: Formatting the memory card
 - This operation will delete all the data in the stora ge
- Remove: Select the memory card, you can perform t o remove function to remove the memory card in a safe.
 - If you want to continue to use the memory card, re-plug can be

17. Calculator

Display prompts, press the number keys on the screen calculator function

18. FM Radio

In the menu before please to insert headphones.

- 1. Play Mode: Choosing the play button to play
- 2. End play: Click the stop button to stop playback
- 3. Channel: The current broadcast channels.

- 4. Last channel: Switch to last frequency.
- 5. Next channel: Switch to next frequency.

19. Note

Information such as user record some log in notepad

20.Application Manager

What users have downloaded into can view the application

21.Theme manager

Enter the theme manager, you can switch the theme of the mobile phone impassability style

22.Play Store&Google settings

Including Location, Ads and Android device Manager

23. Other applications and games

Including Clive ,C Games, Maps, Play store, Opera Mini

Six. Common problems and solutions

Before and after-sales service contact, follow these simple checks, you might be able to avoid unnecessary maint enance time and cost of waste.

Frequently	Causes and solutions		
Asked Que			
stions			
Cannot boot	 ■ n check whether to hold the power butto n for at least one second; ■ Check the battery connection is bad, ple ase remove and then reinstall and retry t he boot; ■ Check the battery power is exhausted, please charge□; 		
Unable to c onnect to th e network	3, 1		
Boot time, t he display i nformation	· · · · · · · · · · · · · · · · · · ·		

Poor call q uality	to use; enter the PIN, chose to enter the PIN every time you turn, you must enter the PIN code; PUK code: the connection three times to enter the wrong PIN code will lock the SIM card, you should enter the network operators to provide the PUK code; Check to see if volume adjustment inappropriate (see P19) use of mobile phones in poor reception areas, such as high-rise near or basement, radio waves can not be effectively communicated; use of mobile phones in the call-intensive period, the above working hours, line congestion caused not call;□
Standby tim e is shorter	■ Standby time network system settings, w hich may in a poor reception area. When no signal is received, the phone will co ntinue to launch in order to find the base station, consume a large amount of batt ery power, resulting in the standby time i s shorter. Move to a strong signal or tem porarily turn off the phone; ■ need to replace the battery, replace the new battery□

SIM card er	■ SIM card metal surface dirt, with a clea
ror	n cloth, wipe the SIM card metal contact
	points;
	■ the SIM card is not installed; n SIM car
	d is damaged, contact your network servi
	ce provider.□
Can not ma	■ Make sure whether to press the dial key
ke calls	after dialing;
	■ Make sure whether to be banned due to
	arrears call;
	■ Please Confirm SIM is valid;
	■ Please confirm whether the call barring
	feature is set;
	■ Make sure to set fixed dialing;□
The recipie	■ Make sure the phone is switched on, an
nt is unable	d connect to the network;
to contact	■ Make sure whether to be banned due to
you	arrears incoming;
	■ Make sure the SIM card is valid;
	■ Please confirm whether the call barring
	feature is set;
	■ Make sure to set fixed dialing;
Can not be	■ bad contact, check the plug is connecte
charged	d;
	■ charge in less than 40 ° C or above 55
	° C environment, to change the chargin
	g environment;

	battery or charger is damaged, in need o f replacement
Some featur	operating error;
es can not	
be set	network provider does not support this fe
	ature, or you did not request this

Seven .Reference information

1. Access password

The phone and SIM card to use several access passwords. These passwords help protect your phone from unauthorized use.

Security Settings option in the main menu settings can be used to modify the access password (PUK and PUK2 codes excluded), see page P52.

2 Cell phone password

The phone password can be used to prevent unauthoriz

ed use of mobile phones. Select Phone Password featur e, every time you turn the phone automatically locked, y ou need to use a password to open the phone lock.

- Before start using the phone, it is recommended that you modify the phone password.
- A new password for confidentiality and kept in a safe place, the best mobile phone separate.

1.2 .PIN code

PIN (Personal Identification Number) protects your SIM c and stolen. Usually provided with the SIM card PIN code.

Need to enter the PIN code every time you turn to sel ect the PIN test.

If the PIN code three times in a row input errors, sh ould enter the PUK code, then enter the new PIN co de to confirm re-enter the new PIN code again and c onfirm.

1.3. PIN2 code

Some SIM cards may provide PIN2, the PIN2 code, cert

ain features are in use, such as call billing. Only the SI M card supports these features in order to use these features.

If the PIN2 code three times in a row to enter the w rong PUK2 code, then enter the new PIN2 code conf irmation, re-enter again a new PIN2 code and confir m.

1.4. PUK code

The PUK (Personal Unblocking Key) used to change you r PIN locked. The PUK code is provided with the SIM c ard. If not provided, please contact your local service pr ovider to ask for the PUK code.

- If the connection is ten times enter the wrong PUK c ode, SIM card can not continue to use please contac t your ISP to replace the new SIM card.
- The PUK code can not be changed. If you have lost the PUK code, please contact the service provider.

1.5. PUK2 code

PUK2 code, supplied with some SIM cards. Used to change the locked PIN2 code.

- If the connection is ten times enter an incorrect PUK 2 code, SIM card will no longer continue to use the new SIM card,
- PUK2 code can not be changed. If lost, please conta ct the service provider.

1.6. Barring password

Call barring, 4 barring password. To apply this function, you can get the password from your service provider.

2. Health and safety information

2.1. Battery

- Do not short-circuit the battery device, which will dam age the battery to generate heat and may cause fire.
- Prohibit the battery in hot or thrown into the fire, this will cause an explosion. Used batteries should be re

turned to the supplier or on the designated collection points, and can not be placed in household garbag e.

2.2 Traffic Safety

The wireless phone has a powerful voice communication function, almost at any time, anywhere communications and liaison. But there are a number of important respons ibilities, have the advantage of the wireless phone, each user must fulfill these responsibilities.

While driving, driving is your primary duties, answer the phone while driving should be vigilant and keep in mind the following tips:

- Understanding of the wireless phone and its features, such as speed dial and redial. If these features can help you make a call, rather than to make your driving hours of heart.
- If hands-free device, you should use a hands free. If possible, use either supply hands-free accessories th

at you can improve the convenience and security of wireless phone use.

- Wireless phone is placed in an easy-to-find place. Do not need to divert attention from the road, you can use the phone. If you receive an incoming call at an inconvenient time, as much as possible to apply the voice mail answers the phone.
- Told to call each other in your car; hang up when ne cessary, in the case of traffic jams or bad weather. R ain, sleet, snow, ice and even heavy traffic is very d angerous.
- Airbags, brakes, speed control system and fuel injecti on system should be free from the influence of wirele ss transmission. If you are experiencing the problems mentioned above, please contact the car dealer.
- Please turn off your phone when refueling, the same situation also applies to prohibit the use of two-way wireless devices. Please do not flammable, explosive materials and the phone on with the internal spark m ay cause a fire.

- Turn off the phone before the plane took off. In order to prevent interference with aircraft communications systems, never allowed to use the phone in flight. Co nsent in accordance with the safety requirements for the crew to allow before take-off of the aircraft did n ot use the phone.
 - Set to flight mode of the phone will not communic ation system of the aircraft interference can not s hutdown.

2.3 Use of the environment

- Should comply with this no matter where the special provisions, and turn off the phone when in use or m ay be dangerous.
- When connected to the mobile phones and other devices, you should read the user manual to learn more about the safety instructions, you can not connect with incompatible products.
- As with other mobile radio transmitting equipment, it is

s recommended that users: For satisfactory use of the equipment and personnel security, and should only be used in the normal work location.

2.4 Electronic equipment

Most electronic equipment is shielded from RF signals. However, some electronic equipment may not be shielde d against the RF signals generated by the wireless hand set.

Pacemakers

- When the phone is switched on, must be kept aw ay from pacemakers six inches (15cm) above the distance;
- phone should not be carried in a breast pocket;
- use of the pacemaker on the other side of the ear to answer, may cause interference to reduce to a minimum.

■ Hearing aids

Some digital wireless phones may interfere with some he aring aids, if there is such interference, the deliberations

of substitutes can be used with your hearing aid manuf acturer.

Other medical devices

If other personal medical devices, please consult the device manufacturer, to confirm these equipment is shielded from external RF energy. Physician can help you obtain this information.

■ Posted notice of the place

Posted a notice to shut down places to turn off the phone.

2.5. Other important information

- Use only the first wife or by the manufacturer approved accessories. The use of any unauthorized accessories, there may affect the use of the phone's perform ance, damage your phone, and even lead to physical danger or violation of the relevant provisions of the national communication terminal products.
- Clean your phone use a slightly damp or antistatic cl

oth, do not use dry or easy to produce static cloth. Clean the surface of the phone, be careful not to us e cleaning agents, chemicals. Cleaning your phone, p lease turn off.

- Your phone will generate electromagnetic fields, pleas e do not place magnetic storage medium such as co mputer disks and the like. Use the phone near the te levision, telephone, radio and personal computers and other electrical equipment may cause interference, th us affecting the performance of the phone.
- Do not your mobile phone exposure in strong sunlight, avoid heat.
- Avoid all kinds of liquid into the phone's internal, so as not to cause damage.
- Do not drop, knock the phone Rough handling can b reak internal circuit boards.
- Please do not connect with other ancillary equipment.

3. Explanation of terms

To help you understand the main technical terms and ab

breviations in this manual, as well as better use of the phone functions, the following provides a definition of the meaning of some words.

ALS (Exchange line services)

ALS provides a function to join two lines with one SIM c ard. The use of the services needed to make and receiv e calls with any one line.

Dual card dual standby

Support dual card dual standby mobile phone user to ins ert two cards and two cards can be properly registered, can realize the two card standby at the same time and normal calls, SMS and other functions, including the realization of the two cards will also call the function.

Call barring

Limit cell phone to make and receive calls the function.

Call Transfer

Calls go to another mobile phone or fixed line telephone

functions.

Call on hold

Receive or make calls, keep another phone; when you n eed it to switch between the two calls.

Call Waiting

During the call, inform the user there was another call.

Line Identification Service (Caller ID)

Through the service, users can view the Caller ID or do not make their numbers displayed in each other's phon e network functionality..

GSM (Global System for Mobile Communications)

Cellular communications international standards to ensure compatibility between different network operators. The G SM system covers most European countries and in man y places around the world.

Multi-party call

Create up to 5 people at the same time participate in the call of the conference call function.

Roam

Use of mobile phones (such as tourism) in the local ser vice area.

SIM (Subscriber Identity Module)

The SIM card contains a chip, in which there is required to use the phone (network and memory information, an d user personal data). The SIM card can be inserted int o the small slot of the phone behind the battery protection.

SMS (Short Message Service)

To another network user to send or receive information f rom another user no need to call with the other network service functions. Information can be generated or recei ved, receive, edit or send.

Voice mail

Computer answering service. When you can not answer a call, the service functions of automatic answering their own voice (optional) sends greetings, and record inform ation.

Other

GPRS General Packet Radio Service

SMS-CB Broadcast messages

WAP Wireless Application Protocol

FDN Fixed number dialing

IMEI International Mobile Equipment Identity, 15 digit

s, a mobile phone corresponds to a unique IM

El number□

1.FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by

independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for

safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 0.726W/Kg and when worn on the body, as described in this user guide, is 0.775W/Kg(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is 1.142W/Kg. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/ oet/fccid after searching on

FCC ID: **YSEGO963** Additional information on Specific Absorption Rates (SAR) can be found on the Cellular

Telecommunications Industry Asso-ciation (CTIA) web-site at http://www.wow-com.com. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a sub-stantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.