User's Manual

Congratulations on your new purchase of a Savv Headrest Entertainment system

Please take a moment to fully review this owner's manual thoroughly prior to the initial operation, which will provide you with the best understanding to properly operate your new Savv Entertainment System

Description of Buttons

	DVD/USB/SD mode	MENU mode	V. SEL Mode
Power logo	Power On/ Off		
<	Volume up	Left cursor in MENU mode	Left cursor in V.SEL mode
>	Volume down	Right cursor in MENU mode	
MENU	MENU Display On/Off		
V.SEL	Video Mode Selection		
<<	Previous Chapter in DVD, USB, SD mode	Up cursor in MENU mode	Up cursor in V.SEL mode
>>	Next Chapter in DVD, USB, SD mode	Down cursor in MENU mode	Down cursor in V.SEL mode
>	Play / Pause / Enter		




Logos	Descriptions
AV	AV Video input port
SD logo	SD Card slot
Open logo	Open & Close button
USB logo	USB Memory slot
Headphone	Wired earphone Jack
logo	

Description of Remote Control



		<u> </u>	
1	POWER	Power On/Off	
2	V.SEL	Video Mode selection	
3	DIMMER	Dimmer On/Off	
4	USB/SD	USB/SD Hot Key	
5	MENU	Menu display On/Off	
6	ASPECT	4:3, 16:9 changes	
7	MUTE	Mute On/Off	
8		Cursor Up	
9		Cursor Left	
10		Cursor Right	
11		Cursor Down	
12		Function select	
13	Vol +	Volume up	
14	Vol -	Volume down	
15	>II	Play & Pause	
16	口	Stop	
17	SET-UP	DVD Menu Set-up	
18	l<<	Previous Chapter	
19	>>	Next Chapter	
20	<<	Fast Forward	
21	>>	Rewind	
22	DISPLAY	Display Mode	
		(Normal, Zoom, Wide)	
23	DVD-ROOT	Back to DVD-Root	
24	SUB-TITLE	Sub-Title selection	
25	AUDIO	Audio Mode	



How to Change Video Sources

This unit has 5 different Modes. DVD, SD Card, USB, AV, AV2.

1. DVD


- 1) Press Open button on the unit to load DVD or CD Disc
- 2) Completely close the LCD flip until you hear the sound "Click"
- 3) DVD or CD disc will be playing automatically.

2. USB

- 1) Put USB Memory on the slot located on left bottom side
- 2) Insert USB Memory firmly and press "SD/USB" button on the remote or press "V.SEL" button on the unit.
- 3) Move cursor to the right

3. SD Card

- 1) Put SD card (We recommend SD MMC) on the slot located on left bottom side
- 2) Insert SD card firmly and press "SD/USB" button on the remote or press "V.SEL" button on the unit.
- 3) Move cursor to the right




4. AV

- 1) AV input is located on the left bottom side of unit (right next to SD card slot)
- 2) You can simply connect portable or handheld device to this input on the front.

5. AV 2

- 1) AV 2 input is located at the end of DIN cable (Left side DIN Cable)
- 2) This input designed for slave external device such as TV tuner, DVB-T or



General Specifications

No.	Functions	7" DVD headrest	9" DVD headrest
1	Power	DC 12V (11V ~ 16V)	DC 12V (11V ~ 16V)
2	LCD Screen	7"	9"
3	Resolution	480 X 234	640 X 234
4	Aspect Ratio	16: 9	16: 9
5	AV Inputs	2 AV inputs (One on the front panel)	2 AV inputs (One on the front panel)
6	AV Outputs	1 AV output	1 AV output
7	Video Input Level	1Vp-p, 75 ohm(Composite)	1Vp-p, 75 ohm(Composite)
8	IR Frequency(A Ch.)	2.3MHz / 2.8MHz	2.3MHz / 2.8MHz
9	IR Frequency(B Ch.)	3.2MHz / 3.8MHz	3.2MHz / 3.8MHz
10	ID T	1m +- 30 degree	1m +- 30 degree
11	IR Transmitter range	3m +- 15 degree	3m +- 15 degree
12	DVD Player	Fully integrated with Top loading DVD player	Fully integrated with Top loading DVD player
13	Media input	Via USB and SD Slot (Video, Audio and Picture viewer)	Via USB and SD Slot (Video, Audio and Picture viewer)
14	Post Diameter	10mm Post with 12/12.5/12.7/13.8/14/16mm Post adoptor	10mm Post with 12/12.5/12.7/13.8/14/16mm Post adoptor
15	Posts distance	Adjustable 110mm ~ 210mm	Adjustable 110mm ~ 210mm
16	FM Transmitter	Built-in	Built-in
17	FM Frequency Range	88.1/88.3/88.5/88.7/88.9/89.1/89.3/89.5	
18	Remote Control	Full function remote control included	Full function remote control included
19	Wireless heaphone Suport	Yes	Yes
20	Color Choices	Black, Beige, Light gray, Dark gray	Black, Beige, Light gray, Dark gray
21	Multi Language Support	Yes (English, Deutsch, Spanish, French, Russian and Polski)	Yes (English, Deutsch, Spanish, French, Russian and Polski)

FCC warning statement:

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.