# 名前から引く索引

### 数字/アルファベット

ACアダプタ	. 18
au ICカード17	.83
au Media Tuner	. 97
au one トップ	. 62
auお客さまサポート	. 63
auのネットワークサービス	. 76
Bluetooth®	111
Cメール	. 58
EZ FeliCa	. 74
EZweb	. 62
EZアプリ	. 73
EZチャンネルプラス/EZチャンネ	ル
	. 67
EZナビ	
	. 7C
EZナビ	. 70 . 68
EZナビ EZニュースEX	. 70 . 68 . 80
EZナビ EZニュースEX EZパスワード	. 70 . 68 . 80 . 50
EZナビ EZニュースEX EZパスワード Eメール	. 70 . 68 . 80 . 50
EZナビ EZニュースEX EZパスワード Eメール Eメール・EZwebの初期設定	. 70 . 68 . 80 . 50 . 21
EZナビ	. 70 . 68 . 80 . 50 . 21 . 74 . 92
EZナビ EZニュースEX EZパスワード Eメール Eメール・EZwebの初期設定 FeliCaマーク	. 70 . 68 . 80 . 50 . 21 . 74 . 92
EZナビ	. 70 . 68 . 80 . 50 . 21 . 74 . 92
EZナビ	. 70 . 68 . 80 . 50 . 21 . 74 . 92 . 94

PINTコード
あ
アイコン
יל
海外でのご利用81、82

ガイド機能	106
外部接続端子	17
顔文字入力	35
各部の名称と機能	16
カチャブル	5
カメラ	86
カレンダー	109
簡易留守メモ	
漢字入力	34
キー操作	31
記号入力	35
機能設定	112
緊急地震速報	61
クイックアクセスメニュー	29
グローバルパスポートCDMA.	81
グローバルパスポートGSM	82
ケータイアップデート	117
ケータイアレンジ	110
ケータイ探せて安心サービス	15
検索ウィンドウ	69
故障とお考えになる前に	135
さ	
災害用伝言板サービス	13
サイレントマナー	40
三者通話サービス	
ジャンプメール	5
充電	9、18
受信ボックス	

受話ロ	電源
た	は
卓上ホルダ       18         タスク切替メニュー…       29         着信…       38         着信音…       113         着信財否       12         着信爾送サービス       78         着信履歴       39         通常マナー       40         通知アイコン       30         通話明細分計サービス       76         データ通信サービス       76         データフォルダ       100         デコレーションアニメ       54	バックアップ
デコレーション絵文字入力35	ま
デコレーションメール52 テレビ電話99 テレビ録画99 テレビ(ワンセグ)97 天気予報64	マイク26、31、114 待受画面26、31、114 待受ショートカット30 待ちうた76 マナーモード40

ムービー録画	91
迷惑電話撃退サービス	76
迷惑メール	57
迷惑メールフィルター	
メインメニュー	28
文字入力	33
や	
ユーザー設定アイコン	30
よく使うメニュー	29
5	
<b>5</b> 料金照会	13
料金照会	17
料金照会 レシーバー	17 139
料金照会 レシーバー 連続通話時間	17 139 139
料金照会 レシーバー 連続通話時間 連続待受時間	17 139 139
料金照会 レシーバー 連続通話時間 連続待受時間 ロックNo8	17 139 139 0, 115

# 目的から引く索引

Wi-Fi WINを利用する	
アクセスポイントとの接続を切る	. 85
アクセスポイントに接続する	. 84
アクセスポイントを登録する	. 84
インターネットにアクセスする	
EZwebでアクセスする	
PCサイトビューアーでアクセスする	. 75
海外で利用する	
グローバル機能(グローバルパスポートCDMA)を利用する	
グローバルパスポートGSMを利用する	.82
確認する	
microSDメモリカードについて確認する	102
PINコードについて確認する	. 80
T006の主な仕様を確認する	139
T006の電話番号を確認する	.47
アイコンの意味を確認する	. 26
アフターサービスについて確認する	137
安全上の注意事項を確認する	118
各種暗証番号について確認する	. 80
各部の名称を確認する	. 16
充電のしかたを確認する	

ノロフィールの内谷を唯認 9 る	4/
防水の注意事項を確認する10、1	31
本書について確認する	8
待受画面の見かたを確認する	26
カメラで撮影する	
大きなフォトを撮影する	89
フォトを撮影する	87
ムービーを録画する	91
基本操作を覚える	
機能を設定する1	12
基本的なキー操作を覚える	31
複数の機能を切り替えて利用する	29
待受画面から機能を起動する	30
メインメニューから機能を起動する	28
文字入力の方法を覚える	33
ゲームで遊ぶ	
EZアプリを利用する	73
困ったときは	
安心ロックを利用する	15
故障とお考えになる前に1	35
ご利用の準備をする	
au ICカードを取り外す・取り付ける	83
Eメール·EZwebの初期設定をする	21
microSDメモリカードを初期化する1	03
microSDメモリカードをセットする・取り外す24、	25

PIN I コートを変更する I 16	操作万法を調べる
充電する18	- オンラインマニュアルを表示する12
テレビ(ワンセグ)の初期設定をする97	操作方法を調べる100
電源を入れる/切る20	なるほど!auを利用する13
電池パックを取り外す・取り付ける22、23	ニーク心性和ちに強する
ロックNo.を変更する115	データや情報を保護する
情報を調べる	microSDメモリカードにデータをバックアップする 105
EZwebを利用する62	データを交換する
EZチャンネルプラス/EZチャンネルを利用する67	Bluetooth®機能を利用する11
EZニュースEXを利用する68	赤外線を使ってプロフィールを交換する48
PCサイトビューアーを利用する75	データを表示/再生する
お天気を調べる64	LISMO WAVEでFMラジオや動画を再生する94
カレンダーを表示する109	microSDメモリカード内のデータを表示する104
地図を表示する70	音楽をLISMOで再生する
通話料や通信料の目安を調べる63	簡易留守メモを再生する
テレビ(ワンセグ)を見る98	データフォルダのデータを表示する100
乗り換えを調べる65	ビデオをLISMOで再生する95
待受画面から情報サイトを検索する69	本(電子書籍)をLISMOで再生する96
道を調べる70	
料金プランや割引サービスを調べる63	電話を受ける
設定をする	お留守番サービスで留守応答する77
アラームを設定する108	簡易留守メモで留守応答する4
機能を設定する112	着信拒否する12
ケータイアレンジを利用する110	着信転送サービスで電話を転送する78
着信音を変更する113	電話番号が通知されない電話を拒否する75
有信目で変更する	電話を受ける38
可久  国内で名文 5 / 0	マナーモードを設定する 40

電話をかける	
アドレス帳から電話をかける	44
通話中の相手の声を大きくする	37
電話番号を通知して電話をかける	79
電話番号を通知しないで電話をかける	79
電話をかける	37
発信履歴/着信履歴を利用して電話をかける	39
登録する	
アドレス帳に電話番号などを登録する	43
受け取ったメールのアドレスを登録する	46
お気に入りリストに情報サイトを登録する	66
かかってきた電話の番号を登録する	45
カレンダーにスケジュールを登録する1	09
非常時に備える	
PIN1コードを変更する1	16
安心ナビを利用する	71
遠隔ロックを利用する	14
置き忘れたau電話の位置を検索する	15
緊急地震速報を利用する	61
災害用伝言板サービスを利用する	13
着信があったように見せかける1	07
ロックNo.を変更する1	15

メールを受け取る	
Cメールを受け取る	59
Eメールを受け取る	55
受信ボックスのCメールを確認する	60
受信ボックスのEメールを確認する	56
迷惑メールを受け取りたくない	57
メールを送る	
Cメールを送る	58
Eメールを送る	50
送信ボックスのCメールを確認する	60
送信ボックスのEメールを確認する	56
デコレーションアニメを送る	54
デコレーションメールを送る	52
添付データを送る	50
撮ったフォトをメールで送る	88

本製品に搭載されているソフトウェアまたはその一部につき、改変、翻訳・翻案、リ バース・エンジニアリング、逆コンパイル、逆アッセンブルを行ったり、それに関与 してはいけません。

本製品を、法令により許されている場合を除き、日本国外に持ち出してはいけま せん。(本製品は、外国為替及び外国貿易法によるリスト規制品を含みます。米国 輸出規制により、以下の国々に本製品を持ち込むことはできません。(2009年9 月現在)キューバ、イラン、朝鮮民主主義人民共和国、スーダン、シリア)

U.S law and international agreements currently prohibit export of this device's browser and security technology to the following countries-Cuba, Iran, North Korea, Sudan and Syria, (Other restrictions regarding this device may apply.)









**NetFront** Browser

**NetFront** M-IMAP Client

**NetFront SMIL Player** 

**NetFront** Sync Client





























RSA®はRSA Security Inc.の登録商標です。BSAFE™はRSA Security Inc.の米国およびその他の国における登録商標です。

Myriad Group、Myriad Groupのロゴ、およびMyriad Groupで始まる用語群 はすべてMyriad Groupの商標です。その他の商標および登録商標は各所有企 業に属します。

Myriad Group, the Myriad Group logo and the family of terms carrying the "Myriad Group" prefix are trademarks of Myriad Group AG. All other trademarks and registered trademarks are the properties of their respective owners. Copyright © 2001-2011 Myriad Group AG. All Rights Reserved.

「ATOK」は株式会社ジャストシステムの登録商標です。

「ATOK | は株式会社ジャストシステムの著作物であり、これにかかる著作権、そ の他の権利は株式会社ジャストシステムおよび各権利者に帰属します。

microSDロゴ、microSDHCロゴはSD-3C、LLCの商標です。

本製品はワンセグデータ放送BMLブラウザとして、株式会社ACCESSの NetFront Browser DTV Profile Wireless Editionを搭載しています。

本製品は放送コンテンツ起動機能として、株式会社ACCESSのMedia:/メディ アコロン仕様を採用しています。

本製品のソフトウェアの一部分に、Independent JPEG Groupが開発したモ ジュールが含まれています。

Copyright @ 1996-2011 ACCESS Co., LTD.

本製品はインターネットメール機能として、株式会社ACCESSのNetFront v3.3 M-IMAP Client for KDDIを搭載しています。 Copyright @ 2003-2011 ACCESS CO., LTD.

本製品はSMILプレーヤとして、株式会社ACCESSのNetFront SMIL Player を搭載しています。

Copyright @ 2003-2011 ACCESS CO., LTD.

本製品はデータ授受機能として、株式会社ACCESSのNetFront Sync Client を搭載しています。

Copyright @ 2004-2011 ACCESS CO., LTD.

ACCESS、NetFrontは株式会社ACCESSの日本またはその他の国における 商標または登録商標です。

本製品はAdobe Systems IncorporatedのFlash® Lite™テクノロジーを搭 載しています。

Adobe、Flash、FlashLiteおよびMacromediaはAdobe Systems Incorporated (アドビ システムズ社)の米国ならびにその他の国における商標または登録商標です。

Brew MP™及びBrew MP™に関連する商標は、Qualcomm社の商標または登録商標です。

Brew  $\mathsf{MP^{TM}}$  is a registered trademark of Qualcomm Incorporated and the Brew  $\mathsf{MP}$  logo with interlocking circles is a trademark of Qualcomm Incorporated.

This wireless device ("Device") contains BREW software owned by Qualcomm Incorporated ("Software"). OEM hereby grants to each recipient of this Device ("User") a non-exclusive, non-transferable, non-assignable license to use the Software solely in conjunction with the Device on which it is installed, for the duration of the useful life of such Device. Nothing herein shall be construed as the sale of the Software to the User of this Device. User shall not reproduce, modify, distribute, reverse engineer, decompile or use any other means to discover the source code of the Software or any component of the Software. Qualcomm Incorporated is the sole and exclusive owner of and retains all rights, title and interest in and to the Software. Qualcomm Incorporated, and to the extent that the Software contains material or code of a third party such third party, shall be intended third party beneficiaries of these terms.

Operalは、Opera Software ASAの商標または登録商標です。 Operaに関する詳細については、http://jp.opera.comをご覧ください。

FeliCaはソニー株式会社が開発した非接触ICカードの技術方式です。FeliCaはソニー株式会社の登録商標です。

つは、フェリカネットワークス株式会社の登録商標です。

「おサイフケータイ®」は株式会社NTTドコモの登録商標です。

Gガイド、G-GUIDE、Gガイドモバイル、G-GUIDE MOBILE、およびGガイド関連 口ゴは、米Gemstar-TV Guide International, Inc. およびその関連会社の日本国内における登録商標です。

Portions of software incorporated in this product are copyright Digital Fountain, Inc., are covered by current and pending patents, and are protected by other intellectual property laws and international treaties.

Powered by JBlend™ Copyright 1997-2011 Aplix Corporation. All rights reserved.

JBIendおよびJBIendに関する商標は、日本およびその他の国における株式会社アプリックスの商標末たは登録商標です。

OracleとJaval、Oracle Corporation及びその子会社、関連会社の米国及びその他の国における登録商標です。文中の社名、商品名等は各社の商標または登録商標である場合があります。

Bluetooth®ワードマークおよびロゴは、Bluetooth SIG, Inc.が所有する登録商標であり、富士通は、これら商標を使用する許可を受けています。

Wi-Fi®はWi-Fi Alliance®の登録商標です。

BUFFALO™は株式会社メルコホールディングスの商標です。

AirStation™、AOSS™は株式会社バッファローの商標です。

らくらく無線スタート®はNECアクセステクニカ株式会社の登録商標です。

Aterm®は日本電気株式会社の登録商標です。

Wi-Fi Protected Setup™はWi-Fi Alliance®の商標です。

ホットスポット®はNTT コミュニケーションズ株式会社の登録商標です。

BBモバイルポイント®はソフトバンクテレコム株式会社の登録商標です。

livedoor®は、株式会社ライブドアの登録商標です。

Wireless Gate  $^{\circ}$  (ワイヤレスゲート) は株式会社トリブレットゲートの登録商標です。

Wi2 300™は株式会社ワイヤ·アンド·ワイヤレスの商標です。

「うたとも®」は、株式会社レーベルゲートの登録商標です。

本製品には赤外線通信機能としてイーグローバレッジ株式会社のDeepCore® 3.0 Plusを搭載しています。

Copyright @ 2005 E-Globaledge Corp. All Rights Reserved.

SanDiskはサンディスク社の登録商標です。

QRコード<sup>®</sup>は株式会社デンソーウェーブの登録商標です。

DBEX™は、DiMAGIC社の商標です。

「着うた<sup>®</sup>」「着うたフル<sup>®</sup>」「着うたフルプラス<sup>®</sup>」は株式会社ソニー・ミュージックエンタテインメントの登録商標です。

「ATRAC」は、ソニー株式会社の商標です。

「moralは株式会社レーベルゲートの登録商標です。

「REGZA」は株式会社東芝の登録商標です。

※「PCドキュメントビューアー」はCATALYST MOBILE® Readerにより実現しています。

%「CATALYST MOBILE®」はカタリスト・モバイル株式会社の登録商標です。

Microsoft® Word, Microsoft® Officeは、米国Microsoft Corporationの商品名称です。

Adobe、Adobeロゴ、Acrobatは、Adobe Systems Incorporated (アドビシステムズ社)の米国ならびにその他の国における商標または登録商標です。

Microsoft<sup>®</sup>, Windows<sup>®</sup>, Windows Vista<sup>®</sup>, Excel<sup>®</sup>, PowerPoint<sup>®</sup>は、米国 Microsoft Corporationの米国及びその他の国における登録商標です。

Windows®の正式名称は、Microsoft® Windows® Operating Systemです。

画像高速表示技術には株式会社モルフォのImageSurf®を採用しております。 ImageSurf®は株式会社モルフォの登録商標です。

撮影シーン判定技術には株式会社モルフォのPhotoScouter™を採用しております。PhotoScouter™は株式会社モルフォの商標です。

顔検出機能には株式会社モルフォのFaceSolidを採用しております。 FaceSolidは株式会社モルフォの日本またはその他の国における商標または登録商標です。

Powered by MascotCapsule® 3D e-moji engine
MascotCapsule® is a registered trademark of HI CORPORATION
© 2002-2009 HI CORPORATION. All Rights Reserved.

ケータイチェック機能にはCommon Public License (CPL)に基づきライセンスされるソフトウェアが含まれています。当該ソフトウェアに関する詳細は、下記のサイトをで参照ください。

お使いのパソコンから:auホームページ→auオンラインマニュアル(http://www.au.kddi.com/manual/index.html)  $\rightarrow$  [T006]を選択→[その他]  $\rightarrow$  [ケータイチェックメニュー機能CPLに関して]

その他の社名および商品名は、それぞれ各社の登録商標または商標です。

## OpenSSL License

[OpenSSL License]

Copyright © 1998-2007 The OpenSSL Project. All rights reserved.

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)

THIS SOFTWARE IS PROVIDED BY THE OPENSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OPENSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)

HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

[Original SSLeay License]

Copyright © 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS

OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## **FCC Notice**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help and for additional suggestions.

#### Warning

The user is cautioned that changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

## FCC RF EXPOSURE INFORMATION

Warning! Read this information before using your phone.

In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

#### Specific Absorption Rate (SAR) for Wireless Phones

The exposure standard for wireless handsets employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.

The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model handset when tested for use at the ear is 0.385 W/kg and when worn on the body, as described in this user guide, is 0.561 W/kg.

#### **Body-worn Operation**


This device was tested for typical body-worn operations with the back of the phone kept 0.59 inches (1.5 cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.59 inches (1.5 cm) must be maintained between the user's body and the back of the phone, including the antenna. All beltclips, holsters and similar accessories used by this device must not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with FCC RF exposure limits and should be avoided.

#### Turn off your phone before flying

You should turn off your phone when boarding any aircraft. To prevent possible interference with aircraft systems, U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

# English Simple Manual(簡易英語版)





## Turning Power On and Off

- Turning Power On
  - Hold down for at least one second.
- Turning Power Off

Hold down for at least one second.

## Switching the Screen to English

From the stand-by screen: Press ●. ▶ Press ③. ▶ Press ⑤. ▶ Press ②.

## **Checking Your Own Phone Number and E-mail Address**

From the stand-by screen: Press . Press O.

## Making and Answering a Call

## Making a Call

From the stand-by screen: Enter the phone number you want to call. ▶Press .

To end a call: Press ----

#### Answering a Call

When the phone starts ringing, press . To adjust the earpiece volume during a call: Use 🗘.

## Storing and Recalling Address Book **Entries**

#### Storing an Entry

From the stand-by screen: Hold down in for at least one second. ▶Use 🛟 to select the item you want to edit. ▶ Press 💽 (Select). ▶Enter the data. ▶Press (Reg).

#### Recalling an Entry

From the stand-by screen: Press 🖂 to display the Address Book screen.

- ▶ Use → to select the tab for the record you want to recall.
- ▶ Use 🛟 to select the name of the record.
- ▶ Press (Detail) to view the record in detail.

## **Using the Camera (Movie and Snapshot)**

## Recording a Movie Clip

From the stand-by screen: Press 
. Luse to select "Camera".

- ▶ Press (Select). ▶ Select "Movie (Mail)". ▶ Press (Select).
- ▶ Press (Record) to start recording.
- ▶ Press (Stop) to stop recording.

▶ Press • (Save) to store the movie.

Press (II) (Pause) during recording to pause recording.

Press (□ (□ ⇒ □) in the Movie mode to change to the Photo mode.

## Taking a Snapshot

From the stand-by screen: Press . Let Use to select "Camera".

- ▶ Press (Select). ▶ Select "Photo (DSC)". ▶ Press (Select).
- ▶ Press (Shoot) to take a snapshot.
- ▶ Press (Save) to store the photo.

Press ( ) in the Photo mode to change to the Movie mode.

## Making an International Call

Ex: To call 212-123- \(\triangle \triangle \triangle \triangle \) in the USA



Number you want to call

## **Other Handy Features**

## Setting the Manner Mode

From the stand-by screen: Hold down 😎 for at least one second. Repeat the above operation to disable the Manner Mode.

#### Setting the Answer Memo (Voice Recording)

From the stand-by screen: Hold down for at least one second. Repeat the above operation to disable the Answer Memo.

#### For inquiries, please contact

au Customer Service Center (General Information)

- If you are calling from a landline phone:
  - **©** 0077-7-111 (toll free)
- If you are calling from an au mobile phone: 157 (toll free)