


EUT – Transceiver module (side 1)



EUT – Transceiver module (side 2)



Transmitter module mounted in sample host (view 1)



Transmitter module mounted in sample host (view 2)

