

Bluetooth Keyboard User Guide


 To activate the keyboard power, first, push the white switch to "ON" position, you will see the power lights as the figure shown below.



2. When the screen enters into Win 7, please click the "triangle" option on the task bar.




3. The selection box appears, then click the "Bluetooth" option.




4. A list of options appear, please select "Add Device".




5. The Bluetooth device will automatically appear, but Bluetooth keyboard does not appear this time.



6. You need to use sharp object to press the reset button for restarting the keyboard. Simultaneously, the blue light blinks, that indicates the keyboard makes a pair with the machine.



7. In pressing the reset button, the Bluetooth keyboard appears in the box, please double-click the Bluetooth Keyboard.



8. The screen now appears the matching code (the matching code are not the same when you reset the keyboard each time). Please follow the screen instructions to enter the code directly from the keyboard and press enter.



 When matching procedures are completed, the Bluetooth keyboard can be used



Specification

Product Name:	BT Keyboard
Model No. :	AC-30
Carrier Frequency Modulation Model	Blue Tooth
Frequency:	2.402GHz~2.480GHz
Number of Channel	79 channel
Power	4.5V~3.0V
Operating Voltage:	3.0V
Operating Current	4mA

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.