Wireless life



Quick Installation Guide

300 Mbps Wireless USB Adapter Air 2411

Installation













Step 1 Insert the Air 2411 Easy Setup CD into your PC.



Installation

Please run the Easy Setup CD first.

- The Air 2411 Wireless USB Adapter can be used with both laptop and desktop computers.
- You can use the extension cable that is included in the box to help your device receive the best possible signal and work at the highest possible speed.
- Wireless devices work best if they "see" each other. Place the desktop unit and the extension cable in a way that they can "see" the router or access point.

Important! Windows Vista users must have SP1 installed. SP1 can be downloaded from www.microsoft.com/downloads.

^{*} Please see the back of this guide for the installation diagram.

Step 2 To begin the installation process, click "Next>" in the AirTies Utility Setup Wizard.





Step 3 After the driver installation is complete, you will be asked to insert the Air 2411 Wireless USB Adapter. Insert the device into the USB port either by itself or using the extension cable. Click "Finish" to complete the installation.



For detailed information and advanced settings, please refer to the User Manual included in the Easy Setup CD (Air2411.pdf).



TECHNICAL PROPERTIES:

- Wireless Standards: IEEE 802.11n, IEEE 802.11g, IEEE 802.11b
- 802.11b: 1, 2, 5.5, 11 Mbps
- 802.11g: 6, 9, 12, 18, 24, 36, 48, 54 Mbps
- 802.1n: 6,5 300 Mbps
- Frequency range: ETSI 2400 MHz 2483.5 MHz
- Outup Power: 16dBm EIRP
- USB and Wireless Activation LED
- Wireless Security: WEP, WPA, WPA2, 802.1x
- · Low Power Consumption Mode
- WMM (Wireless Multimedia)
- · DPT (Direct Packet Transmission) Feature

1),

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

2),

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help. 3),

Please include instructions in the User Manual that this device is restricted to indoor use only.

Warranty

- Manufacturer guarantees absence of manufacturing defects and failures of the Equipment and bears responsibility accordingly to warranty.
- If your AirTies product fails, contact AirTies 24/7 Technical Support first (see 24/7 support number on www.airties.com). Most problems can be solved by consulting the experts at AirTies technical support.
- If the AirTies 24/7 technical support requires, you will be assigned a
 problem tracking number and asked to ship the faulty unit to AirTies
 repair center. Please, write the problem tracking number legibly on
 the package.
- The product is under warranty for 3 years starting from the date of purchase.
- The parts that are shipped with the product such as power adapter and cables are all covered under this 3-years warranty.
- If the product fails for any reason within the warranty period, it will be repaired by AirTies or an AirTies Authorised service provider at no cost to the customer.
- The units that are not repairable will be replaced by a new or refurbished unit at no cost to the customer.
- The warranty does not cover defects caused by misuse or abuse of the product.
- The products that are sent to an Authorised AirTies Service Center, will be repaired or replaced and shipped back to the customer within 3 business days from the date it is received.
- If a replacement with the same product model is not possible, AirTies will replace the unit with a newer model that has all the features of the original product.
- 11. Check www.airties.com for repair centers.

©2011 AirTies Wireless Networks, all rights reserved. Trademarks or registered trade marks are the property of their owners. Software and specifications may be changed without notification.

No	
	e seller completely fills out the warranty card, I serial number and product models.
PRODUCT:	
MODEL:	
SERIAL NUMBER:	
DATE OF SALE:	
Warranty period – three years from	n the date of purchase.
FIRM-SELLER:	
FIRM-SELLER ADDRESS AND PH	ONE NUMBER:
Defect-free item received with a fu conditions acquainted and agreed	all set, with warranty conditions, rules and service
CUSTOMER'S SIGNATURE:	
FILLING DATE:	STAMP HERE:
With "unconditional customer sati	isfaction" as its standard , AirTies offers the

24/7 people support +90 212 444 0 239

following terms and conditions on all its products:

www.airties.com



Easy setup CD



Three years warranty



24/7 Technical support

