User Manual

Model number: 1645854

Remote-controller's battery installation

- 1) Release the cover of battery box
- 2) Install 9V batteries into battery compartment according to the right poles
- 3) Close the cover of the battery box

Car battery installation

- 1) Unlock the battery cover of the battery compartment which is back of the car;
- 2) Install 3×AA batteries into battery compartment according to the right poles;
- 3) Close the cover of the battery compartment;
- 4) Lock the battery cover.

Use instruction

- 1) Turn the power switch of car-body to "ON" position;
- 2) When the user control the control stick, the LED light will be turn on; When the light is turning dimmer, the batteries are to be replaced;
- 3) Operate the handle of the controller, the car can move Forward and Backward clockwise. After play, turn the power switches of car-body to "OFF" position.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment such modifications could void the user authority to operate the equipment.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.