
TR-6 User Manual



A. TV control area

- 1) Press【学习】button about 2s until the red LED turned on and then release this button. The TR-6 enter learning status.
- 2) Press & release the desire button for learning("A" area), the red LED will flash,TR-6 enter learning receiver status.
- 3) Press the correspondence button on original remote control aim at the top of TR-6.
- 4) The red LED will flash three times to confirm store the present remote code.
- 5) Otherwise if the red LED flash two times it means
- 6) Repeat $(2) \sim (5)$ for other remote code learning.
- 7)Press【学习】button to exit the learning mode.

Now you can use your TR-6 to control your TV set now.

F+B.Mouse+Game control

- 1)Plug the micro receiver into your computer's USB port.
- 2) Double click the middle button of the "F"area to open the Air mouse and Game control function, the blue LED will turned on.
- 3) Now the cursor on your computer will be moved following the movement of the TR-6.
- 4) Also you can use the TR-6 to control the body feeling games we provide for you.
- 5) Double click the middle button again to close the Air mouse and Game control function, the blue LED will turned off.
- 6) If the TR-6 don't connect with the micro receiver ,when you pressed any button under the "F" area, the blue LED will flash.

C. Set-top box control

- 1)You can use this buttons to control the Set-top box's functions. When any button pressed the red LED will turned on and send infrared codes through the IR LED, and turned off when you released it.
- 2)Press 【F4】 button to turn on the mircophone function, the red LED will turned on and you can use the TR-6 as a wireless microphone. Press 【F4】 again to exit this function.
- 3)Also you can use this button to operation your computer. You can use the UP/LEFT/RIGHT/DOWN buttons as the normal keyboard UP/LEFT/RIGHT/DOWN buttons.

D. Micro receiver

E. Mircophone input

F. Mouse control

It includes left mouse button, right mouse button and cursor enable button. Open the Air mouse function and hold TR-6 at any angle and point in any direction. No need to keep it level or pointed at the screen. For maximum responsiveness, hold TR-6 like a remote, point by tilting the nose of mouse up, down, or side-to-side.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter