Before using the headphone, please carefully read this user

■ Features

- · TWS (True Wireless Stereo) earphones Two earphones mode and single earphone mode meet different
- Compact shape easy for carrying around 3 hours earphone playing, charging box for more 9 hours playing
- 8mm moving coil driver unit
 Bluetooth V4.2 with CSR technology
- Lightweight design equipped with removable ear wings
 Multifunctional button to control call and music

■Specifications

■ Specifications

Bluetooth version: Bluetooth V4.2

Bluetooth profile: HFP, HSP, A2DP, AVRCP

Bluetooth distance: 10m

Playback lime: 3 hours (earphones) + 9 hours (charging box)

Charging time: 1.5 hours (earphones) + 3 hours (charging box)

Input: 5.0V=500mA

Frequency response: 20Hz-20KHz

Sensithity: 98dB

Impedance: 320

to change from time to time without prior notice Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product Picture for reference only, actual product prevails. Note:

• Playback time and charging time will be varied by playing environment, volume and audio source devices.

• The design and specifications may be changed without prior notice in order to make improvements.

Ver1.0 IB-200-XXXXXX-00

EDIFIER International Limited

© 2018 Edifier International Limited. All rights reserved.

For the need of technical improvement and system

upgrade, information contained herein may be subject

www.edifier.com

Printed in China

NOTICE:

■Box contents



Left and Right earphones x 1 PCS













■Operational instructions



■Charging

During using, if red light instead of blue light flashes, it indicates

Charging: Place the earphones into the charging box, and e that Leaphone for left position and R earphone for right position. Earphone indicator: Red light steady lit = charging Red light off = fully charged Charging time: about 1.5 hours for a full charging

2. Charging box
Blue light indicates battery capacity, and it can charge the

earphones for 3 times if blue lights are all lit; it indicates that battery capacity is if only the leftmost blue light is lit, please charge the charging box.

Charging: Connect the provided charging cable to the microUSB

port of the charging box; Charging box indicator: Blue light all lit = fully charged Charging time: about 3 hours for a full charging

Warning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion

■ How to use the earphones

I. How to wear

· Please select suitable ear wings according to your ear size Ensure that L earphone is for left ear and R earphone for right ear, and adjust earphones to the most comfortable position.

II. Power ON/OFF

turn off simultaneously.

2. Power OFF

III. Connection

1. Power ON · Take out the earphones from the charging box, they will turn on

2. Power Orr Place the earphones into the charging box, they will turn off automatically; When without the charging box, press and hold the multifunctional button of the L/R earphone for 2 seconds, the earphones will

1. Connect to mobile phone in Two Earphones Mode
Place TWS3 near mobile phone, and enable Bluetooth function
of the mobile phone;
Open TWS3 charging box to take out the two earphones, they

will automatically turn on, make interconnections, and enter

. Set the mobile phone to search for and connect to "EDIFIER TWS3"

and the pairing is successful when the blue light flashes slowly

pairing status with red and blue light flashing rapidly;

2. Connect to mobile phone in Single Earphone Mode 2. Contect of money priore in angie Earphone wode
The left earphone is the main earphone by default, please take
out the left earphone from the charging box if only needs to use
one earphone, please refer to the connection procedures
mentioned in "Two Earphones Mode" to complete connection.

and right earphones
The left and right earphones have been paired before leaving the factory. If the wireless connection fails to resume, please follow the steps below to re-pair: . When without the charging box, press and hold the multifunctiona button for 2 seconds, the earphones will be on and enter pairing

In standby status, separately double press the multifunctional button of the L/R earphone to enter TWS status, red and blue

3. TWS (True Wireless Stereo) pairing and connection for left

lights will flash rapidly;

• Make the L/R earphone close to each other and wait for 8 seconds to let them pairing automatically; after the pairing is finished, blue lights of the L/R earphone will both flash slowly.

When connected to IOS® devices, the device can display real-time battery level of the earphones. And it will display red to remind the user to charge the earphones



Fully charged



Low battery leve

VI. Play music

Function Headphone status Operation

Previous track Play music Double press the multifunctional button of the Leaphone

Play music Double press the multifunctional button of the Reaphone

Pless the multifunctional button of the Reaphone ume playing Pause playing Press the multifunctional button the L/R earphone

VII. Restore to factory settings

V. Basic call operation

ing call ringing

ang up call Talking

Only the left earphone supports call operation

When unconnected or in paring status, press the multifunctional button three times until blue light is steady lit after flashing slowly 5 times, then the earphones have restored to factory settings.

After factory settings are restored, please place the earphones back into the charging box and charge the earphones, then you can operate the multifunctional buttons.

· After factory settings are restored, pairing list of the earphone: will be cleared but the pairing record with the other earphone will be reserved. Please re-pair to the earphones if wants to connect to mobile phone.

During using, please read the following advices carefully to help you comply with warranty terms and extend the product's service life.

- \bullet Keep the product away from humid places to avoid affecting
- internal circuit.Do not use the product during intense exercise or with much weat to prevent sweat from dropping into it to make damage Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic
- components, damage battery and deform plastic components . Do not put the product in cold places to avoid damaging internal
- Do not dismantle the product. Non-professional personnel may damage the product.
 Do not drop, strongly vibrate, strike the product with hard object to product the product with the prod
- to avoid damaging internal circuit.

 Do not use drastic chemicals or cleaner to clean the product. Do not use sharp objects to scratch product surface to avoid

damaging shell and affecting looking. If the product cannot operate properly, please send it to your qualified maintenance agency for repair.

■FAQs Red light instead of blue light flashes.

底面

Red light is off during charging.

- Please ensure the earphone is appropriately placed in the charging box.
- When the earphone is not used for long periods of time, the battery will enter sleep state, it needs to charge about 30 minutes and then the red light will be lit.

- . Check if the earphone volume is at an appropriate level.
- . Check if the earphone is correctly connected with mobile phone Check if the earphone is operated within normal working range

Check if mobile phone is in an area with strong signal.
 Please ensure the earphone is within effective distance (10m)

and no obstacle between the earphone and mobile phone. When playing music, unable to control pause/play/previous

track/next track via earphone.

• Please ensure the paired device support AVRCP (Audio/Video Remote Control Profile) profile

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine fire or the like



- 1. "To prevent possible hearing damage, do not listen at high
- volume levels for long periods."
- "Fully understand user manual before use."

3. "Ensure your player at low volume levels or power off before

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

FCC statement:

"This device complies with Part 15 of the ECC Rules Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

10

IC statement:CAN ICES-3(B)/NMB-3(B) FCC ID: Z9G-EDF69 IC: 10004A-EDF69



Replace only with the same or equivalent type. For products with removable battery, the battery must be properly recycled or disposed. For products with built-in battery, disassembling is prohibited.

Never disassemble, hit with force, squeeze batteries or dispose of batteries in fire. Do not expose batteries in conductive materials, liquid, fire or heat. Do not let metal object contact two battery poles. If the battery looks swollen, leaking, discolored, having odor or any abnormal appearance stop using it. Do not use the battery after immersed in water. Improper use of battery may lead to explosion or leakage, causing skin burn or other injuries; in the event of battery leakage, handle it with care and immediately dispose of the battery in the manner in compliance with applicable laws and regulations in your locality.

(EN) Warning!

To guarantee your personal safety, please do not wear or keep earphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Earphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.

For traffic safety, do not use earphones while driving or cycling.

12

安全注意事項:

為保證您的人身安全,請勿將該耳機佩戴或放置在離心臟 起期器過近的位置(小于10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備,本產品幷非玩具。 在高音量下使用耳機——特別是長時間使用——可能會對

您的聽力造成損傷。 操作高保真音響開關或插入耳機時可能會發出尖利的聲音 其在高音量設置下可能會影響您的聽力。因此,在切換各種音源或插入耳機前,請將音量控制設置為最低。

為交通安全起見,駕駛時或騎自行車時請勿使用耳機。

13

Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm) d'un pacemaker.

Ne pas introduire la fiche à jack dans des prises de courant.

Surveillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier s'il est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une service à l'illustre claire platifie la lectera de CP d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

14

Attenzione! Al fine di garantire la sicurezza personale, fare attenzione che queste cuffie non siano posizionate in prossimità del proprio eventuale pace maker

Non introdurre la spina jack in una presa sotto

(con una distanza inferiore a 10 cm).

Sorvegliare i bambini quando utilizzano il dispositivo. Questo apparecchio non è un giocattolo.

L'utilizzo delle cuffie ad alto volume, soprattutto se prolungato, può danneggiare l'udito. Maneggiare le manopole del Vostro sistema hi-fi o inserire le cuffie quando il volume è troppo alto, potrebbe produrre dei rumori che potrebbero danneggiare l'udito, soprattutto se il volume è alto. Si consiglia pertanto di regolare il volume al minimo prima di passare da una fonte all'altra (radio, giradischi, lettore CD, ecc.) o prima di collegare le

Per la sicurezza nel traffico, si prega di non usare mai le cuffie mentre si guida o si va in bicicletta.

Peringatan! Untuk menjamin keselamatan diri Anda, jangan memakai atau menyimpan earphone di sekitar (dekat dari 10 cm) alat pacu jantung.

Jangan masukkan steker ke stopkontak listrik.

Awasi anak-anak saat menggunakan peralatan, produk ini bukan mainan.

penyumbatan pada earphone dapat menimbulkan klik yang pada pengaturan volume tinggi dapat memengaruhi pendengaran Anda.

Mendengarkan earphone pada tingkat volume tinggi – khususnya, selama waktu yang lama – dapat merusak pendengaran Anda.

Karena itu, selalu mengatur kontrol volume paling endah sebelum beralih di antara berbagai su

(penala, pemutar piringan hitam, pemutar CD, dll) atau penyumbatan pada earphone. Untuk keselamatan lalu lintas, jangan gunakan earphone selama mengemudi atau berkendara.

Waarschuwing!

Steek de stekker in een stopcontact.

Om uw persoonlijke veiligheid te garanderen, dient de koptelefoon niet te worden bewaard of gedrager in de buurt van (minder dan 10 cm) een pacemake

Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor.

De bediening van de schakelaars op uw hifisysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten. Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen

de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon

wordt aangesloten. Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het riiden of fietsen.

【】 경고! 안전상의 이유로,이 헤드폰은 심장박동 조절장치 근처

잭 플러그를 전류가 흐르는 소켓에 삼입하지 마십시오.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰 이 필요합니다.이 제품은 장난감이 아닙니다. 헤드폰을 높은 볼륨상태에서 특히 장기간 사용할 경우 청

하이파이 오디오 시스템상에서 스위치를 바꾸거나 해드 폰을 하이파이 오디오 시스템에 연결할 경우.높은 불류상 태에서는 청각에 해를 줄수 있는 클릭소리가 날수 있습니 다.그러므로 하이파이 오디오 시스템상의 한 소스키기에 서 다른 소스기기(라디오,레코드 플레이어,CD-플레이어..) 를 선택하거나 헤드폰을 연결시킬 경우에는 항상 불류을 초저상태로 조정해 놓으십시오.

여러분의 운정상태와 다른 운전자들의 안전을 보호하기

Um Ihre persönliche Sicherheit zu garantieren, achten Sie oitte darauf, dass dieser Kopfhörer nicht in nächster Nähe

ufsichtigen Sie ihre Kinder bei der Benutzung des Geräts.

Die Verwendung von Kopfhörern kann bei großer Lautstärke - vol allem im Dauerbetrieb - zur Schädigung des Gehörs führen.

anschließen Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie Kopfhörer keinesfalls beim Lenken eines Kfz oder beim

19

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm

todo al utilizarlos durante largos períodos – puede conducir

Para no poner en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en

Запрещается вставлять штекер в электрические розетки

Прослушивание музыки через наушники на высокой громкости, особенно длительное вр ости, особенно длительное время может навредить вашему слуховому аппарату

لضمان سلامتك الشخصية، يرجى عدم ارتداء سماعات الرأس أو

ضربات القلب . لا تدخل القابس في مآخذ آمر بائية احرص على الإشراف على الأطفال عند استخدام الجهاز، فالمنتج ليس لعبة

الرأس قد يسبب نقرات والتي قد تؤثر على سمعك في مستويات الصوت العالية لذلك، قم دائما بضبط زر التحكم في مستوى الصوت على الحد

安全のために、このヘッドフオン-スメ-カ-の近く(10cm 以内)で使用または保管することは避けてください。 差し込プラグをコンセントに差し込まないようにして

ください。本製品は玩具ではありません。 する場合において聴覚障害の原因となる恐れがありま

お子様が使用になる場合は、必ず大人が付き添えって

HIF機器の切り替え時、あるいは機器にへっドフオンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を与える恐れがあります。 HIF機器で各ソス (ラジオ、レコードプレーヤ、CDプレーヤ...) を選ぶ際、あるいはヘッドフオンを接続する際には、音量のっまみを常に最少にしてください。



Aby zapewnić sobie bezpiecze ń stwo, nie należy nosić ani trzymać słuchawek w pobliżu (w odległości mniejszej niż 10cm)

Nadzorować dzieci podczas korzystania ze sprzętu, produkt to

Słuchanie w słuchawkach przy wysokich poziomach głośności, szczególnie przez długie okresy czasu, może spowodować

Dlatego należy zawsze ustawiać głośność na minimalnym poziomie przed przełączaniem między różnymi źródłami dźwięku (tunerem, gramofonem, odtwarzaczem CD itp.) lub podlączeniem słuchawek.

Indsæt ikke stikket i stikkontakter. Overvåge børn ved brug af udstyr, produktet er ikke legetøj.

Driften af kontakter på din hi-fi-system eller tilslutte hovedtelefonerne kan forårsage klik der på volumen indstilling højt kan påvirke hørelsen. Derfor altid indstiller lydstyrken til minimum, før der skiftes mellem forskellige kilder (tuner, pladespiller, CD-afspiller, etc.) eller tilslutte hovedtelefonerne

For trafiksikkerheden, ikke anvendes under kørsel eller cykling

D Sicherheitshinweis!

(näher als 10cm) zu Ihrem. Herzschrittmacher getragen oder auf-bewahrt wird. Klinkenstecker nicht in stromführende Buchsen einführer

Das Produkt ist kein Spielzeug.

Bei Umschaltvorgängen an Ihrer HiFi-Anlage oder bei Anschluss ber Unischaltvorganger an ihre nieder lage über der Artschlüsse des Kopfhörers an die Anlage können Knackgeräusche auftreten, die bei hoher Lautstärke das Gehör beeinträchtigen.Drehen Sie daher den Lautstärkeregler immer auf Minimum, wenn Sie an Ihrer HiFi-Anlage zwischen verschiedenen Quellen (Radio, Plattenspieler, CD-Player ...) wählen oder den Kopfhörer

Radfahren.

(Atención!

No introducir el conector Jack en los casquillos conductores

Vigile a sus hijos al utilizar el equipo. Este producto no es un La utilización de auriculares a un volumen muv alto - sobre

al deterioro del oído. Al operar los interruptores de su sistema HiFi o al conectar Al operar los interruptores de su sistema HiH o al conectar los auriculares al sistema puede hacer clíc, lo que a un volumen muy alto puede deteriorar el oído. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los auriculares.

ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.



В целях гарантии вашей безопасности просим не надевать и не держать наушники вблизи

При использовании прибора присматривайте за детьми, так как это оборудование не является игрушкой

Включение и выключение переключателей на высококачественной системе воспроизведения или подключение наушников может привести к возникновению целичков, которые на высокой громкости могут нанести вред вашему списковым адгаразу. слуховому аппарату. Таким образом, всегда устанавливайте громкость на минимальный уровень, прежде чем производить переключение между различными источниками (тюнер, диск проигрывателя,

CD-проигрыватель и т.д.) или подключать наушники в систему. Для безопасности дорожного движения не использу наушники во время езды на велосипеде и вождения

الاحتفاظ بها بالقرب من (أقرب من 10 سم) جهاز تنظيم

الاستماع من خلال سماعات الأذن عند مستويات الصوت العالية، خاصة على مدى فترات طويلة، قد يضر بسمعك تشغيل المفاتيح في نظام وأي فاي الخاص بك أو إدخال سماعات

الأدنى قبل التبديل بين المصادر المختلفة (موالف، قرص دوار، مشغل أقراص مدمجة، الخ) أو عند توصيل سماعات الرأس من أجل السلامة المرورية، لا تستخدم سماعات الرأس أثناء



安全なドライブ、そして他の運転手の安全のためにも、 お車を運転する場合、あるいは自転車に乗る場合には ヘッドヘオンは絶対に使用しないでください。





Nie wkładać wtyczki do gniazdka elektrycznego.

Działanie przełączników w systemie hi-fi lub podłączanie słuchawek mogą powodować mocne impulsy dźwiękowe które przy dużej głośności mogą powodować pogorszeni

Advarsel!

For at garantere din personlige sikkerhed, skal du ikke bære eller holde hovedtelefonerne i nærheden (tættere end 10 cm)

Hovedtelefon lytte ved høje lydstyrker Navnlig glæder over længere perioder - kan høreskader.