Operating instructions

EDIFIER International Limited www.edifier.com

© 2018 Edifier International Limited. All rights reserved Printed in China

NOTICE:

For the need of technical improvement and system upgrade, information contained herein may be subject

Products of EDIFIER will be customized for different applications Pictures and illustrations shown on this

Before using the headphone, please carefully read this user

■ Features

- Stylish and causal Bluetooth sports headphones . Half in-ear structure with soft earmuffs to wear comfortably
- Bluetooth V4.2 technology for signal stabilization
- 9mm moving coll unit to bring powerful low frequency fitting for dynamic pop music
 Support AAC audio decoding and call voice noise reduction
- · IP54 rating ensures daily sweat and splash proof Wired controller to easily control voice call/volume/music switching Dual battery design to support playback time of 5.5 hours

■ Specifications

Bluetooth version: Bluetooth V4.2 Bluetooth profiles: HFP, HSP, A2DP, AVRCP Effective distance: 10m Playback time: up to 5.5 hours Charging time: 2 hours


Standby time: About 200 hours Input: 5.0V==500mA Frequency response: 20Hz-20KHz Sensitivity: XXdB

Impedance: 32Ω

Driver unit: \$XXmm

Note: The design and specifications may be changed without prior notice in order to make improvements.

■Box contents



Headphone *1 PCS Earmuffs *3 Pairs

2. Volume+/next track 3. Multifunction button 4 Volume-/previous track 5 .Charging connector

6. Microphone


User manual *1 PCS

■Charging

Before use, ensure the headphones have a full charging.

During use, if red light instead of blue light blinks, it indicates low battery level and please use it after fully charged. Red light steady lit = charging Red light off = fully charged Charging time: about 2 hours for a full charging

Warning: to avoid battery life shortage, please at least charge the headphones once per three months



Varning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Oo not dispose of batteries in fire to prevent an explosion

■ How to operate the headphones

I. Power ON/OFF

 Turn off the headphones, then press and hold the multifunction button to let the headphones enter pairing status, and connect 1. Power ON: Press and hold the multifunction button for 3 seconds until blue light is on, there will be a prompt tone.
2. Power OFF: Press and hold the multifunction button for 4 seconds with the second mobile phone.

Then operate the first mobile phone to select "EDIFIER W285BT", until red light is on, there will be a prompt tone.

II. How to wear the headphones

1. Please select the appropriate earmuffs for your ear 2. Please ensure left sound channel for left ear and right for right ear, moderately insert earbuds into ears and adjust the earbuds to ensure the headphones fit comfortably and securely.

III. Pairing and Connection

- Connection with Bluetooth mobile phone
 The steps are as below:

 Place the headphones near mobile phone, the closer the better. When turned off, press and hold the multifunction button for 5 seconds until the red and blue light blinks alternately, it enters pairing mode.
- Set Bluetooth phone to search for and pair with "EDIFIER W285BT" Walt until hearing a prompt tone and the blue light will blink twice per 5 seconds.

- PIN code for connection is "0000" if needed
- After pairing is complete, the headphones will auto-connect to the device connected last time when powered on again;

nnect two Bluetooth devices simultaneously Pair the headphones with the first mobile phone

and it completes to connect two Bluetooth devices simultaneously

Note: When two Bluetooth devices have different operating sys

Note: when two suberoon devices have directent operating system (eg one has Android and the other is IOS), some cross-system operations (eg pause music in Android and play music in IOS) may be delayed. Please be aware that this is normal.

When paired with iOS devices, current battery level will appear on

@ F

V. Calling 1. Basic call operation

· For the optimum talking effect, please place the microphone

 How any the control of the cont the headphones or operate your phone. Please see your mobile phone manual for details.

2. Make three way call

Function	Headphone status	Operation
End the current call to answer the new incoming call	Talking, There is the second incoming call	Press the multifunction button once
Remain the current call to answer the new incoming call	Talking, There is the second incoming call	Press the multifunction button twice
Call switching	Talking (remained)	Press the multifunction button twice
End the current call	Talking (remained)	Press the multifunction button once

Function	Headphone status	Operation	
End the first mobile's call, answer the second mobile's incoming call	The first mobile is talking, the second mobile having incoming call	Press the multifunction button once	
Remain the first mobile's call, answer the second mobile's incoming call	The first mobile is talking, the second mobile having incoming call	Press the multifunction button twice	
Switch calls	Talking, a call is remained	Press the multifunction button twice	
End the current call, Return to the remained mobile	Talking, a call is remained	Press the multifunction button once	

VI. Play music

Function	Headphone status	Operation
Increase volume	Play music	Press the " + " button
Decrease volume	Play music	Press the " - " button
Last track	Play music	Press and hold the " - " button for about 2 seconds
Next track	Play music	Press and hold the " + " button for about 2 seconds
Pause play	Play music	Press the multifunction button
Resume playing	Pause playing	Press the multifunction button

next track/pause/play), please ensure your mobile phone or

VII. Clear the pairing list

- Under charging, press and hold the multifunction button and volume + button for about 5 seconds, blue light blinks six times and all the pairing lists will be cleared;
- After clearing is complete, the headphone will auto-enter pairing status when powered on again,.

VIII. Restore to factory settings

If the headphone can not be powered on after fully charged or have no reaction when used, please follow the steps below to

Connect the headphone to USB port of computer or to USB power adapter using charging cable, when the red light is lit, it means restoration of the headphone is successful.

During using, please read the following advices carefully to help you comply with warranty terms and extend the product's service

- . Keep the product away from humid places to avoid affecting
- Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and deform plastic.
- Do not put the product in cold places to avoid damaging

- to avoid damaging internal circuit.

 Do not use drastic chemicals or cleaner to clean the product.
- Do not use sharp objects to scratch product surface to avoid damaging shell and affecting appearance.

qualified maintenance agency for repair.

■ FAOs

1. Red light instead of blue light flashes swer: It indicates the headphone is in low battery level, please harge the headphone.

- 2. Red light is off during charging. Answer: a. Please ensure the charging device is correctly connected with the headphone.
- b. When the headphone is not used for long periods of time, the battery will enter sleep state. It needs to charge about 30 minutes and then the red light will be lit.
- 3. No sound heard from the headphone.
- Answer a. Check if the headphone is operating, b. Check if the headphone volume is at an appropriate level. c. Check if the headphone is correctly connected with mobile phone. d. Check if the headphone is operated within an effective distance.
- 4. The headphone calling effect is bad.
- Answer: a. Check If mobile phone is in an area with strong signal. b. Please ensure the headphone is within effective distance (10m and no obstacle between the headphone and mobile phone.
- 5. When playing music, unable to control pause/play/ previous track/next track via headphone Answer: Please ensure the paired device support AVRCP (Audio/ Video Remote Control Profile) profile.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine fire or the like



- 1. "To prevent possible hearing damage, do not listen at high
- volume levels for long periods." "Fully understand user manual before use."
- 3. "Ensure your player at low volume levels or power off before

Correct Disposal of this product. This marking indicates that this product should not be disposed with other household disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, pleasuse the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Z

WARNING!

IV. Battery level display

31 31 31 31 31 31 31

8 H

Low battery level

Danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type. For products with removable battery, the battery must be properly recycled or disposed. For products with built-in battery, disassembling is prohibited. Never disassemble, hit with force, squeeze batteries or dispose of batteries in fire. Do not expose batteries in

conductive materials, liquid, fire or heat. Do not let metal object contact two battery poles. If the battery looks swollen, leaking, discolored, having odor or any abnormal appearance, stop using it. Do not use the battery after immersed in water. Improper use of battery may lead to explosion or leakage. causing skin burn or other injuries; in the event of battery leakage, handle it with care and immediately dispose of the battery in the manner in compliance with applicable laws and regulations in your locality.

13



To guarantee your personal safety, please do not wear or keep earphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Earphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or The operation of switches on your hin's ystem or plugging in the earphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the earphones.

For traffic safety, do not use earphones while driving or cycling.

14

安全注意事項:

為保證您的人身安全,請勿將該耳機佩戴或放置在離心臟 起搏器過近的位置(小于10CM)。

請勿將插頭插入電源插座。

兒童應在成人監督下使用本設備,本產品幷非玩具。

在高音量下使用耳機——特別是長時間使用——可能會對您的聽力造成損傷。 操作高保眞音響開關或插入耳機時可能會發出尖利的聲音, 種音源或插入耳機前, 請將音量控制設置為最低。

為交通安全起見, 駕駛時或騎自行車時請勿使用耳機,

其在高音量設置下可能會影響您的聽力。因此,在切換各

Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm)

veillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet.

de provoquer de troubles de l'audition, en particulier

s'il est porté de façon prolongée Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison il faut toujours mettre le son au minimum avant de pass

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

d'une source à l'autre (radio, platine, lecteur de CD ...)

Al fine di garantire la sicurezza personale, fare attenzione che queste cuffie non siano posizionate in prossimità del proprio eventuale pace maker

(con una distanza inferiore a 10 cm). Ne pas introduire la fiche à jack dans des prises de courant. Non introdurre la spina jack in una presa sotto

Sorvegliare i bambini quando utilizzano il dispositivo. Questo apparecchio non è un giocattolo. Un casque d'écoute utilisé à un volume élevé risque

> L'utilizzo delle cuffie ad alto volume, soprattutto se prolungato, può danneggiare l'udito. Maneggiare le manopole del Vostro sistema hi-fi o inserire le cuffie quando il volume è troppo alto, potrebbe produrre dei rumori che potrebbero danneggiare l'udito, soprattutto se il volume è alto. Si consiglia pertanto di regolare il volume al minimo prima di passare da una fonte all'altra (radio, giradischi, lettore CD, ecc.) o prima di collegare le

Per la sicurezza nel traffico, si prega di non usare mai le cuffie mentre si guida o si va in bicicletta.

Peringatan!

Untuk menjamin keselamatan diri Anda, jangan memakai atau menyimpan earphone di sekitar (dekat dari 10 cm) alat pacu jantung.

Jangan masukkan steker ke stopkontak listrik. Awasi anak-anak saat menggunakan peralatan,

produk ini bukan mainan. Mendengarkan earphone pada tingkat volume tinggi – khususnya, selama waktu yang lama – dapat merusak pendengaran Anda.

enyumbatan pada earphone dapat menimbulkan klik yang pada pengaturan volume tinggi dapat memengaruhi pendengaran Anda. Karena itu, selalu mengatur kontrol volume paling endah sebelum beralih di antara berbagai sumbe

Untuk keselamatan lalu lintas, jangan gunakan earphone selama mengemudi atau berkendara.

Waarschuwing!

Om uw persoonlijke veiligheid te garanderen, dient de koptelefoon niet te worden bewaard of gedrager n de buurt van (minder dan 10 cm) een pacemaker Steek de stekker in een stopcontact.

Houd toezicht op kinderen tijdens het gebruik van het apparaat; dit product is geen speelgoed Luisteren met de koptelefoon op hoog volume – met name gedurende een langere periode – kan leiden tot schade aan uw gehoor.

De bediening van de schakelaars op uw hifisysteem of het insteken van uw koptelefoon kan leiden tot harde klikgeluiden wat uw gehoor kan aantasten.

Om deze reden dient de volumeknop altijd op een minimum te worden geschakeld, voordat er tussen de verschillende bronnen (tuner, draaitafel, cd-speler, enz.) wordt geschakeld of de koptelefoon wordt aangesloten.

Met het oog op verkeersveiligheid dient de koptelefoon niet te worden gebruikt tijdens het riiden of fietsen.

잭 플러그를 전류가 흐르는 소켓에 삼입하지 마십시오.

헤드폰을 높은 볼륨상태에서 특히 장기간 사용할 경우 청

하이파이 오디오 시스템상에서 스위치를 바꾸거나 헤드 폰을 하이파이 오디오 시스템에 연결할 경우 높은 봉품상 태에서는 청각에 해를 줄수 있는 클릭소리가 날수 있습니 다.그러므로 하이파이 오디오 시스템상의 한 소스기기에 서 다른 소스기기(라디오, 메코드 플레이어,CD-플레이어...) 를 선택하거나 헤드폰을 연결시킬 경우에는 항상 볼륨을 초저상태로 조정해 놓으십시오.

여러분의 운정상태와 다른 운전자들의 안전을 보호하기 위해 운정 중이거나 자전거를 타고 이동할 시에는 헤드폰 착용을 삼가 해 주십시오.

20

DE Sicherheitshinweis!

Um Ihre persönliche Sicherheit zu garantieren, achten Sie bitte darauf, dass dieser Kopfhörer nicht in nächster Nähe (näher als 10cm) zu Ihrem.

Beaufsichtigen Sie ihre Kinder bei der Benutzung des Geräts. Das Produkt ist kein Spielzeug.

Bei Umschaltvorgängen an Ihrer HiFi-Anlage oder bei Anschluss des Kopfhörers an die Anlage können Knackgeräusche auftreten, die bei hoher Lautstärke das Gehör beerlintfächtigen. Drehen Sie daher den Lautstärkeregler immer auf Minimum, wenn Sie

Plattenspieler, CD-Player ...) wählen oder den Kopfhörer

21

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm).

Vigile a sus hijos al utilizar el equipo. Este producto no es un

Para no poner en peligro ni su capacidad de conducir, ni la seguridad de otros usuarios de la vía pública, no utilice en

В целях гарантии вашей безопасности просим не надевать и не держать наушники вблизи

При использовании прибора присматривайте за детьми, так как это оборудование не является игрушкой

Включение и выключение переключателей на

اتحذير SA

لضمان سلامتك الشخصية، يرجى عدم ارتداء سماعات الرأس أو الاحتفاظ بها بالقرب من (أقرب من 10 سم) جهاز تنظيم

احرص على الإشراف على الأطفال عند استخدام الجهاز، فالمنتج ليس لعبة الاستماع من خلال سماعات الأذن عند مستويات الصوت العالية، خاصة على مدى فترات طويلة، قد يضر بسمعك

الصوت العالية لذلك، قم دائما بضبط زر التحكم في مستوى الصوت على الحد الأدنى قبل التبديل بين المصادر المختلفة (موالف، قرص دوار، مشغل أقراص مدمجة، الخ) أو عند توصيل سماعات الرأس من أجل السلامة المرورية، لا تستخدم سماعات الرأس أثناء

. لا تدخل القابس في مأخذ أمر بائية

تشغيل المفاتيح في نظام واي فاي الخاص بك أو إدخال سماعات الرأس قد يسبب نقرات والتي قد تؤثر على سمعك في مستويات

安全のために、このヘッドフオン-スメ-カ-の近く(10cm) 以内)で使用または保管することは避けてください。 差し込プラグをコンセントに差し込まないようにして

HIF 機器の切り替え時、あるいは機器にヘッドフオンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を与える恐れがあります。HIF 機器で各ソス(ラジオ、レコードブレーヤ、CDプレーヤ・、)を選ぶ際、あるいはヘッドフオンを接続する際には、音量のっまみを常に最少にしてください。

(penala, pemutar piringan hitam, pemutar CD, dll) atau penyumbatan pada earphone.

Advarsel!

Słuchanie w słuchawkach przy wysokich poziomach głośności, szczególnie przez długie okresy czasu, może spowodować

Dlatego należy zawsze ustawiać głośność na minimalnym poziomie przed przełączaniem między różnymi źródłami dźwięku (tunerem, gramofonem, odtwarzaczem CD itp.) lub podłączeniem słuchawek.

For at garantere din personlige sikkerhed, skal du ikke bære eller holde hovedtelefonerne i nærheden (tættere end 10 cm)

Indsæt ikke stikket i stikkontakter. Overvåde børn ved brud af udstyr, produktet er ikke ledetøi.

Driften af kontakter på din hi-fi-system eller tilslutte hovedtelefonerne kan forårsage klik der på volumen indstilling højt kan påvirke hørelsen. Derfor allti indstiller yddstyrken til minimum, før der skiftes mellem forskellige kilder (tuner, pladespiller, CD-afspiller, etc.) eller tilslutte hovedtelefonerne.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰 이 필요합니다.이 제품은 장난감이 아닙니다.

an Ihrer HiFi-Anlage zwischen verschiedenen Quellen (Radio

Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie kopfhörer keinesfalls beim Lenken eines Kfz oder beim Radfahren.

¡Atención!

Al operar los interruptores de su sistema HiFi o al conectar los aurículares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oido. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD ...) en su sistema HiFi o al conectar los aurículares.

ningún caso sus auriculares al conducir un vehículo o al andar en bicicleta.

Предупреждение!

Для безопасности дорожного движения не используйте наушники во время езды на велосипеде и вождения автомобиля.

● 安全指摘事項!

する場合において聴覚障害の原因となる恐れがありま

Ostrzeżenie!

Aby zapewnić sobie bezpiecze ń stwo, nie należy nosić ani trzymać słuchawek w pobliżu (w odległości mniejszej niż 10cm)

【】 경고!

안전상의 이유로,이 헤드폰은 심장박동 조절장치 근처 (10cm 이내)에 두어서는 안됩니다.

12

Herzschrittmacher getragen oder auf-bewahrt wird. Klinkenstecker nicht in stromführende Buchsen einführen

Die Verwendung von Kopfhörern kann bei großer Lautstärke - vor allem im Dauerbetrieb - zur Schädigung des Gehörs führen.

anschließen.

No introducir el conector Jack en los casquillos conductores

La utilización de auriculares a un volumen muy alto - sobre todo al utilizarlos durante largos períodos – puede conducir al deterioro del oído.

Прослушивание музыки через наушники на

お子様が使用になる場合は、必ず大人が付き添えって ください。本製品は玩具ではありません。

安全なドライブ、そして他の運転手の安全のためにも、 お車を運転する場合、あるいは自転車に乗る場合には ヘッドへオンは絶対に使用しないでください。

Działanie przełączników w systemie hi-fi lub podłączanie słuchawek mogą powodować mocne impulsy dźwiękowe, które przy dużej głośności mogą powodować pogorszenie

Hovedtelefon lytte ved høje lydstyrker Navnlig glæder over længere perioder - kan høreskader.

For trafiksikkerheden, ikke anvendes under kørsel eller cyklind

(ближе 10 см) кардиостимулятора. Запрещается вставлять штекер в электрические розеткі

Таким образом, всегда устанавливайте громмость на минимальный уровень, прежде чем производить переключение между различными источниками (тюнер, диск проигрывателя, СО-проигрыватель и т.д.) или подключать наушники в систему.



- to change from time to time without prior notice.
- manual may be slightly different from actual product If any difference is found, the actual product prevails
- Ver1.0 IB-200-W0285B-00

- Bluetooth transmitter supports AVRCP profile;

- Do not dismantle the product. Non-professional personnel may damage the product.
 Do not drop, strongly vibrate, strike the product with hard object

Attenzione!

Nie wkładać wtyczki do gniazdka elektrycznego. Nadzorować dzieci podczas korzystania ze sprzętu, produkt to



EDIFIER

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate reading frequency energy and, if not installed and used in accordance with the instructions, was cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

IC Caution

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause
 - undesired operation of the device.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf. Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation estautorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectrique subi, mêmesi le brouillage est susceptible d'en compromettre le fonctionnement.

IB-200-000000-08

名	称:	说明书FCC认证说明/便携式音箱及耳机		东莞市漫步者科技有限公司
材	质:	80g书纸	版面设计:	
尺	寸:	125×120 (MM)	校 对:	
版本号及料号:		V1. 0/1B-200-000000-08	批 准:	