


W288BT
Bluetooth Sport Headphone

Operating instructions

Manual Edition 1.0, Apr. 2015
IB-200-W02880-00EDIFIER TECHNOLOGY CO., LTD.
www.edifier.com
www.edifier-international.com
© 2015 Edifier International Limited. All rights reserved.
Printed in ChinaNOTICE:
For the need of technical improvement and system
upgrade, information contained herein may be subject
to change from time to time without prior notice.
Products of Edifier will be customized for different
applications. Pictures and illustrations shown on this
manual may be slightly different from actual product.
If any difference is found, the actual product prevails.

Note:

- Turn on the one with two function: Press and hold **+** and **-** keys in standby status at the same time, then loosen the keys when hearing 4 prompt tones from low to high. Turn off the one with two function: Press and hold **+** and **-** keys in standby status at the same time, then loosen the keys when hearing 4 prompt tones from high to low.
- If the ear-bud has connected two devices, the ear-bud can automatically connect the two devices when it is on again.
- If you only need to connect one phone, we advise to turn off its one with two function to improve the ear-bud using performance.

4. Communication with ear-bud

1 Basic operation

Function	Status	Operation	Prompt tone
Cancel call	Calling	Press + once	One short tone
Answer call	Incoming rings	Press + once	Two rising tones
Reject call	Incoming rings	Press and hold + for 2 seconds	Two falling tones
End call	Answering	Press + once	One short tone
Increase volume	Answering	Press + once	N/A
Decrease volume	Answering	Press -	N/A
Transfer to phone	Answering	Press and hold + for 2 seconds	One short tone
Transfer to ear-bud	Answering	Press and hold + for 2 seconds	One short tone
Microphone mute	Answering	Press and hold + for 2 seconds	Two falling tones
Cancel mute	(Microphone mute)	Press and hold + for 2 seconds	Two rising tones
Voice dial	Connected to the device	Press + and - at the same time	One short tone
Last number recall	Connected to the device	Double press +	One short tone

Note:

- When ear-bud volume is adjusted to the maximum or minimum, you will hear a prompt tone.
- When ear-bud is in mute condition, you will continuously hear a prompt tone twice per 10 seconds.
- For some phones, press its answer key to answer the incoming call, communication will firstly transmit to the phone. At this moment, you can use ear-bud's call switch function or operate on the phone to switch the call to ear-bud. Please refer to your phone manual for detailed operation.

2 Three sides communication operation

Function	Status	Operation	Operation
Answer the new call and end the current call	The second call coming	Press + once	The second call coming
Answer the new call and keep the current call	The second call coming	Double press +	Double press +
Switch the calls	Answering (keeping)	Double press +	Answering (keeping)
End the current call and transfer to the keeping call	Answering (keeping)	Press + once	Press + once

Function	Status	Operation
End the 1st phone call, answer the 2nd phone call	The 1st phone is on call, the 2nd phone has incoming call	Press + once
Keep the 1st phone call, answer the incoming call of the 2nd phone	The 1st phone is on call, the 2nd phone has incoming call	Double press +
Switch the calls	Answering one call is kept	Double press +
End the current call, return to the kept phone	Answering, one call is kept	Press + once

3 Connect two phones call

Function	Status	Operation
End the 1st phone call, answer the 2nd phone call	The 1st phone is on call, the 2nd phone has incoming call	Press + once
Keep the 1st phone call, answer the incoming call of the 2nd phone	The 1st phone is on call, the 2nd phone has incoming call	Double press +
Switch the calls	Answering one call is kept	Double press +

4. Play music

Function	Status	Operation
Increase volume	Play music	Press + once
Decrease volume	Play music	Press - once
Previous track	Play music	Press and hold +
Next track	Play music	Press and hold -
Pause play	Play music	Press 0 once
Recover play	Pause play	Press 0 once

Note:

- When ear-bud volume is adjusted to the maximum or minimum, you will hear a prompt tone.
- When ear-bud is in mute condition, you will continuously hear a prompt tone twice per 10 seconds.
- For some phones, press its answer key to answer the incoming call, communication will firstly transmit to the phone. At this moment, you can use ear-bud's call switch function or operate on the phone to switch the call to ear-bud. Please refer to your phone manual for detailed operation.

5. Maintenance

Note:

- When ear-bud volume is adjusted to the maximum or minimum, you will hear a prompt tone.
- For remote-playing control function (previous/next track/pause/resume), your phone or Bluetooth launcher needs to support AVRCP (Audio/Video Remote Control Profile).

Indicator	Status
Red and blue light blinks alternately	Pairing
Blue light blinks once per 2 seconds	Not connected to device
Blue light blinks twice per 4 seconds	Connected to device
Red light replacing blue light blinks	Low battery level

6. Restore factory settings

When charging, press and hold **+** button for approx. 4 seconds, red and blue lights blink at the same time and there are 4 prompt tones.

7. FAQs

Note:

- After restoring factory settings, ear-bud's pairing list will be eliminated. When power on ear-bud again, it automatically enters pairing mode instead of auto-connection. If need to connect to devices, please re-pair with it.

8. Specification



Note:

- In first use, you need to touch the ear-bud with phones for approximately 3 seconds. You can move away the phone when the ear-bud red/blue indicator alternatively blinks. If not, it may fail to pair.
- If the ear-bud has connected to phone, it will automatically disconnect when phone again touches the ear-bud NFC area.

Pair/connect with more devices
This ear-bud can build connection with two Bluetooth devices at the same time. When in first use, one with two functions of the ear-bud is by default; you can switch it by hand. If need to pair/connect with more devices, please follow the below steps.

- Firstly pair and connect with the 1st device.
- Restart the ear-bud and make it into pair mode, then pair and connect with the 2nd device.
- Operate on the 1st device, select to connect with this ear-bud. Then the ear-bud is connected with the 1st and the 2nd device at the same time.

安全注意事项:

为保证您的人身安全,请勿将该耳机佩戴或放置在离心脏起搏器过近的位置(小于10CM)。

请勿将插头插入电源插座。

儿童应在成人监督下使用本设备,本产品并非玩具。

在高音量下使用耳机——特别是长时间使用——可能会对您的听力造成损伤。

操作高保真音调开关或插入耳机时可能会发出尖利的声音,其在高音量设置下可能会影响您的听力。因此,在切换各种音源或插入耳机前,请将音量控制设置为最低。

为交通安全起见,驾驶时或骑自行车时请勿使用耳机。

安全指摘事項!

安全のために、このヘッドフォン-スマ-カ-の近く(10cm以内)で使用または保管することは避けてください。

差し込みプラグをコンセントに差し込まないようしてください。

お子様が使用になる場合は、必ず大人が付き添ってください。本製品は玩具ではありません。

大きな音量でのヘッドフォンの使用は、特に長時間使用する場合において聴覚障害の原因となる恐れがあります。

HIFI機器の切り替え時、あるいは機器にヘッドフォンを接続する際に、音量が大きい場合にはガリガリという騒音が発生し、聴覚に悪影響を被る恐れがあります。HIFI機器で各ソース(ラジオ、レコードプレーヤー、CDプレーヤー...)を選択する際には、音量のつまみを常に最小にしてください。

安全なドライブ、そして他の運転手の安全のためにも、お車を運転する場合、あるいは自転車に乗る場合にはヘッドホンは絶対に使用しないでください。

Conseils de Sécurité!

Pour votre sécurité, ne portez pas et ne posez pas ce casque à proximité immédiate (moins de 10 cm) d'un pacemaker.

Ne pas introduire la fiche à jack dans des prises de courant.

Surveillez vos enfants s'ils utilisent l'appareil. Ce produit n'est pas un jouet.

Un casque d'écoute utilisé à un volume élevé risque de provoquer de troubles de l'audition, en particulier si est porté de façon prolongée.

Lorsque vous procédez à un réglage sur votre installation hi-fi ou que vous branchez le casque sur l'installation, des bruits dangereux pour l'oreille peuvent se produire si le son est réglé sur un volume élevé. Pour cette raison, il faut toujours mettre le son au minimum avant de passer d'une source à l'autre (radio, platine, lecteur de CD ...) ou de brancher le casque.

Pour ne pas mettre en danger votre sécurité au volant ni celle des autres usagers de la route, n'utilisez jamais le casque lorsque vous conduisez ou que vous roulez à vélo.

Pour la sécurité nel traffico, si prega di non usare mai le cuffie mentre si guida o si va in bicicletta.

Attenzione!

Al fine di garantire la sicurezza personale, fare attenzione che queste cuffie non siano posizionate in prossimità del proprio eventuale pacemaker (con una distanza inferiore a 10 cm).

Non introdurre la spina jack in una presa sotto tensione.

Sorvegliare i bambini quando utilizzano il dispositivo. Questo apparecchio non è un giocattolo.

L'utilizzo delle cuffie ad alto volume, soprattutto se prolungato, può danneggiare l'uditivo.

Maneggiare le manopole del Vostro sistema hi-fi o inserire il cuffio quando il volume è troppo alto, potrebbe produrre dei rumori che potrebbero danneggiare l'uditivo, soprattutto se il volume è alto. Si consiglia pertanto di regolare il volume al minimo prima di passare da una fonte all'altra (radio, giradischi, lettore CD, ecc.) o prima di collegare le cuffie.

For traffic safety, do not use headphones while driving or cycling.

Warning!

To guarantee your personal safety, please do not wear or keep headphones in the vicinity (closer than 10cm) of a pacemaker.

Do not insert plug into electric sockets.

Supervise children when using the equipment, the product is not a toy.

Headphone listening at high volume levels – particularly, over extended periods of time – may damage your hearing.

The operation of switches on your hi-fi system or plugging in the headphones may cause clicks which at high volume setting may affect your hearing. Therefore, always set the volume control to minimum before switching between different sources (tuner, turntable, CD player, etc.) or plugging in the headphones.

For traffic safety, do not use headphones while driving or cycling.

Sicherheitshinweis!

안전상의 이유로,이 헤드폰은 심장 박동 조절 장치 근처(10cm 이내)에 두어서는 안됩니다.

제 플러그를 전류가 흐르는 소켓에 삽입하지 마십시오.

어린이가 헤드폰을 사용할 때는 보호자의 주의 깊은 관찰이 필요합니다.제 제품은 장난감이 아닙니다.

헤드폰을 높은 볼륨 상태에서 특히 장기 사용 경우 청각에 해가 될 수 있습니다.

하이파이 오디오 시스템에서 스위치를 바꾸거나 헤드폰을 하이파이 오디오 시스템에 연결할 경우,높은 볼륨 상태에서는 청각에 해를 줄 수 있는 클릭소리가 날수 있습니다.그러므로 하이파이 오디오 시스템과의 접속 시에는 다른 소스기기(라디오,레코드 플레이어,CD 플레이어...)를 선택하거나 헤드폰을 연결 시킬 경우에는 항상 볼륨을 조절 상태로 조정해 놓으십시오.

여러분의 운전상태와 다른 운전자들의 안전을 보호하기 위해 운전 중이거나 차전거를 타고 이동할 시에는 헤드폰 작용을 삼가 해 주십시오.

Um Ihre Fahrtüchtigkeit und die Sicherheit anderer Verkehrsteilnehmer nicht zu gefährden, verwenden Sie Kopfhörer keinesfalls beim Lenken eines Kfz oder beim Radfahren.

Atención!

Por su propia seguridad, procure no llevar ni guardar estos auriculares muy cerca de su marcapasos (a menos de 10cm).

No introducir el conector Jack en los casquillos conductores de corriente.

Asegúrese de sus hijos al utilizar el equipo. Este producto no es un juguete.

La utilización de auriculares a un volumen muy alto – sobre todo al utilizarlos durante largos períodos – puede conducir al deterioro del oído.

Al operar los interruptores de su sistema HiFi o al conectar los auriculares al sistema puede hacer clic, lo que a un volumen muy alto puede deteriorar el oído. Por lo tanto disminuya el nivel de volumen al mínimo al seleccionar entre diferentes fuentes (radio, tocadiscos, reproductor de CD...) en su sistema HiFi o al conectar los auriculares.

Para no poner en peligro ni su

EDIFIER

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Caution

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :
(1) Ce dispositif ne peut causer d'interférences ; et
(2) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

IB-200-000000-05

名 称:	说明书FCC认证说明		东莞市漫步者科技有限公司
材 质:	80g书纸	版面设计:	
尺 寸:	125×120 (MM)	校 对:	
版本号及料号:	V1.1/IB-200-000000-05	批 准:	