Bluetooth® pressure sensitive stylus

*Jot touch

WORLD'S SMARTEST STYLUS iPad 2 | New iPad

Pressure Sensitivity

Not all lines are created equally. Jot Touch reacts to the amount of pressure you apply to deliver more accurate interpretations of your strokes.

Shortcuts

Get to software tools quickly. Switch to your eraser with the flick of a finger. Minimize your navigation. Maximize your creation.

Bluetooth® Connect

Easily pairs with Bluetooth-ready devices. Once connected, it gives you more tools like Pressure Sensitivity and Shortcuts.

Stay Juiced

meet

vour

Plug the USB charger into your computer, tablet, or iPad / iPhone charger to replenish Jot Touch and keep those creative juices flowing.

Precision Everywhere

Even if the app isn't setup to read pressure input, you're still using the most precise stylus on the market. Jot Touch's precision disc works naturally with any app on any touch screen: iOS, Android, and Windows.

Jot Ready Apps

Sketchbook Pro, Procreate, ArtRage, Sketch Club, Clibe, GoodNotes. More apps at http://adonit.net/ product/jot-ready-apps/

In the Box

Jot Touch, USB charging Dock, Precision Disc, Replacement Tip and Instructions

~adonit

www.adonit.net

保証期間:1年間 ※購入履歴(レシート/領収書) を保存してください。 Patents Pending







JP

感圧センサー

すべての線が同じ幅というわけ ではありません。Jot Touchは 筆圧を感知して更にあなたのタ ッチを正確に表現します。

※対応ソフトウェアが別途必要になります。

ショートカット

ソフトウェアのツールを使用するのに便利なショートカットキー搭載。消しゴムなどの機能をかんたんに指先だけで操作できます。

Bluetooth®接続

かんたんにBluetooth搭載機器 とペアリングできます。接続が 完了すると便利なツールやショ ートカット等を使用できます。

どこでも充電

付属のUSB充電ドックをパソコンのUSBポートやタブレット、 iPad、iPhoneなどの充電器に 接続してJot Touchを充電でき ます。

どこでも使える

アプリが感圧センサーに対応していない場合でもJot Touchは普通のスタイラスとして使用できます。ディスクのおかげで、あらゆる静電式タッチスクリーンのIOS、Android、そしてWindows機器で快適に使用できます。

Jot Ready Appsの紹介 Sketchbook Pro, Procreate, ArtRage, Sketch Club, Clibe, GoodNotes, 詳細は

ArtRage, Sketch Club, Clibe, GoodNotes. 詳細は http://adonit.net/product/ jot-ready-apps/

同梱品

本体、USB充電ドック 交換用ディスク、取扱説明書

で使用前にお誘うください/ ディスの全面が発量ディスプレイに 触れるように操作してください。 キャスの上の一般ではないでは、 キャスのリタの部分で急性をすると、 画面の、機体や動かつく恐れがありま すのでご注意ください。 製品の使用時に存出した他性機器の 被陥まなびトラブルに関して当社は 切り責任とあいなまま。まない で使用中のスクリーン画面は実に 腫匠して本製品をで使用ください。 で使用中のスクリーン画面は実に 動

ディスクを紛失しないようにご注意 ください。

プリンストン テクノロジー株式会社 = 101-0032

〒101-0032 東京都干代田区岩本町3-9-5 K.A.Lビル3_年 電話: 03-6670-6848 製品の詳しい情報に関しては、 下記WF Bページをご確認ください。

www.princeton.co.jp

2 266



本無線機の本体には、電波法に基づく技術基準適合証明(もしくは工事設計認証)を取得した表示をしています(全) 技適マークかついています)。

WE EMPOWER THE
THINKERS, DOERS, AND
MAKERS TO BUILD A
MORE VIBRANT WORLD.
IF YOU ARE NEVER
SATISFIED BY WHAT IS,
BUT IMAGINE WHAT
COULD BE, THEN YOU
ARE ONE OF US.

YOU ARE THE

Creative.

Jot Touch Glossary

各部名称

EN

1. Precision Disc

Mimics the capacitance signature of your finger while allowing you to see exactly where you're drawing

2. Pressure Sensitive Tip

3. Button A

4. Power Button Power On / Off and

Bluetooth pairing

5. Button B Shortcut Button

6. Indicator Light
Notifies you of Bluetooth
connection, battery level,
and when charging

7. Charging Tip

Charging Tip sits on USB charger

8. USB charger

Plugs into any USB port

9. Protective Cap Twists on to front and back

Replacement Tip Located behind instruction manual JP

-2

1.導電性ディスク

先端に透明ディスクを採用。 アイデアをそのまま正確に 画面に伝えることができま す。

2. 感圧センサー

3. Aボタン

ショートカットボタン

4. 電源ボタン (AとBボタンの同時押し) 電源オン/オフ Bluetoothペアリング

5. Bボタン

ショートカットボタン

6. インジケーターランプ

Bluetooth接続状態、バッテリー残量、充電状態を表示します。

7. 充電コネクター

充電時にUSB充電ドックへ 接続します。

8. USB充電ドック

USBポートへ接続します。

9. 保護キャップ

ねじ込み式のキャップで先端ディスク部分を保護します。使用時は外してペン後部へ装着できます。

交換用の導電性ディスクと感 圧センサーは取扱説明書の裏 にあります。



Getting Connected

接続方法

ΕN

Bluetooth Pairing

- 1. On your device, navigate to Settings > General > Bluetooth, then turn on Bluetooth.
- 2. Without touching the tip of the stylus, press and hold the power button in the grip area.

 Touching the disc will incorrectly calibrate Jot Touch to it's zero position. If pressed simply shut off and restart.
 - Continue holding until you see the red / green flashing.
 - 4. Select Jot Touch after it appears in the list of pairable items in your device's settings
 - 5. Once selected, enter the pin "0000" to confirm your pairing with the correct device.
 - 6. Once successfully paired, the indicator light will flash green and the device settings will show that Jot Touch is connected.
 - 7. If unsuccessful, the indicator light will flash red.
 - 8. If this happens, please turn Jot Touch completely off and restart the sequence.
- To turn your Jot Touch off, press and hold the power button until the indicator light flashes red.



Bluetoothペアリング方法

- 接続する機器のBluetooth 設定からBluetooth機能を オンにしてください。
- 2. 電源ボタンを長押しして電源を入れます。(AとBボタンの同時押し) ※この時先端のディスク部分を触らないでください。触っ しまった場合は電源を落として再度やり直してください。
- インジケーターランプが赤 /緑に点滅するまで電源ボタ ンを長押しし続けてください。
- 4. 接続する機器のBluetooth ペアリングリストに表示され たらJot Touchを選択して ください
- 5. パスキーの入力が必要な場合は「0000」を入力してください。 ※接続する機器によってはパスコードの入力が必要の無い場合もあります。
- 接続が完了したらインジケーターランプが緑に点滅します。
- 接続に失敗している場合は、 インジケーターランプが赤で 点滅します。
- 8. 接続に失敗した場合は、Jot Touchの電源をオフにして 最初の手順からやり直してく ださい。
- 9. Jot Touchの電源をオフに するにはインジケーターラン ブが赤く点滅するまで電源ボ タンを長押しし続けてくださ い。

Charging / Powering up

充電方法/電源の入れ方

Charging the Battery

When your Jot Touch needs charging, simply plug your provided adaptor into any standard USB connection, following these instructions.

- 1. Place the rear of the stylus on the open contacts of the charger; it should attach magnetically, and adhere firmly.
- 2. Jot Touch's indicator light will turn on, either red or green.
- 3. Red indicates that the Jot Touch is charging, but that charge value is below 90%.
 - 4. Green indicates that Jot Touch is fully charged.

Powering Up

- 1. Without touching the tip of the stylus, press and hold the power button, until the indicator light flashes green.
 - 2. The green indicator light should flash again once a successful connection has been made with the device.

Jot Touchを充電するには、 付属のUSB充電ドックをUSB ポートに接続し以下の手順を おこなってください。

- 1. Jot Touch後部の充電コネ クターを充電ドックに接続 します。マグネット式なの でかんたんに接続できます。
- 2. Jot Touchのインジケータ ーランプが赤か緑に点灯し
- 3. 充電が90%以下の場合は 赤のランプが点灯します。
- 4. 満充電になると緑に点灯し ます。

電源の入れ方

ペアリング済みのデバイスと 再度接続する場合。

- 1. 電源ボタンを長押しして電 源を入れます。(AとBボタ ンの同時押し) ※この時先端のディスク部分を触らないでください。 触ってしまった場合は電源 をオフにして再度やり直し
- 2. インジケーターランプが緑 色に点滅し機器との接続が 完了します。

充電方法

Resetting / Maintenance

リヤット/メンテナンス

Resettina

1. Turn your Jot Touch off. 2. On your device,

navigate to Settings > General > Bluetooth, then turn on Bluetooth.

- 3. Touch the small right arrow next to 'Adonit Touch', then tap 'Forget this Device', and finally touch 'OK'.
- 4. Turn your Jot Touch on, and repeat the connection process.



リセット

- 1. Jot Touchの電源をオフにし
- 2. 接続する機器のBluetooth設 定からBluetooth機能をオン
- 3. 接続する機器のBluetooth設 定のリストに表示された Jot Touchを選択し「このテバイスの登録を解除」をタップして登録を解除してくださ
- 4. 再度Jot Touchの電源を入れ てBluetoothのペアリングを

Battery

The non-replaceable battery in Jot Touch will provide you with up to 12 hours of constant use. When it needs to recharge, the indicator light will flash red every 15 seconds when the battery's capacity reaches 10%.

Cleaning Jot Touch does not like water, so don't go swimming with it. If you need to clean Jot Touch, please use a slightly damp cloth. Do not attempt to open the stylus, as there are no serviceable parts inside.

Removing the disc

To remove the disc. grip it firmly and pull it directly out of the stylus. Do not twist it or pull it at an angle, as damage to the pressure mechanism may result.



バッテリー

Jot Touchの内蔵バッテリーは 一回の充電で約12時間使用可能

一 回。 です。 バッテリーの残量が10%以下に ニュー マンジケーターランプが なると、インジケーターランプが 赤く15秒間隔で点滅します。



クリーニング

Jot Touchは防水ではありません ので水につけて洗うことはできま せん 汚れてしまった場合は、固く絞っ

た湿った布で拭いてください。 スタイラスを分解しないでくださ



ディスクの取り外し方

ディスクを取り外す際は、グリッ プをしっかりと握って垂直に引い て抜いてください。 捻ったり、斜めに引き抜かないで ください。感圧センサーの破損な

どの原因になります。



Jot Ready Apps

EN

Jot Ready

Although Jot Touch works with any app, some apps have been calibrated for a smart stylus rather than a finger. 'These apps have integrated Adonit's Jot Ready SDK (Software Development Kit), so when they are used with Jot Touch it provides the best stylus experience on the market.

Precision

Tablets have been calibrated for fingers. Jot Ready changes that calibration to accommodate a precision stylus.

Pressure Sensitivity

Jot Ready changes the screen's detection to determine how hard you're pressing in any location.

Shortcuts

Jot Ready adds convenient buttons to get you to the tools you need quickly.



Jot Readyとは

Jot Touchはどんなアプリでも一緒に使うことができます。一緒に使うことができます。 対応アプリでは指よりも高性能なスマートスタイラスの使用を前提 に設計されています。 それら対応アプリはAdonit社の Jot Ready SDK (ソフトウェー 開発キット) に集積されており、 それらとJot Touchを組み合わ せればもっとも優れたスタイラス を体験できます。





タブレットは指での使用を前提と しています。Jot Readyはそれ らを精度の高いスタイラスを使用 できるタブレットに変更します。

感圧センサー



Jot Readyはスクリーン上でど のくらいの筆圧で描かれているか を検知する機能を追加できます。

ショートカット



Jot Readyで便利なショートカットボタンを追加することができます。

of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation, This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures. Repriet or relocate the receiving antenna, Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio, TV technicain for help. Any changes or modifications not expressly approved by the party responsible for compliance could would be user's authority to operate the equipment. This device and its antennals; must not be occlosed or operating in conjunction with any other antenna or transmitter. This device and is antennals; must not be occlosed or operating in conjunction with any other antenna or transmitter. The device complete such that the fact of the following two conditions: (1) The device may not cause harmful interference.

WELCOME TO THE STYLUS REVOLUTION.

WE WANT TO SEE WHAT YOU CREATE. SHARE YOUR JOT CREATIONS. SEE WHAT OTHERS CREATE.

WWW.FACEBOOK.COM/ADONITFB





SketchBook Pro

Autodesk



Autodesk SketchBook Pro for iPad is a professional-grade paint and drawing application. Using the same paint engine as its desktop counterpart, SketchBook Pro delivers a complete set of sketching and painting tools through a streamlined and intuitive user interface designed exclusively for the iPad experience.

Features

Retina Display on 3rd Gen iPad High Quality Brushes & Tools:

- Professional grade paint engine delivers smooth and precise brush strokes
- More than 60 preset brushes, including pencils, pens, markers and natural media
- Install more than 90 additional brushes and stamps brushes from the in-app Store
- the in-app Store

 Completely customizable brush
- settings for each brush
 Pressure sensitivity (brush fade-off)
- Undo/Redo 10 levels Gen 1 iPad 1; 20 levels iPad 2; 30 levels 3rd gen iPad
- · Dynamic symmetric drawing

Layers:

- · Import images from Photo Library
- · Duplicate, Merge & Reorder Layers
- Move, scale, and rotate layers
- interactively using Multi-Touch

 Layer Blend Modes: Multiply, Add,
- Preserve Transparency mode to paint only where paint already exists

Video Output

Screen and Normal

Gallery:

- Store and view work-in-progress
- · Import/Export as a layered file (PSD)
- Import/Export via iTunes File Sharing or Dropbox
- · iCloud support









Express your artistic side with easy to use painting and drawing tools that work just like the real thing! ArtRage packs a powerful physical paint simulation into a creative experience tailor-made for your iPad, and with a stylus it feels even more like using a real brush on a real canvas. Explore a powerful and intuitive environment that lets users of all levels work with a wide range of natural painting and sketching tools.

Features

Real World Painting Tools:

- High quality strokes respect the volume of paint on the canvas, letting you play with texture as well as color.
- Oil Brush with thickness and smearing.
- Watercolor tracks tool and paper wetness as you paint.
- Airbrush
- Palette Knife for spreading and blending pigment.
- · Paint Roller & Paint Tube.
- Inking Pen with auto-smoothing and pressure simulation.
- · Pencil & Eraser.
- · Marker Pen.
- · Chalk & Crayon.

Recording:

 Record your paintings, export the recording and play it back in a desktop version of ArtRage Studio or Studio Pro to recreate your art at higher resolution!

Layers:

- Unlimited layers.
- Blend Modes including all Photoshop standards.
- · Easy access to visibility/opacity.
- Preservation of transparency.
- Layer transformations.

Utilities:

- · Unlimited Undo / Redo.
- · Reference & Tracing Images.
- Unlimited color samples.

artrage.com









Get the most out of your new Jot Touch.

Whether storyboarding the next Hollywood blockbuster, illustrating a children's book, or just having fun, Procreate will put you into a league of your own.

- Over 45 pro brushes
- Up to 16 HD layers
- 100 undo/redo states
- Multi-touch gestures
- Precision sliders
- Deep 48-bit colour
- Silica™ paint engine
 - Full retina support

iPad is a registered trade mark of Apple Inc, registered in the U.S. and othe countries. Procreate is a trademark of Savage Interactive Pty Ltd.







JOURNALING IS SOCIAL

"I was sitting here" by Carles Lopez, Barcelona Spain



Clibe





Clibe is a simple and beautiful social journaling app with a collaborative space for sharing your creative talent or next big idea. With tools to sketch, paint, write, add and mainpulate photos, you can keep notes, hatch a project or create a photo or travel journal. All uniquely handcrafted by you.

Drop in photos from Instagram, Facebook, Evernote, and Dropbox.

Natual inking for drawing and writing with palm detection.

Browse the artist gallery and follow the journals that inspire you the most. Make your journals public, share them with select individuals, or keep them private.

Share your pages via email, facebook and twitter.

Explore the marketplace for new journal covers, page templates and fun stickers.



myClibe.com

3 **273** JOTT-RD