

# SOUNDPIPE Bluetooth Speaker for iPad, iPhone and Smartphone

## Instruction Manual




#### Speaker




- Insert 4 AAA batteries (not included).
- Slide the battery cover latch to release the battery cover.
- Remove batteries when not using speaker for a long period of time.

#### **Setup Instructions**


- 1. Place 4 fresh AAA batteries in the speaker, or use the AC adapter to connect the speaker to a power outlet.
- 2. Slide the power switch to the "ON" position.
- 3. The LEDs on the top of the speaker will glow "On"



#### Components



## Connecting speaker




## Pairing with a Bluetooth enabled Audio Visual device like: iPad, iPhone, smartphone and etc.

- 1. Press the "Pick-up" switch on top of the speaker for more than 3 seconds or press and hold the "Pick-up" button on the remote control to enter pairing mode.
- 2. The LEDs will begin flashing slowly, signaling that the Bluetooth speaker (Device ID: SB-1) is ready to be discover by your Bluetooth enabled device.
- 3. The password for pairing is "0000".
- 4. Please refer to your device manual to enable Bluetooth, discover new device and set as wireless stereo.
- 5. When pairing is successful the LEDs will blink quickly and stop.
- 6. Make sure the device remain within 20 ft of the SoundPipe speaker.


## Using the Soundpipe as a speaker phone.

- 1. Power up the SoundPipe and pair it with a Bluetooth enabled mobile phone.
- 2. To answer an in-coming call, press the "Pick-up" push button switch or on the remote control.
- 3. To reject or hang-up a call, press the "Drop-call" push button switch or on the remote control.

#### Speaker



#### Remote control



#### **Trouble Shooting**

Distortion or poor sound quality

: 1. Original music is distorted

2. Volume is too high

Solution: 1. Check original music before downloading to iPod

2. Adjust volume

Sound volume is not consistent

: 1. Audio plug or iPod connector is dirty

2. Poor quality music

Solution: 1. Clean audio plug or iPod connector

2. Reload music

Cause : 1. Power is not on

3. iPod does not set on dock firmly

4. Battery is dead when using battery

Solution: 1. Turn power on

2. Set volume higher

3. Check iPod position

4. Replace battery

Congratulations on your purchase! Soundpipe products come with a 180-days limited warranty from the date of purchase from an authorize retailer.

Soundpipe warrants this product to be free from any material or workmanship defect but is not liable for damages due to misuse or improper care and maintenance.

Please visit this website for more warranty information :

#### www.skasystems.com

#### Specifications:

Output Power: 5.6 Watts (2\*2.8 Watts) Frequency Response: 100 Hz to 20k Hz

Input Impedance: 4kΩ Distortion: ≤0.7%

S/N: 55dB

AC Adapter: 110V to 240V, 50/60 Hz,

Power Supply: 4 AAA batteries or AC adapter Bluetooth Technology: V2.1 + EDR Class 2

Interface Support: HFP, HSP, A2DP, AVRCP

Dimensions: 8 in (L) x 1 ¾ in (W) x 1 ¾ in (H)

Remote Control Distance: 10ft

Certificate: FCC, CE

FCC ID: ZD2SB-1

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipments.