
FCC ID Label Location



KS10, KS11, KS12, KS13, KS14, KS15, KS16, KS17, KS18, KS19, KS20, KS21, KS22, KS23, KS24, KS25, KS26, KS27, KS28, KS29, KS31, KS32, KS33, KS34, KS35, KS36, KS37, KS38, KS39, KS40, KS41, KS42, KS43, KS44, KS45, KS46, KS47, KS48, KS49

