SmartStand C4i User's Manual

[Name of apparatus] SmartStand C4i (FM Transmitter, Hands-free)

[Name of certified company] UBIMATE

[Manufacturer/ Contury] UBIMATE / KOREA

FCC notice to users and product statements

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. Operation is subject to the following two conditions; (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

C€1177 **①**

European CE notice to user and product statements
This product is CE marked according to the provisions of the
R&TTE Directive(99/5/EC). Hereby, UBIMATE declares that
this product is in compliance with the essential requirements
and other relevant provisions of Directive 1999/5/EC.
For further information, please contact http://www.ppyple.com

[Features]

■ Dimension: 115(L) x 65(W) x 79(H)mm

■ Weight: 50g without accessories

■ Power: DC 5V

■ RF Power: less than 500uV/m

■ Radio Frequency Range: 88.1MHz ~ 107.9MHz

■ Audio Response: 40Hz ~ 15kHz(ALC off)

■ Operating Temperature: 0 ~ 55°C

[Functions and Directions for Use]

■ Power Supply in 5V power in the micro USB socket.

■ Connection Cradle the smartphone for charging and/or connect the audio cable of this product into earphone socket of smartphone.

■ Frequency Press the + - buttons to set the FM Frequency.(88.1MHz ~ 107.9MHz)

Setting Turn on the power of the FM radio and set the frequency as in C4.

■ MODE With smartphone cradle, press M button to change frequencies.

Without smartphone the time will set with M button 1-2 seconds pressed.

■ Save Frequen- Up to 4 frequencies can be stored, and the frequencies are preset upon shipment.

cy Set the frequency using + - buttons.

Press M button for 1 to 2 seconds, and the number 1 will brank on the top of the display.

Press the + - buttons to select the frequencies in the slot numbers 1 throuth 4 and press M button briefly to save the selection.

The frequencies will move from 1 to 4 each time the M button is pressed.

[Caution for Safety]

- product related May cause breakage or damage.
 - Do not store under direct sunlight or where the temperature is too high or too low.
 - Do not drop or place metals (hair pins) or flammable substances in the interior of the product.
 - When the product becomes wet due to rain(water), drink, chemicals, or cosmetics, immediately disconnect from DC power and dry with a towel. Seek help from a customer service representative.
 - Never disassemble, repair, or remodel.
 - Do not use chemicals or detergents, for they may cause discoloration of the surface.
 - Do not drop the product or apply excessive shock (excessive vibration).
 - Do not press more than 1 key simultaneously.

Miscellaneous May cause injury, breakage, or damage.

- Stop use or lower volume when you hear an echo.
- Do not use at high volumes for long periods.
- Remove battery when not in use for long periods.
- Do not touch the connection area with wet hands.
- Do not keep in vehicle for long periods.
- Do not use in areas with excessive dust or humidity.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is con-nected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

IMPORTANT NOTE:

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IMPORTANT Safety Instruction:

CAUTION

To reduce the risk of electric shock, do not remove the top cover (or the rear section). No user serviceable parts inside, refer servicing to qualified personnel.



This symbol, wherever it appears, alerts you to the presence of uninsulated dangerous voltage inside the enclosure-voltage that may be sufficient to constitute a risk of sock.



This symbol, wherever it appears, alerts you to the important operating and maintenance instructions in the accompanying literature. Please read the manual.

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this equipment near water.
- 6) Do not using near any heat sources such as radiators, heat resisters, stove, or other equipment that produce heat.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

CONTACT INFORMATION

Manufacturer Address: 3F, 363-7, Songnae-dong, Sosa-gu, Bucheon-city, Gyeonggi-do, Korea

To locate in-country UBIMATE distributors of the C4i, please refer to the UBIMATE Website http://www.ubi-mate.com These distributor(s) represent local contacts for this product.

CORPORATE HEADQUARTERS:

UBIMATE

3F, 363-7, Songnae-dong, Sosa-gu, Bucheon-city, Gyeonggi-do, Korea

Tel: 82-70-7123-5891

Fax: 82-70-7016-1230

Web: http://www.ubi-mate.com

EUROPEAN UNION "DECLARATION OF CONFORMITY"

DECLARATION OF CONFORMITY

UBIMATE

3F, 363-7, Songnae-dong, Sosa-gu, Bucheon-city, Gyeonggi-do, Korea

declare under our sole responsibility that the product(s)

FM Transmitter - C4i

to which this declaration relate(s) is in conformance with the following standards:

EN 301 489-1 V1.8.1:2008

EN 301 489-9 V1.4.1:2007

EN60950-1:2006

EN 301 357 V1.4.1:2007

following the provisions of the 1999/5/EC Directives.