



## Bluetooth V4.0

Use Manual

## Bluetooth Headset Model:BH803



## LANYA ELECTRONIC Co., Ltd.




- 1.charging voltage:5V
  - e:5V 2.charging current:75-80Ma
- 3.charging time:15.-2h
- 4.full charge current voltage:4.1-4.2v



Bluetooth wireless connect

## Appearance



1.power on:press and hold multifunction key for 3s,the blue light

-2-

- 2.power off:press and hold the multifunction key for 3s until headset beeps and the red light flash 3 times.
- 3.pair headset:make sure headset is turn off.put the multifunction key 7s until headset beeps ,blue and red light start alternate flashing. open your mobile phone bluetooth to search and connect.
- 4.NFC pair:standby mode,put headset NFC site touch with mo-bile phone NFC site the bluetooth will automatic connect. (note:mobile phone need have NFC function)
- 5.answer calls:press the multifunction key to answer calls,the blue light flash 2 times every 2s.
- 6.end calls:press the multifunction key to end calls.

start to flash 3 times and headset beeps.

- 7.refuse calls:press the multifunction key 3s refuse the call and headset beeps.
- 8.volume+:press volume+ button to increase the volume. (max voice headset beeps)
- 9.volume-:press volume- button to reduce the volume. (min voice headest beeps)
- 10.switch the call between phone and headset:
- during a conversation, press and hold the multifunction key 3s until the headset beeps, the call will be transferred to you phone.

if you want transfer the call to the headset use the same way.

-3-

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.