BOM LIST

F	1 1 1	4G SK6617AB配MT29F32G08CBA CA或H27UBG8T2ATR-BC
128MHz FBGA84_0D8 U2, U3 MT29F32G08CBACA 或 MT29F32G08CBABA 或 H27UBG8T2ATR BC TS0P48(详见flash support list) KK6617AB 或 KK6633BB LGA-53 U5 RT8188 USB WIFI模块 J12 RT9169-18PVL S0T23 U18	1	SK6617AB配MT29F32G08CBA CA或H27UBG8T2ATR-BC
BC TSOP48(详见flash support list) 4 SK6617AB 或 SK6633BB LGA-53 U5 5 IC 6 RT8188 USB WIFI模块 J12 7 RT9169-18PVL SOT23 U18	1	SK6617AB配MT29F32G08CBA CA或H27UBG8T2ATR-BC
5 IC 5 IC 6 RT8188 USB WIFI模块 7 RT9169-18PVL SOT23 U18		CA或H27UBG8T2ATR-BC
6 RT8188 USB WIFI模块 J12 7 RT9169-18PVL S0T23 U18	1	SK6633BB配MT29F32G08CBA
7 RT9169–18PVL S0T23 U18	1	BA
	1	
8 RT9169-12PVL SOT23 U20	1	
9 LM4890 MS0P8 U603	1	
10 MP3202DJ TS0T23-6 U10	1	
11 MP2602 QFN10 U23	1	
12 SY8008B/RT8024/PAM2312 SOT23-5 U9, U11, U12, U13	4	
13 RK100 SOP8 U7	1	
14 12M S5032A ±10ppm 10pF Y1	1	
15 晶振 32.768kHz S3215 ±10ppm 10pF Y2	1	
FB 120R@100MHz 0402 FB5, FB6, FB7, FB8, FB9, FB10, FB11, FB12, FB13, FB18, FB26, FB27, FB29	FB16 14	
17 磁珠 FB 120R@100MHz 0603 FB17, FB19, FB20, FB22, FB23, FB28	6	
18 FB 120R@100MHz 0805 FB606	1	
19 LED指示灯 LED RED LED0805 D8	1	
20 _{肖特基二板} 5819 SMD0805 D1	1	
21 管 CRS08 SMD1206 D10	1	
22 ESD二极管 ESD二极管 ESD9B5V D0402 ESD1, ESD2, ESD3, ESD4, ESD5, ESD24, ESD25, ESD SD29, ESD31, ESD32, ESD33	26, E 12	
23 ESDA6V8UF S0T23-6 Q19	1	
24 MOS管 P-MOS, WPM3401 SOT23 Q2, Q5, Q10, Q16, Q17, Q20	6	
25 N-MOS H N-MOS, KBM2302CA SOT23 Q12, Q13	2	
26 UMBT3904L SOT23 Q1, Q3, Q4, Q6, Q7, Q11, Q15	7	
27 — MMBT3906 S0T23 Q18	1	
28	1	
29 CHIP RESISTOR 33R*4 0402 ±5% RN1, RN2, RN3, RN4, RN5, RN6, RN7	7	
30 CHIP RESISTOR OR 0402 ±5% R13, R24, R34, R35, R36, R37, R38, R39, R45, R48, R67, R75, R81, R171, R177, R229, R231, R237	R66, 23	
31 CHIP RESISTOR OR 0402 ±5% FB3, FB4	2	
32 CHIP RESISTOR 10R 0402 ±5% R1, R3, R169	3	
33 CHIP RESISTOR 15R 0402 ±1% R84, R170	2	
34 CHIP RESISTOR 33R 0402 ±5% R85, R115, R186, R190, R191, R230, R235, R236	8	
35 CHIP RESISTOR 44.2R 0402 ±1% R76	1	
36 CHIP RESISTOR 75R 0402 ±1% R182	1	
37 CHIP RESISTOR 100R 0402 ±5% R222, R225	2	
38 CHIP RESISTOR 330R 0402 ±5% R77	1	
39 CHIP RESISTOR 470R 0402 ±5% R167, R168	2	
40 CHIP RESISTOR 1K 0402 ±1% R47, R52	2	
41 CHIP RESISTOR 1K 0402 ±5% R55, R60, R193	3	
42 CHIP RESISTOR 2.2K 0402 ±5% R194, R195, R217	3	

_	ī		1		
43		CHIP RESISTOR 2.32K 0402 ±1%	R176	1	
44		CHIP RESISTOR 4.7K 0402 ±5%	R56, R57, R58, R59, R102, R103, R219	7	
45		CHIP RESISTOR 4.99K 0402 ±5%	R113	1	
	贴片电阻		R2, R4, R5, R8, R9, R10, R11, R12, R16, R17, R40, R41, R 42, R43, R44, R53, R54, R61, R62, R63, R68, R72, R79, R		
46		CHIP RESISTOR 10K 0402 ±5%	86, R91, R92, R100, R110, R111, R159, R179, R180, R18	43	
			1, R183, R184, R185, R210, R211, R212, R220, R223, R2		
			24, R228		
47		CHIP RESISTOR 20K 0402 ±5%	R173, R206, R207, R208	4	
48		CHIP RESISTOR 33K 0402 ±5%	R197	1	
49		CHIP RESISTOR 47K 0402 ±5%	R6, R175	2	
50		CHIP RESISTOR 64.9K 0402 ±1%	R89, R93	2	
51		CHIP RESISTOR 90.9K 0402 ±1%	R112	1	
52		CHIP RESISTOR 100K 0402 ±5%	R7, R69, R70, R78, R83, R97, R98, R99, R158, R160, R18	19	
52		CHIF RESISION 100K 0402 ±5%	7, R188, R189, R192, R196, R199, R200, R203, R221	19	
53		CHIP RESISTOR 143K 0402 ±1%	R80	1	
54		CHIP RESISTOR 215K 0402 ±1%	R95	1	
55		CHIP RESISTOR 301K 0402 ±1%	R82, R90, R94, R96	4	
56		CHIP RESISTOR 499K 0402 ±5%	R178	1	
57		CHIP RESISTOR 332K 0402 ±1%	R74	1	
58		CHIP RESISTOR 1M 0402 ±5%	R64	1	
59		CHIP RESISTOR 1M 0402 ±1%	R73	1	
60		CHIP RESISTOR 10M 0402 ±5%	R65	1	
61		CHIP CAP 5pF 0402 ±5%	C9	1	
62		CHIP CAP 10PF 0402 ±5%	C115, C221	2	
63		CHIP CAP 22PF 0402 ±5%	C56, C57, C58, C59, C109, C117, C120, C123	8	
64		CHIP CAP 33pF/25V 0402 ±5%	C202	1	
65		CHIP CAP 47PF 0402 ±5%	C220	1	
			C11, C14, C16, C19, C22, C25, C34, C36, C39, C41, C44,		
66		CHIP CAP 0.01UF 0402 ±5%	C47, C67, C68, C71, C84, C85, C86, C102, C103	20	
			C1, C2, C3, C4, C5, C6, C8, C10, C12, C13, C15, C17, C18		
			, C20, C21, C23, C24, C26, C27, C28, C33, C35, C37, C38		
67		CHIP CAP 0.1UF 0402 ±5%	, C40, C42, C43, C45, C46, C48, C54, C61, C63, C64, C65 , C66, C72, C74, C76, C78, C79, C81, C82, C83, C88, C90	64	
			, C92, C94, C96, C98, C100, C101, C104, C128, C133, C1		
	贴片电容		81, C183, C205, C206, C207, C208, C217, C223, C225		
68		CHIP CAP 0. 39UF 0402 ±5%	C216, C234	2	
		CUITO CAD. AND CACO. CO. CO.	C29, C30, C31, C32, C75, C113, C116, C127, C129, C191	10	
69		CHIP CAP 1UF 0402 +80-20%	, C192, C195, C196, C229, C231, C235	16	
70		CHIP CAP 1uF/25V 0603 +80-20%	C114	1	
71				6	
72		CHIP CAP 2. 2uf 0603 ±5% CHIP CAP 4. 7UF 0603 +80-20%	C180, C182, C204, C209, C222, C224 C60, C232	2	
73			C201		
13		CHIP CAP 4. 7uF/25V 0805 +80-20%	C201	1	
			C7, C49, C62, C73, C80, C87, C89, C91, C93, C95, C97, C		
74		CHIP CAP C1608Y5V0J106ZT(TDK) 10UF 0603	99, C110, C111, C112, C118, C119, C121, C122, C124, C	29	
			125, C126, C130, C131, C132, C200, C218, C219, C226		
75		CHIP CAP 1nF 0402 ±5%	C69, C70, C77, C227	4	
76		Tantalum capacitor 22uF 6.3V C3216 \pm 20%	CD1, CD2, CD17	3	
77	贴片钽电容	Tantalum capacitor 10uF 10V C3216 $\pm 20\%$	CD3, CD4	2	
78		Tantalum capacitor 220uF 10V C3528 ±20%	CD5, CD6	2	
79	山岸	10uH/1.0A L_4X4_SMD	L2, L3, L4, L5	4	
80	电感	22uH/1. 0A L_4X4_SMD	L1	1	
81		4. 3″ 480*272 FH12-40S-0. 5SH(55)B上接	J2	1	
82		USB座 MINI USBAB MINIUSB-B-1	J13	1	
83		TF卡座 Push/Push TF CARD TF-CARD	J15	1	
84	接插件	喇叭 8 OHM SIP-2B	SPK2	1	
85		MIC MIC4MM_DIP	M1	1	
86		耳机座 PJ-311	J14	1	
87	<u> </u>	按键 TRE-901A	SW1, SW2, SW3, SW4, SW5, SW6, SW7	7	
88	PCB板	PCB单板		1	
89	-	增加1K 0805电阻 手焊			
G-SENS	OR				
1	TC	MMAZAERI /LICSEDE LCA 14	IIIO	1	
2	IC	MMA7455L/LIS35DE LGA-14	U8	1	
3	磁珠	FB 120R@100MHz 0402	FB14, FB15	2	
4	肝比击效	CHIP CAP 0.1UF 0402 ±5%	C106, C108	2	
5	贴片电容	CHIP CAP C1608Y5V0J106ZT(TDK) 10UF 0603	C105, C107	2	
					

6	贴片电阻	CHIP RESISTOR OR 0402 ±5%	R201, R205	2	
			·		
wo to	uch				
1	IC	AK4187 QFN16_3X3	U29	1	
2	贴片电阻	CHIP RESISTOR 200R 0402 $\pm 10\%$	R214	1	
3		CHIP RESISTOR 68R 0402 ±10%	R215	1	
4		CHIP RESISTOR 578R 0402 $\pm 10\%$	R116	1	
5		CHIP RESISTOR 200R 0402 ±10%	R119	1	
6	→ 贴片电容	CHIP CAP 0.1UF 0402 ±5%	C267, C269	2	
7		CHIP CAP 1UF 0603 +80-20%	C268	1	