Mini-[2.4GHz] User's Manual Ver:2.0



Safety Precautions

Safety Matters

Æ

To avoid injury, death of personnel or damage to the equipment the operator must refer to the explanations in this User's Manual.

Battery: There is a lithium-ion rechargeable battery in this device. Don't water this device, or put it in a humid environment for a long time or the device will be damaged.



Attention to traffic safety

(CAR PC): Do not use the device while driving. When you want to use it, please park your car.



Turn off this device on planes

This Electronic wireless product can disturb the communications systems of planes.

Please turn if off before boarding.



In vicinity of dangerous goods to be shut down

In gas station and close to fuel and chemical agents and other hazardous materials areas, please turn the device off.



Turn off this device in hospital

Please turn the device off in areas with "no wireless device" indication.

Wireless devices may interfere with implanted cardiac pacemakers, hearing aids and other

Medical implant devices.




Interference

All wireless devices may be subject to interference, thus affecting the performance of this product.



Accissories

Only use factory specified parts. Please use the supplied travel charging cable. the use of other charging devices may be dangerous.



Overview


This is a wonderful combo, 2.4GHz Wireless mini QWERTY keyboard, Touch Pad and presenter combo.

This groduct consists not only of normal wireless keyboard keys,but also of multimedia control keys and PC gaming control keys. It has built-in programmable smart touch pad-the world's first Touchpad which can be used in horizontal and vertical directions. It has power indicator, RF signal indicator, CAPSLOCK

light,low-voltage indicator and keypad backlight to facilitate the use in dark environments.In addition,it also has a built-in pointer.

Introduction

Product overview



Touchpad

The touchpad can be used in a Fn horizontal or vertical position.

To switch between horizontal or vertical mode, hold the Fn key

and hit the Alt key.

Enabling the backlight

Once the keyboard has established, the backlight keys will automatically turn on for 3 seconds. The backlight will turn off after 3 seconds to preserve battery life. To manually turn the backlight on, simply press the key specified above in the diagram.

Auto sleep and wake feature

The keyboard also features an auto sleep and auto wake mode. If there is a long period of inactivity, the keyboard will automatically go into a sleep mode. During the sleep mode, the user can wake the unit up by pressing any key. The 2.4 GHz keyboard's RF indicator will continue to flash and will not power down.

Switching off the keyboard after use

After finishing using the keyboard, push the switch to the off position. This turns off the power, of the keyboard. so it is being kept safely.

Charging the battery

The device with built-in lithium-ion battery, please use only approved data lines and chargers.

Note: Fully charge the unit before operating for the first time. This device can be used when charging, but will extend the charging time;

When the battery is low, the low-voltage light will flash to warn the user. The unit will automatically turn off if the battery has been depleted.

Laser pointer

Using the laser pointer only requires that the keyboard will be turned on. Press the Laser Switch as long as you want to use the laser pointer.

Appendix

Technical parameters

Specification

- Measurements (L x W x H): 151mm x 59mm x 12.5mm
- \checkmark Weight (grams): 100g / 0.22 pound
- © Operational Range: up to 10 meters/ 30 feet
- Transmit power: +4db Max.
- © Operation voltage: 3.7V
- © Operation current: < 80mA
- © Charging current: < 300mA
- Sleep current: < 1mA

Computer system requirements

- Windows 2000
- Windows XP
- Windows Vista ,Windows CE, Windows 7
- Linux(Debian-3.1,Redhat-9.0 Ubuntu-8.10 Fedora-7.0 tested)

Maintenance

To not attempt to disassemble the device or replace rechargeable battery. Doing so

will void the warranty.

- The battery will discharge if stored for a long period of time without usage.
- Use the specified charger. Disconnect the device after the battery has been fully charged. Overcharging the battery will shorten the life span of the battery.
- To not expose the device in extreme heat or cold. Extreme temperatures will cause the life span of the battery to shorten.
- Use only a damp cloth with mild soap to clean the device. Solvents and other cleaning agents may cause damage to the device.

Troubleshooting

Below are some basic troubleshooting scenarios for the device. Please contact support from the place of purchase if you are unable to resolve any issues with the device.

Unit does not respond.	 Low battery power. Unit is not turned on. 	1.Charge the device for at least 15 minutes. 2.Check if the switch selected to the "ON" position.
Keyboard cannot establish a connection to the PC.	Possible wireless interference with another device.	1.Change the channel of the device by pressing and holding the Fn+ F1 key for 10 seconds and let the unit reconnect.
The mouse pointer moves erratically and/or unresponsive.	Dust or oil on the touchpad.	1.Clean the touchpad with a damp cloth.
The unit does not charge.	 Defective battery. Check connections. 	1.Contact your local dealer for replacements.2.Verify if the device is securely connected to the charger.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.