

BLUETOOTH® SPEAKER WITH NFC

URBAN



The Bluetooth® word mark and logos are registered trademarks owned by Blueto any use of such marks by The Source (Bell) Electronics Inc. is under license. Other trade names are those of their respective owners. oth® SIG. Inc

8062738 INSTRUCTION MANUAL

WHAT'S INCLUDED:

- Bluetooth® speaker
- USB to micro USB charging cable
- 3.5mm to 3.5mm audio cable
- User Manual
- Lanyard

FEATURES:

- 1 Bluetooth BK V2 1
- 2. NFC Connectivity
- 3. Handsfree telephone calling
- 5. Operating distance up to 10 meters /33 feet
- 6. Operation time up to 7 hours(50% volume level)
- 7. 3.5mm line-in
 8. IPX7 Water-Resistant feature

COMPONENT IDENTIFICATION

- 1 Power ON/OFF
- 3. Volume-
- 4. Volume+
- 6. Blue LED indicator
- 7. Red LED indicator 8. USB charging jack
- 9. Aux-in iack
- 10. NFC connection location







PRODUCT OVERVIEW

You can use this item with iPads, iPhones, iPods and many types of smartphones to stream music, and enjoy handsfree calling. In order to get the best results when using this device, please read this manual first before using. This unit has IPX7 rating: Protected against heavy pools/seas water projected to pass test condition that to have the unit immersion in water of depth 1 meter with duration time 30 minutes. Exactly the units can be floating in water.

PAIRING

- Make sure your Bluetooth audio source is held within 10 meters of your speaker.
- 2. Press and hold the power ON/OFF button about one second to turn the speaker ON. Voice prompt says, "Power on" while blue LED indicator will blink slowly, then "pairing" while blue LED indicator will blink quickly.
- 3. Enable your Bluetooth device, and make sure it is in searching mode.
 4. Select "HR Urban Mini" from the list of discovered Bluetooth devices on your mobile phor The voice prompt says, "Your device is connected". Once paired the blue LED will be solid blue
- Nou can now listen to your music or make/receiver telephone calls on the speaker.
 Press buttons "-" or "+" to volume down or volume up for getting favorable volume lev
- 7. To turn the speaker OFF, press and hold the power ON/OFF button about one second, the
- voice prompt says, "Power off".

 Tip: The next time when you switch on the speaker it will connect automatically as long as your

Bluetooth function is switched on your audio device. The voice prompt will say, "Power on" while blue LED indicator will blink slowly, then "Your device is connected" while blue LED indicator will be solid blue When you disconnect the speaker after paired, the voice prompt will say "Your device is

disconnected" while the blue LED light will start to blink quickly. The speaker has entered into pairing mode. If there is no device paired within 15 minutes the speaker will turn off.

Note:Once Bluetooth paired, the speaker will automatically power off if no signals are received for 15 minutes

PAIRING BY ONE-TOUCH CONNECTION WITH NFC

- Enable the NCF function on your device
 Use your NFC enabled device and touch the NFC logo on the speaker
- 3. Confirm the NFC connection on your device. This will vary depending on your device, check
- your device manual for compatibility.

 4. After paired, the voice prompt says "Your device is connected"

CHARGING

This speaker has a built-in rechargeable Li-ion battery. Fully charge the speaker before first use.

- Charge the battery as follows:

 1. Connect one end of the included USB charging cable to the charging port on your computer or

5. V/1A power adapter (sold separately).

2. The red LED light will turn ON. When the charge is complete the red LED light will turn OFF.

3. It will take 4 hours to fully charge the speaker by PC USB port.

Tip: When battery is low the voice prompt says "Battery Low" every 5 minutes to note need charge the speaker. After approximately 15 minutes if speaker does not get recharged the speaker will turn OFF while voice prompt says, "Power off".

HANDSFREE SPEAKERPHONE

When a smartphone is connected to your speaker follow the steps below to take calls handsfree.

- If there is an incoming call while streaming music, the speaker will beep to notify the call.
 Short press the Play/Pause button to pick up the call; Short press the Play/Pause button again
- to hang up the call.

 3. Press and hold the Play/Pause button for one second to reject the call.

1. Use the supplie d 3.5mm cable to connect the speaker directly with your device Tip: For source of Bluetooth and LINE-IN, Bluetooth function will be priority, which means if Bluetooth and Line-in are connected at same time, Bluetooth should be disconnected then LINE-IN can work. So while LINE-IN connected, Bluetooth is still on wait for paring status while the blue LED is blink quickly.

TO PLAY MUSIC FROM YOUR PC OR LAPTOP

After paring the device to your PC or laptop, right-click on speaker icon on the lower right hand corner of the task bar select "Playback devices". Under the "Playback" tab, the paired device will show within the list. To connect it, click on the device to set it as the default device. The audio will start to play from the paired device.

UNDERSTANDING THE LED STATUS LIGHTS

- When pairing your speaker to a Bluetooth device
 Slow blinking blue LED= Bluetooth searching paired device to ready pairing Quick blinking blue LED= Bluetooth is waiting for pairing. Solid blue LED= Bluetooth connected
- When connect your speaker to a device via 3.5mm to 3.5mm audio cable Solid red LED= Aux is connected
- When charging your speaker
 Solid red LED= charging
 Red LED OFF= charging complete

TECHNICAL SPECIFICATIONS

Output Power: 5W (RMS)
Battery Capacity: 3.7V, 1300mAh
Frequency Response: 100Hz~20KHz

Impedance: 4 Ohms

Operation Distance: Up to 10 meters /33 feet

NOTE: This speaker is in compliance with the specified Bluetooth® version. It does not guarantee compatibility with all the functions on every Bluetooth®-enabled device. Pleacheck your mobile phone's user manual for compatibility and functionality.

TROUBLESHOOTING

No Sound:

- Ensure the speaker is charged and has enough battery power for operation
 Ensure the speaker is switched ON
 Ensure Bluetooth® device is ON
 The volume of the speaker is too low, adjust the volume to an appropriate level

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THE FCC WANTS YOU TO KNOW

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Industry Canada Notice

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and(2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC:255A-8062738

THE SOURCE - WARRANTY



The Source warrants that this product will be free from defects in materials and workmanship for a period of 12 months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage

twiner available, without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

Imported by: The Source, Barrie, Ontario, Canada, L4M 4W5

Manufactured in China