

# CyberSafe247

ADSL2+ Wi-Fi Modem

Model CS247-B58-01

**USER MANUAL** 

Version 1.0



#### Copyright

- 1. Copyright for the Document and all material appearing on it, including but not limited to text, photographs, images, software, music, audio and video clips, (referred to collectively below as "Content") belongs to Hawa Technologies Inc. (The Company), the original author, or other entities.
- 2. Duplication, public transmission, modification, deletion, or reproduction of Content from the Document without the authorization of the copyright holder, whether the Company, the original author, or another entity, is prohibited under U.S. copyright law, international conventions and other copyright laws, except for printing or storage for personal use, or other specific use permitted under those laws. You are therefore requested to contact the Company to obtain permission before making use of Content appearing on the Website. Please note that the Company may refuse to grant permission to use Content at its sole discretion.
- 3. If use is made of Content with the permission of the Company, you are requested to display the copyright notice specified by the Company. Modification or deletion of the copyright notice without prior notice to the Company is prohibited.



# **Table of Contents**


Login	4
Quick Setup	5
ADSL Setup	5
Wireless Setup	
Change Adminstrator Password	
Register CyberSafe247 Suite Account	
Internet Policies	
Create a New Policy	
Edit a Policy	
Edit My Blocklist	
Website Lookup	
Internet Devices	
Usage Monitor	
View Internet Usage Data by Quick Links	17
Customize your own selection criteria	
Block a website from Usage Mornitor	
Regulatory Compliance Notices	
Class B Equipment	
Channel	



# Login

Open a Web browser, such as Firefox, Safari, or Microsoft Internet Explorer, and enter <a href="http://iamhome.cybersafe247.com">http://iamhome.cybersafe247.com</a> (or <a href="http://iamhome.cybersafe247.com">http://iamhome.cybersafe247.com





The admin login page appears. Enter the admin password (default "admin") and then click the "Login" button. The main menu page will appear onscreen.



## **Quick Setup**

Click on the "Quick Setup" icon on the main menu page. The Quick Setup page will appear on screen.



## **ADSL Setup**

Click the ADSL icon on the Quick Setup page.



You now have to enter the details of country, Internet Service Provider (ISP), time zone and your Username and Password.



Your ISP will have provided you with a username and password when you initially set up your account.

If you have forgotten them, simply call up your ISP and they'll come to your rescue.



If your ISP is not in the list, click "More Options". Input other parameters provided by your ISP.



Click "Save/Apply". The modem will reboot and apply the ADSL parameters. It may take up to 3 minutes for the modem to be connected to the internet.



## Wireless Setup

Click "Wireless" icon on the Quick Setup page.



The wireless setup page appears.



Choose the encryption method, wireless network name, and enter a password for the wireless network. Click the "Save/Apply" button






#### Change Adminstrator Password

Click "Change Admin Password" icon on the Quick Setup page.



Enter new admin password in the "New Password" text box. Re-enter the password in the "Verify Password" text box. Click "Save/Apply" button.





#### Register CyberSafe247 Suite Account

Click "Register Your CSS Account" icon on the Quick Setup page.



Enter your registration information in the text boxes and click "Register" button. Follow the prompts to finish the registration.







#### **Internet Policies**

Click on the "Internet Policies" icon on the main menu page. The Internet Policies page will appear on screen.



#### Create a New Policy

Click on the "Create New Policy" icon on the Internet Policies page. The "Create Policy" dialogue appears. Enter a policy name in the text box and click "Add" button.



## Edit a Policy

Click on a policy icon on the Internet Policies page. A context menu associated with the policy will appear. Click on the "Edit" menu item to edit the policy.





On the edit policy page, you can remove, create, or block website categories and software applications. You can also schedule time for each website category and software applications. After done all the editing, click the "Save" button to save all the changes.



## **Edit My Blocklist**

Click "My Blocklist" tag on the internet policies page.

To add a website to My Blocklist, enter the website in the text box and then click "Add New Website" button.





To remove a website from My Blocklist, Click the red box in front of the My Blocklist website item. A "Move Website From My Blocklist Into Other Category" dialogue will appear. Choose the right category for the website and click the "Yes" button. The website will be removed from My Blocklist and moved to the proper category.



## Website Lookup

Click "Website Lookup" tag on the internet policies page.

To look up a website's category, enter the website in the text box and click the "Lookup" button. The category information of the website will appear on screen. You can also recategorize it here if you feel another category is more suitable for the website.








#### **Internet Devices**

Click on the "Internet Devices" icon on the main menu page. The internet devices page will appear onscreen.






Click on the "Add New Device" button on the internet devices page. On the pop-up window, enter device name and choose correct policy. Enter the mac address and description of your device network interface in the "Mac Id" and "Description" text boxes, and then click the "Add" link beside the "Description" text box to add the Mac to this device. If this device has more than one network interface, enter each Mac and description and click the "Add" link to add all Macs to this device. Click the "Add" button to save the device.



Click on the "Discover New Device" button on the internet devices page. You will see a list of all the devices on your local network. Choose and name the devices you want to add and then click the "Save/Apply" button to save the devices.



Click on a device on the list. A context menu associated with the device will appear. Follow the prompts to edit, delete and merge the device.





## **Usage Monitor**

Click on the "Usage Monitor" icon on the main menu page. The Usage Monitor page will appear on screen.



## View Internet Usage Data by Quick Links

Click the "Top Websites" icon on the usage monitor page.



You can view the most viewed websites for last 7 day.





Click the "Top Devices" icon.



You can view the most used devices for last 7 day.





Click the "Top Categories" icon.



You can view the most viewed website categories for last 7 day.






Click the "Last 7 Days" icon.



You can view a quick summary of the last week.





## Customize your own selection criteria

Choose your selection criteria to search usage data. For this example, you can Choose a time period between 2011-05-01 00:00 and 2011-05-03 23:59 and select device "David's Laptop", and then click the "GO" button.



You can view usage data for device "David's Laptop" between 2011-05-01 00:00 and 2011-05-03 23:59.





#### Block a website from Usage Mornitor

select a usage data "<u>www.megavideo.com</u>", a pop-up will appear. Click on "Block websites" and you will block the website "<u>www.megavideo.com</u>".











## **Regulatory Compliance Notices**

#### Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



# Channel

Channel	Frequency(MHz)
1	2412
2	2417
3 4	2422
	2427
5	2432
6	2437
7	2442
8	2447
9	2452
10	2457
11	2462