**EUT-Internal View 1**

EUT-Internal View 2

**EUT-Internal View 3**

GSM
Antenna
Location

Main Board Top View

Main Board Bottom View1

Main Board Bottom View2

**Main Board Shielding Off Bottom View**

Bluetooth
Antenna
Location

GSM Antenna View

Battery View